

# **YAMAHA**

**Marine**

# **Outboards**

**150A, 150F,  
L150F, D150H,  
175D, 200F,  
L200F, 200G,  
225D**

**SERVICE  
MANUAL**

**64C-28197-Z8-11**

---

## PREFACE

This manual has been prepared by the Yamaha Motor Company, Ltd. primarily for use by Yamaha dealers and their trained mechanics when performing maintenance procedures and repairs to Yamaha equipment. It has been written to suit the needs of persons who have a basic understanding of the mechanical and electrical concepts and procedures inherent in the work, for without such knowledge attempted repairs or service to the equipment could render it unsafe or unfit for use.

Because the Yamaha Motor Company, Ltd. has a policy of continuously improving its products, models may differ in detail from the descriptions and illustrations given in this publication. Use only the latest edition of this manual. Authorized Yamaha dealers are notified periodically of modifications and significant changes in specifications and procedures, and these are incorporated in successive editions of this manual.

**150A, 150F, L150F, D150H, 175D,  
200F, L200F, 200G, 225D**

**SERVICE MANUAL**

**©1998 Yamaha Motor Co., Ltd.**

**1st Edition, October 1998**

**All rights reserved.**

**No part of this publication may be reproduced or transmitted in any form or by any means including photocopying and recording without the written permission of the copyright holder.**

**Such written permission must also be obtained before any part of this publication is stored in a retrieval system of any nature.**

## HOW TO USE THIS MANUAL

### MANUAL FORMAT

All of the procedures in this manual are organized in a sequential, step-by-step format. The information has been compiled to provide the mechanic with an easy to read, handy reference that contains comprehensive explanations of all disassembly, repair, assembly, and inspection operations.

For instance, the condition of a faulty component will precede an arrow symbol and the course of action required will follow the symbol.

- Bearings

Pitting/scratches → Replace.

To assist you in finding your way through this manual, the section title and major heading is given at the top of every page.

### MODEL INDICATION

Multiple models are mentioned in this manual and their model indications are noted as follows.

Model name	150AET	L150AET	150FETO		L150FETO		150GETO
USA and Canada name	C150TR	—	—	S150TR	—	L150TR	P150TR
Indication	150AET	L150AET	150FETO	S150FETO	L150FETO	LS150FETO	150GETO
Model name	D150HETO	175AET	175DETO		175FETO	200AET	L200AET
USA and Canada name	D150TR	—	—	S175TR	P175TR	—	—
Indication	D150HETO	175AET	175DETO	S175DETO	175FETO	200AET	L200AET
Model name	200FETO		L200FETO		200GETO	225DET	225DETO
USA and Canada name	200TR	S200TR	—	L200TR	P200TR	—	—
Indication	200FETO	S200FETO	L200FETO	LS200FETO	200GETO	225DET	225DETO

### ILLUSTRATIONS

The illustrations within this service manual represent all of the designated models.

### CROSS REFERENCES

The cross references have been kept to a minimum. Cross references will direct you to the appropriate section or chapter.

## IMPORTANT INFORMATION

In this Service Manual particularly important information is distinguished in the following ways.

 The Safety Alert Symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!

### WARNING

Failure to follow **WARNING** instructions could result in severe injury or death to the machine operator, a bystander, or a person inspecting or repairing the outboard motor.

### CAUTION:

A **CAUTION** indicates special precautions that must be taken to avoid damage to the outboard motor.

### NOTE:

A **NOTE** provides key information to make procedures easier or clearer.

## SPECIFICATIONS

These are given in bold type at each procedure. It is not necessary to leave the section dealing with the procedure in order to look up the specifications.

It is important to note the differences in specifications of models. When a procedure relates to more than one model, the main differences in specifications will be shown in a table similar to the following.

Model name	150AET	L150AET	150FETO		L150FETO		150GETO
USA and Canada name	C150TR	—	—	S150TR	—	L150TR	P150TR
Lubrication system	Pre-mixed	Pre-mixed	Oil injection		Oil injection		Oil injection
Model name	D150HETO	175AET	175DETO		175FETO	200AET	L200AET
USA and Canada name	D150TR	—	—	S175TR	P175TR	—	—
Lubrication system	Oil injection	Pre-mixed	Oil injection		Oil injection	Pre-mixed	Pre-mixed
Model name	200FETO		L200FETO		200GETO	225DET	225DETO
USA and Canada name	200TR	S200TR	—	L200TR	P200TR	—	—
Lubrication system	Oil injection		Oil injection		Oil injection	Pre-mixed	Oil injection



① <b>GEN INFO</b> 	② <b>SPEC</b> 
③ <b>INSP ADJ</b> 	④ <b>FUEL</b> 
⑤ <b>POWR</b> 	⑥ <b>LOWR</b> 
⑦ <b>BRKT</b> 	⑧ <b>ELEC</b> 
⑨ <b>TRBL ANLS</b> 	⑩ 
⑪ 	⑫ 
⑬ 	⑭ 
⑮ 	⑯ 
⑰ 	⑱ 
⑲ 	⑳ 
㉑ 	㉒ 
㉓ 	㉔ 

## SYMBOLS

Symbols ① to ⑨ are designed as thumb-tabs to indicate the content of a chapter.

- ① General information
- ② Specifications
- ③ Periodic inspections and adjustments
- ④ Fuel system
- ⑤ Power unit
- ⑥ Lower unit
- ⑦ Bracket unit
- ⑧ Electrical systems
- ⑨ Trouble analysis

Symbols ⑩ to ⑮ indicate specific data.

- ⑩ Special tool
- ⑪ Specified liquid
- ⑫ Specified engine speed
- ⑬ Specified torque
- ⑭ Specified measurement
- ⑮ Specified electrical value  
[Resistance (Ω), Voltage (V), Electric current (A)]

Symbol ⑯ to ⑱ in an exploded diagram indicate the grade of lubricant and the location of the lubrication point.

- ⑯ Apply Yamaha 2-stroke outboard motor oil (TC-W3)
- ⑰ Apply water resistant grease (Yamaha grease A, Yamaha marine grease)
- ⑱ Apply molybdenum disulfide oil

Symbols ⑲ to ㉔ in an exploded diagram indicate the grade of the sealing or locking agent and the location of the application point.

- ⑲ Apply Gasket Maker®
- ⑳ Apply Yamabond #4 (Yamaha bond number 4)
- ㉑ Apply LOCTITE® No. 271 (Red LOCTITE)
- ㉒ Apply LOCTITE® No. 242 (Blue LOCTITE)
- ㉓ Apply LOCTITE® No. 572
- ㉔ Apply silicon sealant

# CONTENTS

<b>GENERAL INFORMATION</b>	 GEN INFO	<b>1</b>
<b>SPECIFICATIONS</b>	 SPEC	<b>2</b>
<b>PERIODIC INSPECTIONS AND ADJUSTMENTS</b>	 INSP ADJ	<b>3</b>
<b>FUEL SYSTEM</b>	 FUEL	<b>4</b>
<b>POWER UNIT</b>	 POWR	<b>5</b>
<b>LOWER UNIT</b>	 LOWR	<b>6</b>
<b>BRACKET UNIT</b>	 BRKT	<b>7</b>
<b>ELECTRICAL SYSTEMS</b>	 ELEC	<b>8</b>
<b>TROUBLE ANALYSIS</b>	 TRBL ANLS	<b>9</b>





---

## CHAPTER 1 GENERAL INFORMATION



<b>IDENTIFICATION</b> .....	1-1
SERIAL NUMBER .....	1-1
STARTING SERIAL NUMBERS .....	1-1
<b>SAFETY WHILE WORKING</b> .....	1-2
FIRE PREVENTION .....	1-2
VENTILATION.....	1-2
SELF-PROTECTION.....	1-2
OILS, GREASES AND SEALING FLUIDS.....	1-2
GOOD WORKING PRACTICES .....	1-3
DISASSEMBLY AND ASSEMBLY .....	1-4
<b>SPECIAL TOOLS</b> .....	1-5
MEASURING .....	1-5
REMOVING AND INSTALLING .....	1-7



**IDENTIFICATION  
SERIAL NUMBER**

The outboard motor's serial number is stamped on a label which is attached to the port clamp bracket.

**NOTE:** \_\_\_\_\_

As an antitheft measure, a special label on which the outboard motor's serial number is stamped is bonded to the port clamp bracket. The label is specially treated so that peeling it off causes cracks across the serial number.

- ① Model name
- ② Approval model code
- ③ Transom height
- ④ Serial number


**STARTING SERIAL NUMBERS**

The starting serial number blocks are as follows:


Model name			Approval model code	Starting serial number	Model name			Approval model code	Starting serial number
World-wide	USA	Canada			World-wide	USA	Canada		
150AET	C150TR	—	6G4	L: 305521 - X: 704396 -	175FETO	P175TR		62H	L: 500647 -
L150AET	—		6K0	X: 750347 -	200AET	—		6G6	L: 308781 - X: 707018 -
150FETO	—		6G4	L: 352137 - X: 504118 -	L200AET	—		6K1	X: 752202 -
L150FETO	S150TR			L: 350142 - X: 501152 -	200FETO	200TR	—	6G6	L: 350991 - X: 506004 -
150GETO	P150TR		6K0	L: 502379 -	L200FETO	—			6K1
D150HETO	D150TR	—		L: 601301 -	200GETO	L200TR	—	61H	
175AET	—		6G5	L: 302440 - X: 701017 -	225DET	—		6K7	L: 400393 - X: 500160 -
175DETO	—			L: 350273 - X: 501252 -	225DETO	—			L: 450255 - X: 550266 -
	S175TR	—							

**SAFETY WHILE WORKING**


The procedures given in this manual are those recommended by Yamaha to be followed by Yamaha dealers and their mechanics.

**FIRE PREVENTION**

Gasoline (petrol) is highly flammable. Petroleum vapor is explosive if ignited. Do not smoke while handling gasoline and keep it away from heat, sparks and open flames.

**VENTILATION**

Petroleum vapor is heavier than air and is deadly if inhaled in large quantities. Engine exhaust gases are harmful to breathe. When test-running an engine indoors, maintain good ventilation.

**SELF-PROTECTION**

Protect your eyes with suitable safety glasses or safety goggles, when grinding or when doing any operation which may cause particles to fly off. Protect hands and feet by wearing safety gloves or protective shoes if appropriate to the work you are doing.

**OILS, GREASES AND SEALING FLUIDS**

Use only genuine Yamaha oils, greases and sealing fluids or those recommended by Yamaha.


Under normal conditions of use, there should be no hazards from the use of the lubricants mentioned in this manual, but safety is all-important, and by adopting good safety practices, any risk is minimized. A summary of the most important precautions is as follows:

1. While working, maintain good standards of personal and industrial hygiene.
2. Clothing which has become contaminated with lubricants should be changed as soon as practicable, and laundered before further use.
3. Avoid skin contact with lubricants; do not, for example, place a soiled wiping-rag in your pocket.
4. Hands and any other part of the body which have been in contact with lubricants or lubricant-contaminated clothing, should be thoroughly washed with hot water and soap as soon as practicable.
5. To protect the skin, the application of a suitable barrier cream to the hands before working, is recommended.
6. A supply of clean lint-free cloths should be available for wiping purposes.



### **GOOD WORKING PRACTICES**

1. The right tools  
Use the recommended special tools to protect parts from damage. Use the right tool in the right manner – do not improvise.
2. Tightening torque  
Follow the tightening torque instructions. When tightening bolts, nuts and screws, tighten the large sizes first, and tighten inner-positioned fixings before outer-positioned ones.




**3. Non-reusable items**

Always use new gaskets, packings, O-rings, split-pins, circlips, etc., on reassembly.



**DISASSEMBLY AND ASSEMBLY**

1. Clean parts with compressed air when disassembling.
2. Oil the contact surfaces of moving parts before assembly.



3. After assembly, check that moving parts operate normally.


4. Install bearings with the manufacturer's markings on the side exposed to view, and liberally oil the bearings.
5. When installing oil seals, apply a light coating of water-resistant grease to the outside diameter.

**SPECIAL TOOLS**

Using the correct special tools recommended by Yamaha, will aid the work and enable accurate assembly and tune-up. Improvising and using improper tools can damage the equipment.


**NOTE:**

- For U.S.A. and Canada, use part numbers that start with "J-", "YB-", "YM-", "YU-" or "YW-".
- For others countries, use part numbers that start with "90890-".




**MEASURING**

- ① Tachometer  
P/N. YU-08036-A ..... (a)  
90890-06760 ..... (b)
- ② Pressure tester  
P/N. YB-35956  
90890-06762
- ③ Mity vac  
P/N. YB-35956  
90890-06756
- ④ Pinion height gauge  
P/N. YB-34432-7, YB-34432-11,  
YB-34432-97  
90890-06702
- ⑤ Dial gauge set  
P/N. YU-03097  
90890-01252
- ⑥ Magnetic base  
P/N. YU-34481  
90890-06705
- ⑦ Digital caliper  
P/N. 90890-06704
- ⑧ Backlash indicator  
P/N. YB-06265  
90890-06706
- ⑨ Magnetic base attaching plate  
P/N. YB-07003  
90890-07003
- ⑩ Hydraulic pressure gauge  
P/N. 90890-06776
- ⑪ Up-relief valve attachment  
P/N. 90890-06773  
Down-relief valve attachment  
P/N. 90890-06774




- ⑫ Digital tester  
P/N. J-39299  
90890-06752
- ⑬ Peak voltage adapter  
P/N. YU-39991 ..... ①  
90890-03169 ..... ②
- ⑭ Spark gap tester  
P/N. YM-34487 ..... ①  
90890-06754 ..... ②
- ⑮ Diagnostic indicator  
P/N. YB-06765  
90890-06765
- ⑯ Shimming gauge  
P/N. YB-34446-1, YB-34446-3,  
YB-34446-4, YB-34446-7,  
YB-34446-8
- ⑰ Shimming gauge  
P/N. YB-34468-1, YB-34468-2,  
YB-34468-6
- ⑱ Shimming plate  
P/N. 90890-06701
- ⑲ Shift rod wrench  
P/N. YB-06052  
90890-06052
- ⑳ Test harness  
P/N. YB-06770, YB-38831,  
YB-38832  
90890-06770, 90890-06771,  
90890-06772




**REMOVING AND INSTALLING**

- ① Flywheel magnet assembly holder  
P/N. YB-06139 ..... (a)  
90890-06522 ..... (b)
- ② Universal puller  
P/N. YB-06117 ..... (a)  
90890-06521 ..... (b)
- ③ Bearing/oil seal attachment  
P/N. YB-06196 ..... (a)  
90890-06610, 90890-06637 .... (b)
- ④ Driver rod  
P/N. YB-06071  
90890-06602, 90890-06604,  
90890-06605, 90890-06606,  
90890-06652
- ⑤ Bearing/oil seal attachment  
P/N. YB-06205  
90890-06663
- ⑥ Bearing/oil seal attachment  
P/N. YB-06194, YB-06195,  
YB-06200, YB-06246,  
YB-06258, YB-06276,  
YB-06336  
90890-06619, 90890-06622,  
90890-06623, 90890-06624,  
90890-06629
- ⑦ Piston ring compressor  
P/N. YU-33294 ..... (a)  
90890-06530 ..... (b)
- ⑧ Bearing separator  
P/N. YB-06219 ..... (a)  
90890-06534 ..... (b)
- ⑨ Guide plate stand  
P/N. 90890-06538
- ⑩ Guide plate  
P/N. 90890-06501



- ⑪ Bearing puller  
P/N. 90890-06535
- ⑫ Bearing/oil seal attachment  
P/N. 90890-06659, 90890-06660,  
90890-06661, 90890-06662
- ⑬ Ring nut wrench  
P/N. YB-34447  
90890-06512
- ⑭ Ring nut wrench extension  
P/N. YB-06513  
90890-06513
- ⑮ Propeller shaft housing puller  
P/N. YB-06207 ..... ①  
YB-06502 ..... ②  
90890-06502
- ⑯ Center bolt  
P/N. 90890-06504
- ⑰ Slide hammer  
P/N. YB-06096  
90890-06531
- ⑱ Small universal claws  
P/N. 90890-06536
- ⑲ Bearing/oil seal depth plate  
P/N. YB-06213, YB-34474 ..... ①  
90890-06603 ..... ②
- ⑳ Drive shaft holder  
P/N. YB-06201  
90890-06520
- ㉑ Pinion nut holder  
P/N. 90890-06505
- ㉒ Pinion nut holder attachment  
P/N. 90890-06508
- ㉓ Bearing/oil seal attachment  
P/N. 90890-06609, 90890-06612,  
90890-06631, 90890-06633,  
90890-06636, 90890-06653
- ㉔ Bearing puller  
P/N. YB-06029, YB-06247  
90890-06523
- ㉕ Large universal claws  
P/N. 90890-06532



- ②⑥ Slide hammer attachment  
P/N. YB-06335  
90890-06514
- ②⑦ Ring nut wrench  
P/N. YB-42223
- ②⑧ Bearing/oil seal attachment  
P/N. YB-42225
- ②⑨ Bearing/oil seal attachment  
P/N. YB-42227
- ③⑩ Bearing/oil seal attachment  
P/N. YB-42229  
90890-06607
- ③① Pinion nut holder  
P/N. YB-42224
- ③② End screw wrench  
P/N. YB-06548  
90890-06548
- ③③ End screw wrench  
P/N. YB-06175-1A
- ③④ Universal puller  
P/N. YB-06540  
90890-06540

---

## **CHAPTER 2 SPECIFICATIONS**

**GENERAL SPECIFICATIONS**..... 2-1

**MAINTENANCE SPECIFICATIONS**..... 2-7

    POWER UNIT..... 2-7

    LOWER UNIT..... 2-12

    ELECTRICAL ..... 2-13

    DIMENSIONS ..... 2-16

**TIGHTENING TORQUES** ..... 2-18

    SPECIFIED TORQUES ..... 2-18

    GENERAL TORQUES ..... 2-20



**GENERAL SPECIFICATIONS**

Item	Unit		Model				
			150AET	L150AET	175AET	200AET	L200AET
			Worldwide USA Canada	C150TR	—	—	—
<b>DIMENSION</b>							
Overall length	mm (in)	828 (32.6)					
Overall width	mm (in)	600 (23.6)					
Overall height							
(L)	mm (in)	1,577 (62.1)	—	1,577 (62.1)	—		
(X)	mm (in)	1,703 (67.0)					
Boat transom height							
(L)	mm (in)	508 (20.0)	—	508 (20.0)	—		
(X)	mm (in)	635 (25.0)					
<b>WEIGHT</b>							
(with aluminum propeller)							
(L)	kg (lb)	178 (392.4)	—	178 (392.4)	—		
(X)	kg (lb)	182 (401.2)	—	182 (401.2)	—		
(with stainless steel propeller)							
(L)	kg (lb)	180 (396.8)	—	180 (396.8)	—		
(X)	kg (lb)	184 (405.6)	186 (410.1)	184 (405.6)	186 (410.1)		
<b>PERFORMANCE</b>							
Maximum output	kW (hp) @ 5,000 r/min	110.3 (150)		128.7 (175)	147.1 (200)		
Full throttle operating range	r/min	4,500 - 5,500					
Maximum fuel consumption	L (US gal, Imp gal)/hr @ 5,500 r/min	72 (19.0, 15.8)		75 (19.8, 16.5)	81 (21.4, 17.8)		
<b>POWER UNIT</b>							
Type		2 stroke - V					
Number of cylinders		6					
Displacement	cm <sup>3</sup> (cu. in)	2,596 (158.4)					
Bore × stroke	mm (in)	90.0 × 68.0 (3.54 × 2.68)					
Compression ratio		6.2	6.0	5.9			
Compression pressure	kPa (kg/cm <sup>2</sup> )	745 (7.45)		892 (8.92)			
Spark plugs (NGK)		BR8HS-10/BR8HS-10* <sup>1</sup>					
Number of carburetors		3					
Enrichment system		Choke valve					
Intake system		Reed valve					
Induction system		Loop charge					
Exhaust system		Through prop boss					
Lubrication system		Pre-mix					
Cooling system		Water					

\*1: For china



Item	Unit		Model				
			150AET	L150AET	175AET	200AET	L200AET
			C150TR	—	—	—	—
Ignition system			CDI				
Starting system			Electric				
Advance type			Mechanical				
<b>FUEL AND OIL</b>							
Fuel type			Unleaded regular gasoline				
Fuel rating		*PON	86				
		RON	91				
Engine oil type			2-stroke outboard engine oil				
Engine oil grade			TC-W3				
Engine oil capacity (engine oil tank)		L (US qt, Imp qt)	—				
(sub-oil tank)		L (US qt, Imp qt)	—				
Gear oil type			Hypoid gear oil SAE 90				
Gear oil total quantity	cm <sup>3</sup> (US oz, Imp oz)		980 (33.1, 34.5)	870 (29.4, 30.6)	980 (33.1, 34.5)	870 (29.4, 30.6)	
<b>BRACKET</b>							
Trim angle (at 12° boat transom)	Degree		-4 - 16				
Tilt-up angle	Degree		70				
Steering angle	Degree		35 + 35				
<b>DRIVE UNIT</b>							
Gear shift positions			F-N-R				
Gear ratio			1.86 (26/14)				
Reduction gear type			Spiral bevel gear				
Clutch type			Dog clutch				
Propeller shaft type			Spline				
Propeller direction (rear view)			Clockwise	Counter- clockwise	Clockwise	Counter- clockwise	

\* PON: Pump Octane Number  
 RON: Research Octane Number



Item	Worldwide USA Canada		Unit	Model							
				150FETO		L150FETO		150GETO	D150HETO	175DETO	
				—	S150TR	—	L150TR	P150TR	D150TR	—	S175TR
				—	—	—	—	P150TR	—	—	—
<b>DIMENSION</b>											
Overall length	mm (in)	823 (32.4)				896 (35.3)	823 (32.4)				
Overall width	mm (in)	577 (22.7)									
Overall height (L)	mm (in)	1,615 (63.6)		—	1,637 (64.4)	1,573 (61.9)	1,615 (63.6)	—			
(X)	mm (in)	1,742 (68.6)			—		1,742 (68.6)				
Boat transom height (L)	mm (in)	508 (20.0)		—	508 (20.0)			—			
(X)	mm (in)	635 (25.0)			—		635 (25.0)				
<b>WEIGHT</b>											
(with aluminum propeller) (L)	kg (lb)	192 (423.3)		—		192 (423.3)		—			
(X)	kg (lb)	196 (432.1)		—		196 (432.1)					
(with stainless steel propeller) (L)	kg (lb)	194 (427.7)	196 (432.1)	—	194 (427.7)	198.5 (437.6)	194 (427.7)	—			
(X)	kg (lb)	198 (436.5)		200 (440.9)		—		198 (436.5)			
<b>PERFORMANCE</b>											
Maximum output	kW (hp) @ 5,000 r/min	110.3 (150)				128.7 (175)					
Full throttle operating range	r/min	4,500 - 5,500									
Maximum fuel consumption	L (US gal, Imp gal)/hr @ 5,500 r/min	72 (19.0, 15.8)	69 (18.2, 15.2)	72 (19.0, 15.8)	69 (18.2, 15.2)	75 (19.8, 16.5)		74 (19.6, 16.3)			
<b>POWER UNIT</b>											
Type	2 stroke - V										
Number of cylinders	6										
Displacement	cm <sup>3</sup> (cu. in)	2,596 (158.4)									
Bore × stroke	mm (in)	90.0 × 68.0 (3.54 × 2.68)									
Compression ratio		6.2			5.9		6.0				
Compression pressure	kPa (kg/cm <sup>2</sup> )	—									
Spark plugs (NGK)		BR7HS-10				BR8HS-10					
Number of carburetors		3									
Enrichment system		Choke valve									
Intake system		Reed valve									
Induction system		Loop charge									
Exhaust system		Through prop boss									
Lubrication system		Oil injection									



Item	Unit		Model							
			150FETO		L150FETO		150GETO	D150HETO	175DETO	
			—	S150TR	—	L150TR	P150TR	D150TR	—	S175TR
			—	—	—	—	P150TR	—	—	—
Cooling system Ignition system Starting system Advance type			Water Microcomputer (CDI) Electric Mechanical and microcomputer							
<b>FUEL AND OIL</b> Fuel type Fuel rating Engine oil type Engine oil grade Engine oil capacity (engine oil tank) (sub-oil tank) Gear oil type Gear oil total quantity		*PON RON  L (US qt, Imp qt) L (US qt, Imp qt) cm <sup>3</sup> (US oz, Imp oz)	Unleaded regular gasoline 86 91 2-stroke outboard engine oil TC-W3 0.9 (0.95, 0.79) 10.5 (11.1, 9.2) Hypoid gear oil SAE 90							
			980 (33.1, 34.5)	870 (29.4, 30.6)	980 (33.1, 34.5)	900 (30.4, 31.7)	980 (33.1, 34.5)			
<b>BRACKET</b> Trim angle (at 12° boat transom) Tilt-up angle Steering angle		Degree Degree Degree	-4 - 16 70 35 + 35							
<b>DRIVE UNIT</b> Gear shift positions Gear ratio Reduction gear type Clutch type Propeller shaft type Propeller direction (rear view)			F-N-R 1.86 (26/14)      2.00 (28/14)      2.00 (26/13)      1.86 (26/14) Spiral bevel gear Dog clutch Spline Clockwise      Counterclockwise      Clockwise      Forward: Counterclockwise Rear: Clockwise							

\* PON: Pump Octane Number  
RON: Research Octane Number








Item	Unit		Model								
			Worldwide	200FETO		L200FETO		200GETO	225DET	225DETO	
			USA	P175TR	200TR	S200TR	—	L200TR	P200TR	—	—
			Canada	P175TR	—	S200TR	—	—	P200TR	—	—
<b>DIMENSION</b>											
Overall length	mm (in)	823 (32.4)									
Overall width	mm (in)	577 (22.7)									
Overall height (L)	mm (in)	1,637 (64.4)	1,615 (63.6)	—	1,615 (63.6)	—	1,637 (64.4)	1,615 (63.6)			
(X)	mm (in)	—	1,742 (68.6)				—	1,742 (68.6)			
Boat transom height (L)	mm (in)	508 (20.0)		—	508 (20.0)	—	508 (20.0)				
(X)	mm (in)	—	635 (25.0)				—	635 (25.0)			
<b>WEIGHT</b>											
(with aluminum propeller) (L)	kg (lb)	—	192 (423.3)	—			191 (421.1)	192 (423.3)			
(X)	kg (lb)	—	196 (432.1)		—			195 (429.9)	196 (432.1)		
(with stainless steel propeller) (L)	kg (lb)	194 (427.7)		—	196 (432.1)	—	194 (427.7)	193 (425.5)	194 (427.7)		
(X)	kg (lb)	—	198 (436.5)		200 (440.9)		—	197 (434.3)	198 (436.5)		
<b>PERFORMANCE</b>											
Maximum output	kW (hp) @ 5,000 r/min	128.7 (175)	147.1 (200)				165.5 (225)				
Full throttle operating range	r/min	4,500 - 5,500				5,000 - 6,000					
Maximum fuel consumption	L (US gal, Imp gal)/hr @ 5,500 r/min	78 (20.6, 17.2)	81 (21.4, 17.8)	82 (21.7, 18.0)	81 (21.4, 17.8)	82 (21.7, 18.0)	88 (23.2, 19.4)	87 (23.0, 19.1)			
<b>POWER UNIT</b>											
Type		2 stroke - V									
Number of cylinders		6									
Displacement	cm <sup>3</sup> (cu. in)	2,596 (158.4)									
Bore × stroke	mm (in)	90.0 × 68.0 (3.54 × 2.68)									
Compression ratio		6.0	6.2				6.05				
Compression pressure	kPa (kg/cm <sup>2</sup> )	—	892 (8.92)				834 (8.34)				
Spark plugs (NGK)		BR8HS-10									
Number of carburetors		3									
Enrichment system		Choke valve									
Intake system		Reed valve									
Induction system		Loop charge									






Item	Unit		Model							
			Worldwide	200FETO		L200FETO		200GETO	225DET	225DETO
			USA	200TR	S200TR	—	L200TR	P200TR	—	—
			Canada	—	S200TR	—	—	P200TR	—	—
Exhaust system	Through prop boss									
Lubrication system	Oil injection					Pre-mix	Oil injection			
Cooling system	Water									
Ignition system	Microcomputer (CDI)									
Starting system	Electric									
Advance type	Mechanical and microcomputer									
<b>FUEL AND OIL</b>										
Fuel type	Unleaded regular gasoline									
Fuel rating	*PON	86								
	RON	91								
Engine oil type	2-stroke outboard engine oil									
Engine oil grade	TC-W3									
Engine oil capacity (engine oil tank)	L (US qt, Imp qt)	0.9 (0.95, 0.79)				—	0.9 (0.95, 0.79)			
(sub-oil tank)	L (US qt, Imp qt)	10.5 (11.1, 9.2)				—	10.5 (11.1, 9.2)			
Gear oil type	Hypoid gear oil SAE 90									
Gear oil total quantity	cm <sup>3</sup> (US oz, Imp oz)	980 (33.1, 34.5)		870 (29.4, 30.6)		980 (33.1, 34.5)				
<b>BRACKET</b>										
Trim angle (at 12° boat transom)	Degree	-4 - 16								
Tilt-up angle	Degree	70								
Steering angle	Degree	35 + 35								
<b>DRIVE UNIT</b>										
Gear shift positions	F-N-R									
Gear ratio	1.86 (26/14)									
Reduction gear type	Spiral bevel gear									
Clutch type	Dog clutch									
Propeller shaft type	Spline									
Propeller direction (rear view)		Clockwise		Counterclockwise		Clockwise				

\* PON: Pump Octane Number  
 RON: Research Octane Number

**MAINTENANCE SPECIFICATIONS  
POWER UNIT**




Item	Unit	Model			
		150 hp	175 hp	200 hp	225 hp
<b>CYLINDER HEADS</b> Warpage limit  (lines indicate straightedge position)	mm (in)	0.10 (0.004)			
<b>CYLINDERS</b> Bore size Wear limit Taper limit Out-of-round limit 	mm (in)	90.00 - 90.02 (3.543 - 3.544)			
<b>PISTONS</b> Piston diameter (D) Measuring point (H) Piston-to-cylinder clearance <Limit> Oversize piston diameter 1st 2nd 	mm (in)	89.895 - 89.915 (3.5392 - 3.5400)			
<b>PISTON RINGS</b> Type (B) (T) End gap (installed) <Limit> Side clearance 	mm (in)	Keystone			
<b>CRANKSHAFT</b> Runout limit 	mm (in)	0.05 (0.002)			
<b>CONNECTING RODS</b> Small-end axial play (F) Big-end side clearance (E) 	mm (in)	0.12 - 0.26 (0.005 - 0.010)			
	mm (in)	2.0 (0.08)			



Item	Worldwide		Unit	Model				
	USA	Canada		150AET	L150AET	175AET	200AET	L200AET
				C150TR	—	—	—	—
<b>CARBURETORS</b>								
ID mark				64C00	64D00	64E00		
Main jet			#	150, 154 (PU, PM)*, 158 (PL)*		150, 152 (SL)*, 154 (PU, PM)*, 158 (PL)*		
Main air jet			#	310	280	270		
Main nozzle (inside diameter)			mm (in)	4.2 (0.17)		4.5 (0.18)		
Pilot jet			#	84				
Pilot air jet			#	60				
Pilot screw			Turn out	1 ± 1/4	1-1/16 ± 1/4	1-1/8 ± 1/4		
Float height			mm (in)	16.0 ± 0.5 (0.63 ± 0.02)				
								
Valve seat diameter			mm (in)	1.2 (0.05)				
Idling speed			r/min	700 ± 25				
Trolling speed			r/min	575 ± 25				
<b>OIL INJECTION PUMP</b>								
ID mark				—				
Oil discharge (for 3 minutes)			cm <sup>3</sup> (US oz, Imp oz) @ 1,500 r/min	—				
Bleeding				—				
<b>REED VALVES</b>								
Reed valve stopper height ①			mm (in)	6.5 ± 0.3 (0.26 ± 0.01)				
								
Warpage limit ②			mm (in)	0.2 (0.008)				
<b>THERMOSTATS</b>								
Opening temperature			°C (°F)	48 - 52 (118 - 126)				
Full-open temperature			°C (°F)	60 (140)				
								
Valve open lower limit			mm (in)	3 (0.12)				




\*: (PL) Port lower (PU) Port upper  
(PM) Port middle (SL) Starboard lower



Item	Unit		Model					
			150FETO		L150FETO		150GETO	D150HETO
			—	S150TR	—	L150TR	P150TR	D150TR
			—	—	—	—	P150TR	—
	Worldwide							
	USA							
	Canada							
<b>CARBURETORS</b>								
ID mark			64C00	64CS0	64C00	64CS0	64K00	
Main jet		#	150, 154 (PU, PM)*, 158 (PL)*	142	150, 154 (PU, PM)*, 158 (PL)*	142	152, 154 (PU, PM)*, 158 (PL)*	
Main air jet		#	310					
Main nozzle (inside diameter)		mm (in)	4.2 (0.17)	4.0 (0.16)	4.2 (0.17)	4.0 (0.16)	4.2 (0.17)	
Pilot jet		#	84					
Pilot air jet		#	60					
Pilot screw		Turn out	1 ± 1/4	1-1/4 ± 1/4	1 ± 1/4	1-1/4 ± 1/4	1-9/16 ± 1/4 (S)* 1-1/16 ± 1/4 (P)*	
Float height		mm (in)	16.0 ± 0.5 (0.63 ± 0.02)					
								
Valve seat diameter		mm (in)	1.2 (0.05)					
Idling speed		r/min	700 ± 25					
Trolling speed		r/min	575 ± 25					
<b>OIL INJECTION PUMP</b>								
ID mark			6R400					
Oil discharge (for 3 minutes)		cm <sup>3</sup> (US oz, Imp oz) @ 1,500 r/min	3.4 ± 0.7 (0.115 ± 0.024, 0.120 ± 0.025)					
Bleeding			Screw type					
<b>REED VALVES</b>								
Reed valve stopper height ①		mm (in)	6.5 ± 0.3 (0.26 ± 0.01)					
								
Warpage limit ②		mm (in)	0.2 (0.008)					
<b>THERMOSTATS</b>								
Opening temperature		°C (°F)	48 - 52 (118 - 126)					
Full-open temperature		°C (°F)	60 (140)					
								
Valve open lower limit		mm (in)	3 (0.12)					




\*: (P) Port (PM) Port middle (PL) Port lower  
 (PU) Port upper (S) Starboard



Item	Unit		Model					
			175DETO		175FETO	200FETO		
			—	S175TR	P175TR	200TR	S200TR	
			—	—	P175TR	—	S200TR	
	Worldwide							
	USA							
	Canada							
<b>CARBURETORS</b>								
ID mark			64D00	64DS0	64L00	64E00	64ES0	
Main jet	#		150, 154 (PU, PM)*, 158 (PL)*	142	152, 154 (PU, PM)*, 158 (PL)*	150, 152 (SL)*, 154 (PU, PM)*, 158 (PL)*	146	
Main air jet	#		280	310	280	270	310	
Main nozzle (inside diameter)	mm (in)		4.2 (0.17)	4.0 (0.16)	4.2 (0.17)	4.5 (0.18)	4.0 (0.16)	
Pilot jet	#		84		80	84		
Pilot air jet	#		60					
Pilot screw	Turn out		1-1/16 ± 1/4	1-1/8 ± 1/4	1-5/8 ± 1/4 (S)* 1-1/8 ± 1/4 (P)*	1-1/8 ± 1/4	1-1/8 ± 1/4 (S)* 5/8 ± 1/4 (P)*	
Float height	mm (in)		16.0 ± 0.5 (0.63 ± 0.02)					
								
Valve seat diameter	mm (in)		1.2 (0.05)					
Idling speed	r/min		700 ± 25					
Trolling speed	r/min		575 ± 25		570 ± 25	575 ± 25		
<b>OIL INJECTION PUMP</b>								
ID mark			6R400			6R510		
Oil discharge (for 3 minutes)	cm <sup>3</sup> (US oz, Imp oz) @ 1,500 r/min		3.4 ± 0.7 (0.115 ± 0.024, 0.120 ± 0.025)			4.8 ± 1.1 (0.162 ± 0.037, 0.169 ± 0.039)		
Bleeding			Screw type					
<b>REED VALVES</b>								
Reed valve stopper height (a)	mm (in)		6.5 ± 0.3 (0.26 ± 0.01)					
								
Warpage limit (b)	mm (in)		0.2 (0.008)					
<b>THERMOSTATS</b>								
Opening temperature	°C (°F)		48 - 52 (118 - 126)					
Full-open temperature	°C (°F)		60 (140)					
								
Valve open lower limit	mm (in)		3 (0.12)					

\*: (P) Port (PM) Port middle (S) Starboard (PL) Port lower (PU) Port upper (SL) Starboard lower



Item	Unit		Model				
			L200FETO		200GETO	225DET	225DETO
			—	L200TR	P200TR	—	—
			—	—	P200TR	—	—
<b>CARBURETORS</b>							
ID mark			<b>64E00</b>	<b>64ES0</b>	<b>64F00</b>		
Main jet	#		150,152 (SL)*, 154 (PU, PM)*, 158 (PL)*	146	150, 154 (PU, PM)*, 158 (PL)*		
Main air jet	#		270	310	260		
Main nozzle (inside diameter)	mm (in)		4.5 (0.18)	4.0 (0.16)	4.5 (0.18)		
Pilot jet	#		84		80		
Pilot air jet	#		60				
Pilot screw	Turn out		1-1/8 ± 1/4	1-1/8 ± 1/4 (S)* 5/8 ± 1/4 (P)*	1-1/4 ± 1/4 (S)* 3/4 ± 1/4 (P)*		
Float height	mm (in)		16.0 ± 0.5 (0.63 ± 0.02)				
							
Valve seat diameter	mm (in)		1.2 (0.05)				
Idling speed	r/min		700 ± 25				
Trolling speed	r/min		575 ± 25	600 ± 25			
<b>OIL INJECTION PUMP</b>							
ID mark			<b>6R510</b>		—		
Oil discharge (for 3 minutes)	cm <sup>3</sup> (US oz, Imp oz) @ 1,500 r/min		4.8 ± 1.1 (0.162 ± 0.037, 0.169 ± 0.039)		—		
Bleeding			Screw type		—		
<b>REED VALVES</b>							
Reed valve stopper height ①	mm (in)		6.5 ± 0.3 (0.26 ± 0.01)				
							
Warpage limit ②	mm (in)		0.2 (0.008)				
<b>THERMOSTATS</b>							
Opening temperature	°C (°F)		48 - 52 (118 - 126)				
Full-open temperature	°C (°F)		60 (140)				
							
Valve open lower limit	mm (in)		3 (0.12)				

\*: (P) Port (PM) Port middle (S) Starboard  
 (PL) Port lower (PU) Port upper (SL) Starboard lower

**LOWER UNIT**

Item	Model		
	Worldwide	Unit	
	USA		
	Canada		
		L150AET	L150FETO
		—	L150TR
		—	—
		L200AET	L200FETO
		—	L200TR
		—	—
<b>GEAR BACKLASH</b>			
Pinion - forward gear	mm (in)	0.21 - 0.43 (0.008 - 0.017)	
Pinion - reverse gear	mm (in)	0.97 - 1.29 (0.038 - 0.051)	
Pinion shims	mm	0.10, 0.12, 0.15, 0.18, 0.30, 0.40, 0.50	
Forward gear shims	mm	0.10, 0.12, 0.15, 0.18, 0.30, 0.40, 0.50	
Reverse gear shims	mm	0.10, 0.12, 0.15, 0.18, 0.30, 0.40, 0.50	

Item	Model								
	Worldwide	Unit	150AET	150FETO	150GETO	D150HETO	175AET	175DETO	175FETO
	USA		C150TR	S150TR	P150TR	D150TR	—	S175TR	P175TR
	Canada		—	—	P150TR	—	—	—	P175TR
<b>GEAR BACKLASH</b>									
Pinion - forward gear	mm (in)	0.25 - 0.46 (0.010 - 0.018)	0.71 - 1.01 (0.028 - 0.040)	0.19 - 0.59 (0.007 - 0.023)	0.25 - 0.46 (0.010 - 0.018)				
Pinion - reverse gear	mm (in)	0.74 - 1.29 (0.029 - 0.051)	0.79 - 1.38 (0.031 - 0.054)	0.39 - 0.70 (0.015 - 0.028)	0.74 - 1.29 (0.029 - 0.051)				
Pinion shims	mm	0.10, 0.12, 0.15, 0.18, 0.30, 0.40, 0.50							
Forward gear shims	mm	0.10, 0.12, 0.15, 0.18, 0.30, 0.40, 0.50							
Reverse gear shims	mm	0.10, 0.12, 0.15, 0.18, 0.30, 0.40, 0.50							

Item	Model						
	Worldwide	Unit	200AET	200FETO	200GETO	225DET	225DETO
	USA		—	(S)200TR	P200TR	—	—
	Canada		—	S200TR	P200TR	—	—
<b>GEAR BACKLASH</b>							
Pinion - forward gear	mm (in)	0.25 - 0.46 (0.010 - 0.018)					
Pinion - reverse gear	mm (in)	0.74 - 1.29 (0.029 - 0.051)					
Pinion shims	mm	0.10, 0.12, 0.15, 0.18, 0.30, 0.40, 0.50					
Forward gear shims	mm	0.10, 0.12, 0.15, 0.18, 0.30, 0.40, 0.50					
Reverse gear shims	mm	0.10, 0.12, 0.15, 0.18, 0.30, 0.40, 0.50					

**ELECTRICAL**

Item	Unit	Model	
		Oil injection (and 225DET)	Pre-mix (except for 225DET)
<b>IGNITION SYSTEM</b>			
Ignition timing		ATDC 7	
Full retard	Degrees		
Full advance	Degrees		
		BTDC 19 (150A, L150A, 175A/C150TR)	
		BTDC 18 (200A, L200A)	
		BTDC 22 (150F, L150F, D150H, 175D, S175D/ D150TR, S175TR)	
		BTDC 23 (S150F, LS150F, 175F, 200G/ S150TR, L150TR, P175TR, P200TR)	
		BTDC 20 (150G, 200F, L200F/P150TR, 200TR)	
		BTDC 21 (S200F, LS200F, 225D/S200TR, L200TR)	
Piston position	mm (in)	2.28 (0.09) (150A, L150A, 175A/C150TR)	
		2.05 (0.08) (200A, L200A)	
		3.05 (0.12) (150F, L150F, D150H, 175D, S175D/D150TR, S175TR)	
		3.33 (0.13) (S150F, LS150F, 175F, 200G/ S150TR, L150TR, P175TR, P200TR)	
		2.53 (0.10) (150G, 200F, L200F/P150TR, 200TR)	
		2.78 (0.11) (S200F, LS200F, 225D/S200TR, L200TR)	
CDI unit			
Output peak voltage lower limit (B/W – B)			
@ cranking 1	V	—	—
@ cranking 2	V	130	65
@ 1,500 r/min	V	145	140
@ 3,500 r/min	V	145	135
Charge coil			
Output peak voltage lower limit (B/R – L)			
@ cranking 1	V	40	30
@ cranking 2	V	55	30
@ 1,500 r/min	V	165	160
@ 3,500 r/min	V	165	170
(R – Br)			
@ cranking 1	V	140	80
@ cranking 2	V	160	90
@ 1,500 r/min	V	165	165
@ 3,500 r/min	V	165	165

\* Cranking 1: Open circuit voltage.  
Cranking 2: Loaded circuit voltage.



Item	Unit	Model	
		Oil injection (and 225DET)	Pre-mix (except for 225DET)
Pulser coil			
Output peak voltage lower limit (W/R – W/G, W/Y – W/Br, W/B – W/L)			
@ cranking 1	V	3.0	2.5
@ cranking 2	V	2.0	2.0
@ 1,500 r/min	V	8.0	9.5
@ 3,500 r/min	V	14	16
<b>IGNITION CONTROL SYSTEM</b>			
Crank position sensor			
Output peak voltage lower limit (G – G)			
@ cranking 1	V	3.0	
@ cranking 2	V	2.0	
@ 1,500 r/min	V	5.5	
@ 3,500 r/min	V	6.0	
Engine cooling water temperature sensor			
Resistance (B/Y – B/Y)			
@ 5°C (41°F)	kΩ	128	
@ 20°C (68°F)	kΩ	54 - 69	
@ 100°C (212°F)	kΩ	3.02 - 3.48	
Thermo switch (P – B)			
OFF → ON	°C (°F)	84 - 90 (183 - 194)	
ON → OFF	°C (°F)	60 - 74 (140 - 165)	
Oil level sensor (engine oil tank)			
Float position ① "OFF"	mm (in)	3 - 6 (0.12 - 0.24)	
Float position ② "ON"	mm (in)	33 - 36 (1.30 - 1.42)	
Float position ③ "ON"	mm (in)	53 - 56 (2.09 - 2.20)	
Oil level gauge (sub-oil tank)			
Float position ④ "ON"	mm (in)	150 - 153 (5.91 - 6.02)	
<b>STARTING SYSTEM</b>			
Fuse 1	V-A	12-30	12-30
Fuse 2	V-A	12-20	—
Fuel enrichment valve			
Resistance (L – B)	Ω	3.4 - 4.0	


\* Cranking 1: Open circuit voltage.  
 Cranking 2: Loaded circuit voltage.




Item	Unit	Model	
		Oil injection (and 225DET)	Pre-mix (except for 225DET)
<b>STARTER MOTOR</b>			
Type		Bendix	
Output	kW	1.1	
Rating	Second	30	
Brushes			
Standard length	mm (in)	16.0 (0.63)	
Wear limit	mm (in)	12.0 (0.47)	
Commutator			
Standard diameter	mm (in)	33.0 (1.30)	
Wear limit	mm (in)	31.0 (1.22)	
Mica			
Standard undercut	mm (in)	0.8 (0.03)	
Wear limit	mm (in)	0.2 (0.01)	
<b>CHARGING SYSTEM</b>			
Lighting coil			
Output peak voltage lower limit (G – G)			
@ cranking 1	V	—	—
@ cranking 2	V	—	—
@ 1,500 r/min	V	35	20
@ 3,500 r/min	V	85	50
<b>POWER TRIM AND TILT SYSTEM</b>			
Trim sensor			
Resistance (P – B)	Ω	582 - 873	
Resistance (O – B)	Ω	800 - 1,200	
<b>POWER TRIM AND TILT MOTOR</b>			
Fluid type		ATF Dexron II	
Brushes			
Standard length	mm (in)	9.8 (0.39)	
Wear limit	mm (in)	4.8 (0.19)	
Commutator			
Standard diameter	mm (in)	22.0 (0.87)	
Wear limit	mm (in)	21.0 (0.83)	
Mica			
Standard undercut	mm (in)	1.35 (0.05)	
Wear limit	mm (in)	0.85 (0.03)	

\* Cranking 1: Open circuit voltage.  
 Cranking 2: Loaded circuit voltage.

**DIMENSIONS**



Symbol		Unit	Models				
Worldwide	USA		150FETO, S150FETO, L150FETO, LS150FETO, 175DETO, S175DETO, 200FETO, S200FETO, L200FETO, LS200FETO, 225DETO, 225DETO	150GETO, 175FETO, 200GETO	D150HETO	150AET, 175AET, 200AET	L150AET, L200AET
			S150TR, L150TR, S175TR, 200TR, S200TR, L200TR	P150TR, P175TR, P200TR	D150TR	C150TR	—
			S200TR	P150TR, P175TR, P200TR	—	—	—
L1		mm (in)	550 (21.7)	557 (21.9)			
L2		mm (in)	179 (7.0)				
L4		mm (in)	647 (25.5)	717 (28.2)	631 (24.8)	634 (25.0)	
L5	(L)	mm (in)	61 (2.4)	44 (1.7)			
	(X)	mm (in)	80 (3.1)	—			
L6	(L)	mm (in)	1,036 (40.8)	1,033 (40.7)	1,032 (40.6)	—	
	(X)	mm (in)	1,152 (45.4)	—	1,148 (45.2)	1,144 (45.0)	
L7		mm (in)	587 (23.1)		568 (22.4)	577 (22.7)	
H1	(L)	mm (in)	946 (37.2)	882 (34.7)	943 (37.1)	—	
	(X)	mm (in)	1,072 (42.2)	—	1,070 (42.1)	1,072 (42.2)	
H2		mm (in)	670 (25.3)	—	635 (25.0)	657 (25.9)	
H3		mm (in)	210 (8.3)				
H4	(L)	mm (in)	516 (20.3)	452 (17.8)	513 (20.2)	—	
	(X)	mm (in)	642 (25.3)	—	640 (25.2)	642 (25.3)	
H6	(L)	mm (in)	773 (30.4)	695 (27.4)			
	(X)	mm (in)	849 (33.4)	—			
H7		mm (in)	241 (9.5)				
H9		mm (in)	791 (31.1)	864 (34.0)	777 (30.6)	775 (30.5)	
W1		mm (in)	290 (11.4)		297 (11.7)	291 (11.5)	
W5		mm (in)	406 (16.0)		422 (16.6)	408 (16.1)	



Symbol		Models				
Worldwide	Unit	150FETO, S150FETO, L150FETO, LS150FETO, 175DETO, S175DETO, 200FETO, S200FETO, L200FETO, LS200FETO, 225DET, 225DETO	150GETO, 175FETO, 200GETO	D150HETO	150AET, 175AET, 200AET	L150AET, L200AET
USA		S150TR, L150TR, S175TR, 200TR, S200TR, L200TR	P150TR, P175TR, P200TR	D150TR	C150TR	—
Canada		S200TR	P150TR, P175TR, P200TR	—	—	—
B1	mm (in)	125.4 (4.9)				
B2	mm (in)	254 (10.0)				
B3	mm (in)	163.5 (6.4)				
B4	mm (in)	50.8 (2.0)				
B5	mm (in)	180 (7.1)				
B6	mm (in)	367 (14.4)				
B9	mm (in)	18.5 (0.7)				
C3	mm (in)	82 (3.2)				
D1	mm (in)	13 (0.5)				
D2	mm (in)	55.5 (2.2)				

**TIGHTENING TORQUES  
SPECIFIED TORQUES**

Part to be tightened		Thread size	Tightening torques		
			Nm	m•kgf	ft•lb
<b>POWER UNIT</b>					
Fuel pump		M5	3	0.3	2.2
Intake silencer		M6	3	0.3	2.2
Carburetor drain plug		—	5	0.5	3.6
Pilot jet plug		—	3	0.3	2.2
Oil pump		M6	7	0.7	5.1
Flywheel magnet assembly (oil injection and 225DET)		M20	190	19	137
Flywheel magnet assembly (pre-mix except for 225DET)		M20	165	16.5	120
Negative battery lead		M8	7	0.7	5.1
Positive battery lead		M6	4	0.4	2.9
Power unit mount		M8	21	2.1	15
Ignition coil		M6	8	0.8	5.8
Emergency switch		—	4	0.4	2.9
Starter motor lead		M6	9	0.9	6.5
Relay assembly lead		M6	4	0.4	2.9
Starter motor		M8	30	3.0	22
Intake manifold	1st	M6	4	0.4	2.9
	2nd		8	0.8	5.8
Reed valve		M5	3	0.3	2.2
Reed valve stopper		M3	1	0.1	0.7
Spark plug		M14	25	2.5	18
Thermostat cover	1st	M6	4	0.4	2.9
	2nd		8	0.8	5.8
Cylinder head cover	1st	M6	4	0.4	2.9
	2nd		8	0.8	5.8
Cylinder head	1st	M8	15	1.5	11
	2nd		30	3.0	22
Engine cooling water temperature sensor		—	18	1.8	13
Cooling water pressure control valve cover	1st	M6	4	0.4	2.9
	2nd		8	0.8	5.8
Exhaust port outer cover	1st	M6	4	0.4	2.9
	2nd		8	0.8	5.8
Crankcase	1st	M8	10	1.0	7.2
	2nd		18	1.8	13
	1st	M10	20	2.0	14
	2nd		40	4.0	29




Part to be tightened		Thread size	Tightening torques		
			Nm	m•kgf	ft•lb
Connecting rod	1st	M8	19	1.9	14
	2nd		37	3.7	27
	3rd		0	0	0
	4th		19	1.9	14
	5th		37	3.7	27
<b>LOWER UNIT</b>					
Propeller		M18	55	5.5	40
Rear propeller (for D150H/D150TR)		M18	55	5.5	40
Forward propeller (for D150H/D150TR)		M45	65	6.5	47
Lower unit		M10	40	4.0	29
Ring nut		—	145	14.5	105
Pinion nut		M22	95	9.5	68
Gear oil drain screw		—	7	0.7	5.1
Gear oil level check screw		—	7	0.7	5.1
<b>BRACKET UNIT</b>					
Flushing hose		M5	5	0.5	3.6
Shift rod detent mechanism screw		—	24	2.4	17
Upper mount		M12	53	5.3	38
Lower mount		M14	73	7.3	53
Exhaust manifold assembly		M8	21	2.1	15
Muffler		M8	18	1.8	13
Exhaust manifold		M8	18	1.8	13
Lower exhaust manifold guide		M8	18	1.8	13
Clamp bracket		M22	15	1.5	11
Trim sensor stopper		M6	2	0.2	1.4
Trim stopper		—	37	3.7	27
<b>POWER TRIM AND TILT UNIT</b>					
Power trim and tilt reservoir cap		—	8	0.8	5.8
Power trim and tilt reservoir		1/4"	5	0.5	3.6
Power trim and tilt motor		1/4"	5	0.5	3.6
Manual valve		—	4	0.4	2.9
Tilt ram end screw		—	130	13	94
Gear pump unit		5/16"	9	0.9	6.5
Gear pump		—	6	0.6	4.3
Trim ram end screw		—	80	8.0	52



Nut (A)	Bolt (B)	General torque specifications		
		Nm	m•kgf	ft•lb
8 mm	M5	5	0.5	3.6
10 mm	M6	8	0.8	5.8
12 mm	M8	18	1.8	13
14 mm	M10	36	3.6	25
17 mm	M12	43	4.3	31

**GENERAL TORQUES**

This chart specifies tightening torques for standard fasteners with a standard ISO thread pitch. Tightening torque specifications for special components or assemblies are provided in applicable sections of this manual. To avoid warpage, tighten multi-fastener assemblies in a crisscross fashion and progressive stages until the specified tightening torque is reached. Unless otherwise specified, tightening torque specifications require clean, dry threads. Components should be at room temperature.





## CHAPTER 3

### PERIODIC INSPECTIONS AND ADJUSTMENTS



<b>MAINTENANCE INTERVAL CHART</b> .....	3-1
<b>TOP COWLING</b> .....	3-2
INSPECTING THE TOP COWLING FIT .....	3-2
<b>FUEL SYSTEM</b> .....	3-2
INSPECTING THE FUEL LINE .....	3-2
INSPECTING THE FUEL FILTER .....	3-3
<b>CONTROL SYSTEM</b> .....	3-3
ADJUSTING THE IGNITION TIMING .....	3-3
SYNCHRONIZING THE CARBURETOR .....	3-6
ADJUSTING THE ENGINE IDLING SPEED .....	3-7
ADJUSTING THE CARBURETOR PICKUP TIMING .....	3-9
ADJUSTING THE REMOTE CONTROL SHIFT CABLE .....	3-11
ADJUSTING THE REMOTE CONTROL THROTTLE CABLE .....	3-11
<b>COOLING SYSTEM</b> .....	3-12
INSPECTING THE COOLING WATER DISCHARGE .....	3-12
<b>OIL INJECTION SYSTEM</b> .....	3-12
SYNCHRONIZING THE OIL PUMP .....	3-12
AIR BLEEDING THE OIL INJECTION SYSTEM .....	3-13
MEASURING THE OIL PUMP DISCHARGE .....	3-14
<b>POWER TRIM AND TILT SYSTEM</b> .....	3-16
INSPECTING THE POWER TRIM AND TILT FLUID LEVEL .....	3-16
<b>LOWER UNIT</b> .....	3-17
INSPECTING THE GEAR OIL LEVEL .....	3-17
CHANGING AND INSPECTING THE GEAR OIL .....	3-17
INSPECTING THE LOWER UNIT (FOR AIR LEAKS) .....	3-19
<b>GENERAL</b> .....	3-19
INSPECTING THE ANODES .....	3-19
INSPECTING THE BATTERY .....	3-20
INSPECTING THE SPARK PLUGS .....	3-21
LUBRICATION POINTS .....	3-23

## MAINTENANCE INTERVAL CHART

Use the following chart as a guide to general maintenance intervals.

Dependant on operating conditions, adjust the maintenance intervals accordingly.

Item	Remarks	Initial		Every		Refer to page	
		10 hours (Break-in)	50 hours (3 months)	100 hours (6 months)	200 hours (1 year)		
<b>TOP COWLING</b>							
Top cowling fit	Inspect				○	3-2	
<b>FUEL SYSTEM</b>							
Fuel line	Inspect	○		○	○	3-2	
Fuel filter	Clean/inspect	○	○	○		3-3	
Carburetor	Clean	○	○	○		4-17	
<b>POWER UNIT</b>							
Water leakage	Inspect	○	○	○		—	
Motor exterior	Inspect	○	○	○		—	
Exhaust leakage	Inspect	○	○	○		—	
Cooling water passage	Clean/flush		○	○		—	
<b>CONTROL SYSTEM</b>							
Carburetor synchroni- zation	Inspect/adjust				○	3-6	
Engine idling speed	Inspect/adjust	○		○		3-7	
Remote control shift cable	Inspect/adjust				○	3-11	
Remote control throttle cable	Inspect/adjust				○	3-11	
<b>OIL INJECTION SYSTEM</b>							
Oil tank water drain	Clean	○	○	○		—	
Oil pump lever	Inspect/adjust	○				3-12	
<b>POWER TRIM AND TILT UNIT</b>							
Power trim and tilt fluid	Inspect	○	○	○	○	3-16	
<b>LOWER UNIT</b>							
Gear oil	Change	○		○		3-17	
Lower unit leakage	Inspect				○	3-19	
Propeller	Inspect	○	○	○		6-3, 6-27, 6-51	
<b>GENERAL</b>							
Anodes	Inspect/replace		○	○		3-19	
Battery	Inspect/charge	(every month)					3-20
Spark plugs	Clean/adjust/replace	○	○	○		3-21	
Wiring and connectors	Adjust/reconnect	○	○	○		—	
Bolts and nuts	Tighten	○	○	○		—	
Lubrication points	Grease			○		3-23	




**TOP COWLING**  
**INSPECTING THE TOP COWLING FIT**

1. Inspect:
  - Top cowling fitting  
Loose/unlatched → Adjust the top cowling hook.
2. Adjust:
  - Top cowling hook position

**Adjustment steps**


- (1) Loosen the bolts ① approximately 1/4 of a turn.
- (2) Move the top cowling hook either up or down slightly.
- (3) Secure the bolts.
- (4) Check the top cowling fitting and repeat the adjustment if necessary.

- NOTE:**
- Moving the latch towards the seal will loosen the top cowling.
  - Moving the latch away from the seal will tighten the top cowling.



**FUEL SYSTEM**  
**INSPECTING THE FUEL LINE**


1. Inspect:
  - Plastic locking tie  
Loosen → Retighten or replace.
2. Inspect:
  - Fuel line  
Cracks/damage/leaks → Replace.  
Refer to "FUEL JOINT AND FUEL FILTER" on page 4-1.  
Refer to "FUEL PUMP" on page 4-6.



**INSPECTING THE FUEL FILTER**

Inspect:

- Fuel filter element
  - Fuel filter cup
- Clogs/cracks/leaks → Replace.  
Foreign matter → Clean.  
Refer to "FUEL JOINT AND FUEL FILTER" on page 4-1.




**CONTROL SYSTEM**  
**ADJUSTING THE IGNITION TIMING**

1. Inspect:

- Ignition timing (full advance)
- Incorrect → Adjust.

**Inspecting steps**


- (1) Remove the flywheel magnet assembly cover.
- (2) Turn the flywheel magnet assembly ① clockwise and align the timing plate ② with the specified mark.



**Flywheel magnet assembly position**

<b>150A, L150A, 175A/ C150TR:</b>	<b>BTDC 19°</b>
<b>200A, L200A:</b>	<b>BTDC 18°</b>
<b>150F, L150F, D150H, 175D, S175D/D150TR, S175TR:</b>	<b>BTDC 22°</b>
<b>S150F, LS150F, 175F, 200G/S150TR, L150TR, P175TR, P200TR:</b>	<b>BTDC 23°</b>
<b>150G, 200F, L200F/ P150TR, 200TR:</b>	<b>BTDC 20°</b>
<b>S200F, LS200F, 225D/ S200TR, L200TR:</b>	<b>BTDC 21°</b>

- (3) Turn the magneto control lever ③ so that it contacts the full advance adjusting screw ④.
- (4) Check that the mark ① on the flywheel magnet assembly aligns with the mark ② on the pulser coil assembly.




2. Adjust:
- Ignition timing (full advance)

**Adjustment steps**

- (1) Remove all of the spark plugs.
- (2) Remove the intake silencer.
- (3) Install the dial gauge ① into cylinder #1's spark plug hole.
- (4) Slowly turn the flywheel magnet assembly clockwise and stop it when the piston is at TDC.
- (5) Set the dial gauge to "0".
- (6) Turn the flywheel magnet assembly clockwise until the dial gauge indicates the proper specification.

**NOTE:**

Turn the flywheel magnet assembly clockwise to locate BTDC.



**Piston position**


<b>150A, L150A, 175A/ C150TR:</b>	<b>2.28 mm (0.09 in)</b>
<b>200A, L200A:</b>	<b>2.05 mm (0.08 in)</b>
<b>150F, L150F, D150H, 175D, S175D/D150TR, S175TR:</b>	<b>3.05 mm (0.12 in)</b>
<b>S150F, LS150F, 175F, 200G/ S150TR, L150TR, P175TR, P200TR:</b>	<b>3.33 mm (0.13 in)</b>
<b>150G, 200F, L200F/P150TR, 200TR:</b>	<b>2.53 mm (0.10 in)</b>
<b>S200F, LS200F, 225D/S200TR, L200TR:</b>	<b>2.78 mm (0.11 in)</b>

- (7) Align the timing plate ② with the specified mark on the flywheel magnet assembly.



**Timing plate position**

<b>150A, L150A, 175A/ C150TR:</b>	<b>BTDC 19°</b>
<b>200A, L200A:</b>	<b>BTDC 18°</b>
<b>150F, L150F, D150H, 175D, S175D/ D150TR, S175TR:</b>	<b>BTDC 22°</b>
<b>S150F, LS150F, 175F, 200G/S150TR, L150TR, P175TR, P200TR:</b>	<b>BTDC 23°</b>
<b>150G, 200F, L200F/ P150TR, 200TR:</b>	<b>BTDC 20°</b>
<b>S200F, LS200F, 225D/ S200TR, L200TR:</b>	<b>BTDC 21°</b>




- (8) Secure the timing plate.
- (9) Adjust the length (a) of the full advance adjusting screw (3) to specification.



**Full advance adjusting screw length (a)**

<b>150A, L150A, 175A/ C150TR:</b>	<b>23.5 mm (0.93 in)</b>
<b>200A, L200A:</b>	<b>25.0 mm (0.98 in)</b>
<b>150F, L150F, S150F, LS150F/S150TR, L150TR:</b>	<b>21.5 mm (0.85 in)</b>
<b>D150H/D150TR:</b>	<b>41.2 mm (1.62 in)</b>
<b>150G, P150TR:</b>	<b>43.5 mm (1.71 in)</b>
<b>200F, L200F/200TR:</b>	<b>24.0 mm (0.94 in)</b>
<b>175F, 200G/P175TR, P200TR:</b>	<b>40.0 mm (1.57 in)</b>
<b>S200F, LS200F, 225D/ S200TR, L200TR:</b>	<b>42.5 mm (1.67 in)</b>

- (10) Disconnect the magneto control link (4) from the pulser coil assembly (5).
- (11) Turn the magneto control lever (6) so that it contacts the full advance adjusting screw (3).
- (12) Adjust the length of the magneto control link (4) so that the mark (b) on the flywheel magnet assembly aligns with the mark (c) on the pulser coil assembly (5).



**3. Inspect:**

- Ignition timing (full retard)  
Out of specification → Adjust.


**Inspecting steps**

- (1) Turn the flywheel magnet assembly clockwise and align the timing plate and the specified mark.



**Flywheel magnet assembly position  
ATDC 7°**

- (2) Turn the magneto control lever (1) so that the full retard adjusting screw (2) contacts the crankcase (3).
- (3) Check that the mark (a) on the flywheel magnet assembly aligns with the mark (b) on the pulser coil assembly.



4. Adjust:
- Ignition timing (full retard)

**Adjustment steps**

- (1) Turn the flywheel magnet assembly clockwise and align the timing plate and the specified mark.

**Flywheel magnet assembly position**  
**ATDC 7°**

- (2) Turn the magneto control lever ① to the full retard position.
- (3) Adjust the full retard adjusting screw ② so that the mark ③ on the flywheel magnet assembly aligns with the mark ④ on the pulser coil assembly.


**SYNCHRONIZING THE CARBURETOR**

**NOTE:** \_\_\_\_\_  
Before synchronizing the carburetor, be sure to adjust the ignition timing.

1. Inspect:
- Carburetor synchronization  
Incorrect → Adjust.

**Inspecting steps**

- (1) Remove the intake silencer.
- (2) While turning the middle throttle lever, check that all throttle valves become fully closed at the same time.



2. Adjust:
- Carburetor synchronization


**Adjustment steps**

- (1) Loosen the idle adjusting screw ① until it does not touch the throttle arm stopper ②.
- (2) Loosen the upper and lower carburetor's throttle lever securing screws ③ by turning them clockwise.
- (3) While lightly pushing the middle carburetor's throttle lever in the direction of the arrow (fully closed), tighten the upper and lower carburetor's throttle lever securing screws ③ by turning them counterclockwise.
- (4) Turn the middle throttle lever and make sure that all of the throttle valves are synchronized.

**ADJUSTING THE ENGINE IDLING SPEED**

**NOTE:** \_\_\_\_\_  
 Before adjusting the engine idling speed, be sure to synchronize the carburetor and ignition timing.

**CAUTION:** \_\_\_\_\_  
**Twin-barrel carburetors have two independent pilot screws. Therefore, all of the pilot screws should be properly adjusted before adjusting the carburetors.**




1. Measure:
- Engine idling speed
- Out of specification → Adjust.

	<p><b>Engine idling speed</b>  <b>700 ± 25 r/min</b></p>
--	--

**Measuring steps**

- (1) Start the engine and allow it to warm up for a few minutes.
- (2) Install the tachometer onto the spark plug lead of cylinder #1.

	<p><b>Tachometer</b> YU-08036-A / 90890-06760</p>
---	---




2. Adjust:

- Engine idling speed

**Adjustment steps**


- (1) Turn in the pilot screw ① until it is lightly seated.
- (2) Turn out the pilot screw ① the specified number of turns.

	<p><b>Pilot screw (turns out)</b></p> <p><b>150A, L150A, 150F/ C150TR:</b> <span style="float: right;"><b>1 ± 1/4</b></span></p> <p><b>S150F, LS150F/ S150TR, L150TR:</b> <span style="float: right;"><b>1-1/4 ± 1/4</b></span></p> <p><b>150G, D150H/ P150TR, D150TR:</b></p> <p style="text-align: right;"><b>(S) 1-9/16 ± 1/4</b></p> <p style="text-align: right;"><b>(P) 1-1/16 ± 1/4</b></p> <p><b>175A, 175D:</b> <span style="float: right;"><b>1-1/16 ± 1/4</b></span></p> <p><b>S175D/S175TR:</b> <span style="float: right;"><b>1-1/8 ± 1/4</b></span></p> <p><b>200A, L200A, 200F, L200F/200TR:</b> <span style="float: right;"><b>1-1/8 ± 1/4</b></span></p> <p><b>175F/P175TR:</b> <span style="float: right;"><b>(S) 1-5/8 ± 1/4</b></span></p> <p style="text-align: right;"><b>(P) 1-1/8 ± 1/4</b></p> <p><b>S200F, LS200F/ S200TR, L200TR:</b> <span style="float: right;"><b>(S) 1-1/8 ± 1/4</b></span></p> <p style="text-align: right;"><b>(P) 5/8 ± 1/4</b></p> <p><b>200G, 225D/P200TR:</b></p> <p style="text-align: right;"><b>(S) 1-1/4 ± 1/4</b></p> <p style="text-align: right;"><b>(P) 3/4 ± 1/4</b></p>
---	--



- (3) Loosen the throttle roller adjusting screw ②.

**NOTE:** \_\_\_\_\_  
Depending on the model, refer to the appropriate illustration (A) or (B).  
\_\_\_\_\_



- (4) Start the engine and allow it to warm up for a few minutes.
- (5) Install the tachometer onto the spark plug lead of cylinder #1.

	<b>Tachometer</b> <b>YU-08036-A / 90890-06760</b>
--	--

- (6) Turn the magneto control lever ③ so that the full retard adjusting screw ④ contacts the crankcase ⑤.
- (7) Turn the throttle stop screw in or out until the specified engine idling speed is obtained.

<b>Turning in</b>	<b>Engine idling speed increases.</b>
<b>Turning out</b>	<b>Engine idling speed decreases.</b>


	<b>Engine idling speed</b> <b>700 ± 25 r/min</b>
--	---

- (8) Tighten the throttle roller adjusting screw ②.

**ADJUSTING THE CARBURETOR PICKUP TIMING**

**NOTE:** \_\_\_\_\_  
 Before adjusting the carburetor pickup timing, be sure to adjust the ignition timing, carburetor synchronization and engine idling speed.

- 1. Inspect:
  - Pickup timing
  - Incorrect → Adjust.




**Inspecting steps**

- (1) Turn the magneto control lever so that the full retard adjusting screw contacts the crankcase.
- (2) Check that the mark (a) on the throttle cam aligns with the center of the throttle roller (1).

**NOTE:** \_\_\_\_\_

Depending on the model, refer to the appropriate illustration (A) or (B).



**2. Adjust:**


- Pickup timing

**Adjustment steps**

- (1) Adjust the throttle cam control link (1) to the specified length (a).



**Throttle cam control link length**  
**150A, L150A, 150F, L150F, S150F, LS150F, 175A, 175D, S175D, 200A, L200A, 200F, L200F/C150TR, S150TR, L150TR, S175TR, 200TR:**  
**42.5 mm (1.67 in)**  
**150G, D150H, 175F, 200G, S200F, LS200F, 225D/P150TR, D150TR, P175TR, P200TR, S200TR, L200TR:**  
**52.5 mm (2.07 in)**



- (2) Turn the magneto control lever (2) so that the full retard adjusting screw (3) contacts the crankcase (4).
- (3) Loosen the throttle roller adjusting screw (5).
- (4) Align the mark (a) on the throttle cam (6) with the center of the throttle roller (7).
- (5) Tighten the throttle roller adjusting screw (5).

**NOTE:** \_\_\_\_\_

Depending on the model, refer to the appropriate illustration (A) or (B).





## ADJUSTING THE REMOTE CONTROL SHIFT CABLE

1. Inspect:
  - Shift operation  
Incorrect → Adjust.
2. Adjust:
  - Remote control shift cable length

### Adjustment steps

- (1) Disconnect the shift cable joint ①.
- (2) Set the remote control lever to the neutral position.
- (3) Align the center of the set pin ③ with the mark ⑥ on the bottom cowling.
- (4) Adjust the position of the shift cable joint until its hole aligns with the set pin ③.
- (5) Install the clip ② and tighten the lock-nut ③.



### CAUTION:

The remote control cable joint must be screwed in more than 8 mm (0.31 in).

## ADJUSTING THE REMOTE CONTROL THROTTLE CABLE


### NOTE:


Before adjusting the remote control throttle cable, be sure to adjust the ignition timing and carburetor synchronization.

1. Inspect:
  - Throttle operation  
Incorrect → Adjust.

### Inspecting steps

- (1) Turn the throttle lever fully.
- (2) Check the magneto control lever ① so that it contacts the full advance adjusting screw ②.





**2. Adjust:**


- Remote control throttle cable length

**Adjustment steps**

- (1) Loosen the locknut.
- (2) Remove the clip.
- (3) Disconnect the cable joint at the magneto control lever ①.
- (4) Close the throttle grip fully.
- (5) Turn the magneto control lever so that the full retard adjusting screw ② contacts the crankcase.
- (6) Adjust the position of the throttle cable joint until its hole aligns with the set pin.
- (7) Install the clip ③ and tighten the locknut ④.

**CAUTION:**

**The remote control cable joint must be screwed in more than 8 mm (0.31 in).**





**COOLING SYSTEM  
INSPECTING THE COOLING WATER  
DISCHARGE**

**Inspect:**

- Cooling water discharge
- No discharge → Clean and inspect the cooling water passage.

**Inspecting steps**

- (1) Place the lower unit in water.
- (2) Start the engine.
- (3) Check that water flows from the cooling water outlet.



**OIL INJECTION SYSTEM  
SYNCHRONIZING THE OIL PUMP**

1. Inspect:
  - Oil pump lever position
 Incorrect → Adjust.

**NOTE:** \_\_\_\_\_  
 Make sure the oil pump lever ① touches the stopper ② (fully closed position) when the throttle valves are closed.

2. Adjust:
  - Oil pump lever position

**Adjustment steps**

- (1) Disconnect the oil pump link rod joint ②.
- (2) Fully close the throttle valves.
- (3) Turn the oil pump lever ① so it contacts the stopper ② (fully closed position).
- (4) Adjust the position of the oil pump link rod joint until its hole aligns with the set pin on the oil pump lever ①.
- (5) Tighten the locknut ③.
- (6) Install the washer and clip.

**CAUTION:** \_\_\_\_\_

**After adjustment, make sure the oil pump lever operates properly.**

**AIR BLEEDING THE OIL INJECTION SYSTEM**

- Bleed:
- Air bubbles  
(from the oil injection system)

**Bleeding steps**

- (1) Fill the fuel tank with the fuel/oil mixture (50:1).



**Recommended fuel**

**Fuel type**  
Unleaded regular gasoline

**Fuel rating**

**PON: 86**

**RON: 91**

**Recommended engine oil**

**Engine oil type**


2-stroke outboard engine oil

**Engine oil grade**

TC-W3

**CAUTION:**

**Only use the fuel/oil mixture (50:1) or engine malfunctions or seizure may result.**



- (2) Disconnect the oil pump link rod joint from the oil pump lever.
- (3) Start the engine.
- (4) Turn the oil pump lever ① and keep it in the fully-opened position until the fuel/oil mixture flows out of the oil pump feed hoses.

**MEASURING THE OIL PUMP DISCHARGE**

Measure:

- Oil pump discharge

Out of specification → Check all of the oil pump components and replace any defective parts.



**Engine oil discharge**

**(3 minutes/1 cylinder)**

**150F, L150F, S150F, LS150F, 150G, 175F, D150H, 175D, S175D/S150TR, L150TR, P150TR, P175TR, D150TR, S175TR**

**3.40 ± 0.70 cm<sup>3</sup>**

**(0.115 ± 0.024 US oz,**


**0.120 ± 0.025 Imp oz)**

**200F, L200F, S200F, LS200F, 200G, 225D/200TR, S200TR, L200TR, P200TR**

**4.80 ± 1.10 cm<sup>3</sup>**

**(0.162 ± 0.037 US oz,**

**0.169 ± 0.039 Imp oz)**



**NOTE:**

When measuring the oil pump discharge, observe the following.

- The engine oil temperature should be 10 - 30 °C (50 - 86 °F).
- Before measuring the oil pump discharge, completely bleed any air from the oil injection system and make sure that no air bubbles are present in the engine oil which is flowing out of the oil feed hose.
- When using the graduated cylinder, make sure no engine oil clings to its walls; otherwise, the measurement will be incorrect.
- Use only the specified engine oil of the proper viscosity. If the viscosity is too high or too low, the discharge measurement will be incorrect.
- Calculate the rate of discharge per minute. The longer the measurement time, the higher the accuracy of the measurement.

**Measuring steps**

- (1) Fill the fuel tank with the fuel/oil mixture (50:1) and fill the oil tank with engine oil.



**Recommended fuel**


**Fuel type**  
Unleaded regular gasoline  
**Fuel rating**  
PON: 86  
RON: 91

**Recommended engine oil**


**Engine oil type**  
2-stroke outboard engine oil  
**Engine oil grade**  
TC-W3

**CAUTION:**

**Only use the fuel/oil mixture (50:1) or engine malfunctions or seizure may result.**



- (2) Disconnect the oil pump link rod joint from the oil pump lever.
- (3) Move the oil pump lever ① to the fully-opened position.



- (4) Remove the oil inlet hose ② from the vapor separator.
- (5) Install the oil inlet hose onto the graduated cylinder.

**NOTE:**


The measuring range on the graduated cylinder should be divided into 0.1-cc increments.

- (6) Start the engine.
- (7) Set the engine idling speed at 1,500 r/min.  
Refer to "ADJUSTING THE ENGINE IDLING SPEED" on page 3-7.
- (8) Measure the engine oil discharge for 3 minutes.

**POWER TRIM AND TILT SYSTEM  
INSPECTING THE POWER TRIM AND  
TILT FLUID LEVEL**

Inspect:


- Power trim and tilt fluid level  
Level is low → Add power trim and tilt fluid to the proper level.



**Recommended power trim and  
tilt fluid  
ATF Dexron II**

**⚠ WARNING**

When removing the power trim and tilt reservoir cap, the power trim and tilt fluid may spurt out due to internal pressure. Therefore, fully tilt up the outboard (the tilt ram assembly fully extended) and then slowly remove the power trim and tilt reservoir cap.




**Inspecting steps**

- (1) Tilt the outboard all the way up and lock it with the tilt stop levers ①.

**⚠ WARNING**

After tilting up the outboard, be sure to support it with the tilt stop levers.

Otherwise, the outboard could suddenly lower if the power trim and tilt unit should lose fluid pressure.



- (2) Remove the reservoir cap ② and inspect the fluid level.

**NOTE:**

The fluid level should be directly below the check hole as shown.

- (3) Add power trim and tilt fluid if needed, and then install the reservoir cap.



**Reservoir cap**  
**8 Nm (0.8 m • kgf, 5.8 ft • lb)**

**LOWER UNIT  
INSPECTING THE GEAR OIL LEVEL**


Inspect:

- Gear oil level  
Level is low → Add gear oil to the proper level.

**CHANGING AND INSPECTING THE  
GEAR OIL**

1. Inspect:

- Gear oil  
Milky oil → Replace the oil seal.  
Slag oil → Check the gears, bearings, and clutch dog.



**Inspecting steps**

- (1) Tilt up the outboard slightly.
- (2) Place a container under the gear oil drain screw ①.
- (3) Remove the gear oil drain screw and gear oil level check screw ②.


**2. Fill:**

- Gear oil  
(with the specified amount of the recommended gear oil)



**Recommended gear oil**  
**GEAR CASE LUBE (USA) or**  
**Hypoid gear oil, SAE 90**  
**Total amount**

**Regular rotation models**  
**980 cm<sup>3</sup>**  
**(33.1 US oz, 34.5 Imp oz)**  
**Counter rotation models**  
**870 cm<sup>3</sup>**  
**(29.4 US oz, 30.6 Imp oz)**  
**Dual propeller models**  
**900 cm<sup>3</sup>**  
**(30.4 US oz, 31.7 Imp oz)**



**Filling steps**

- (1) Place the outboard in an upright position.
- (2) Insert the gear oil tube into the drain hole and slowly fill the gear oil until oil flows out of the check hole and no air bubbles are visible.
- (3) Install the gear oil level check screw and then quickly install the gear oil drain screw.



**Gear oil level check screw**  
**7 Nm (0.7 m • kgf, 5.1 ft • lb)**  
**Gear oil drain screw**  
**7 Nm (0.7 m • kgf, 5.1 ft • lb)**




**INSPECTING THE LOWER UNIT  
(FOR AIR LEAKS)**

Inspect:

- Lower unit holding pressure  
Pressure drops → Inspect the seals and components.



**Lower unit holding pressure**  
**100 kPa (1.0 kg/cm<sup>2</sup>, 14.2 psi)**



**Inspecting steps**

**CAUTION:** \_\_\_\_\_

**Do not overpressurize the lower unit. Excessive pressure may damage the oil seals.**

- (1) Remove the gear oil level check screw.
- (2) Install the pressure tester into the check hole.



**Pressure tester**  
**YB-35956 / 90890-06762**

- (3) Apply the specified pressure.

**NOTE:** \_\_\_\_\_

The lower unit should hold the specified pressure for 10 seconds.


**GENERAL  
INSPECTING THE ANODES**

Inspect:

- Anodes ①
- Trim tab ②  
(except for D150H/D150TR)  
Scales → Clean.  
Grease/oil → Clean.  
Excessive wear → Replace.

**CAUTION:** \_\_\_\_\_

**Do not oil, grease or paint the anode, or it will not operate properly.**



---

**INSPECTING THE BATTERY****⚠ WARNING**

Battery electrolytic fluid is dangerous; it contains sulfuric acid and therefore is poisonous and highly caustic.

Always follow these preventive measures:

- Avoid bodily contact with electrolytic fluid as it can cause severe burns or permanent eye injury.
- Wear protective eye gear when handling or working near batteries.

Antidote (EXTERNAL):

- SKIN - Flush with water.
- EYES - Flush with water for 15 minutes and get immediate medical attention.

Antidote (INTERNAL):

- Drink large quantities of water or milk followed by milk of magnesia, beaten egg, or vegetable oil. Get immediate medical attention.

Batteries also generate explosive hydrogen gas; therefore, you should always follow these preventive measures:

- Charge batteries in a well-ventilated area.
- Keep batteries away from fire, sparks, or open flames (e.g., welding equipment, lighted cigarettes, etc.).
- DO NOT SMOKE when charging or handling batteries.

**KEEP BATTERIES AND ELECTROLYTIC FLUID OUT OF REACH OF CHILDREN.**

---

**NOTE:**

- Batteries vary among manufacturers. Therefore, the following procedures may not always apply. Consult your battery manufacturer's instructions.
  - First, disconnect the negative lead, then the positive lead.
-




**Inspect:**

- Electrolyte level  
Below the minimum level mark → Add distilled water to the proper level.
- Electrolyte specific gravity  
Less than specification → Recharge the battery.



**Electrolyte specific gravity**  
**1.280 at 20°C (68°F)**



**INSPECTING THE SPARK PLUGS**

**1. Inspect:**

- Electrodes ①  
Cracks/excessive wear → Replace.
- Insulator color ②  
Distinctly different color → Check the engine condition.



**Color guide**

**Medium to light tan color**  
**Normal**

**Whitish color**


- Lean fuel mixture
- Plugged jet(-s)
- Air leak
- Wrong setting

**Blackish color**

- Rich mixture
- Excessive oil usage
- Defective ignition system
- Defective spark plug

**2. Clean:**

- Spark plug  
(with a spark plug cleaner or wire brush.)




3. Measure:

- Spark plug gap **a**  
Out of specification → Regap.



**Spark plug gap**  
**0.9 - 1.0 mm (0.035 - 0.039 in)**



4. Tighten:

- Spark plug



**Spark plug**  
**25 Nm (2.5 m • kgf, 18 ft • lb)**






**NOTE:**

- Before installing the spark plug, clean the gasket surface and spark plug surface. Also, it is suggested to apply a thin film of anti-seize compound to the spark plug threads to prevent thread seizure.
- If a torque wrench is not available, a good estimate of the correct tightening torque is to finger tighten **a** the spark plug and then tighten it another 1/4 to 1/2 of a turn **b**.



**LUBRICATION POINTS**

- Apply:
- Water resistant grease




## CHAPTER 4 FUEL SYSTEM

<b>FUEL JOINT AND FUEL FILTER .....</b>	<b>4-1</b>
REMOVING/INSTALLING THE FUEL JOINT AND FUEL FILTER (FOR PRE-MIX MODELS, EXCEPT FOR 225DET).....	4-1
REMOVING/INSTALLING THE FUEL JOINT AND FUEL FILTER (FOR OIL INJECTION MODELS, AND 225DET).....	4-3
INSPECTING THE CHECK VALVE .....	4-5
 <b>FUEL PUMP .....</b>	 <b>4-6</b>
REMOVING/INSTALLING THE FUEL PUMP.....	4-6
DISASSEMBLING/ASSEMBLING THE FUEL PUMP .....	4-7
INSPECTING THE FUEL PUMPS.....	4-9
 <b>OIL TANK .....</b>	 <b>4-10</b>
REMOVING/INSTALLING THE OIL TANK .....	4-10
 <b>CARBURETOR .....</b>	 <b>4-12</b>
REMOVING/INSTALLING THE CARBURETOR.....	4-12
DISASSEMBLING/ASSEMBLING THE CARBURETOR.....	4-14
INSPECTING THE CARBURETOR .....	4-17
ASSEMBLING THE CARBURETOR.....	4-17
 <b>OIL PUMP.....</b>	 <b>4-19</b>
REMOVING/INSTALLING THE OIL PUMP (FOR 150G, 175F, S200F, 200G, 225D/P150TR, P175TR, S200TR P200TR MODELS) .....	4-19
REMOVING/INSTALLING THE OIL PUMP (EXCEPT FOR 150G, 175F, S200F, 200G, 225D/P150TR, P175TR, S200TR, P200TR MODELS) .....	4-21
INSPECTING THE CHECK VALVE .....	4-23




**FUEL JOINT AND FUEL FILTER**  
**REMOVING/INSTALLING THE FUEL JOINT AND FUEL FILTER**  
**(FOR PRE-MIX MODELS, EXCEPT FOR 225DET)**




Order	Job/Part	Q'ty	Remarks
1	Clip	1	
2	Fuel hose	1	(fuel joint-to-fuel filter)
3	Bolt	1	
4	Fuel joint	1	
5	Plastic locking tie	3	<b>Not reusable</b>
6	Fuel hose	1	(fuel filter-to-fuel pump)
7	Bolt	1	
8	Fuel filter	1	
9	Bolt	1	

Continued on next page.



Order	Job/Part	Q'ty	Remarks
10	Fuel filter bracket	1	
11	Fuel filter nut	1	
12	Fuel filter cap	1	
13	Fuel filter element	1	
14	Spring	1	
15	Float	1	
16	O-ring	1	
17	Fuel filter cup	1	
			For installation, reverse the removal procedure.

**REMOVING/INSTALLING THE FUEL JOINT AND FUEL FILTER  
(FOR OIL INJECTION MODELS, AND 225DET)**



Order	Job/Part	Q'ty	Remarks
1	Clip	1	
2	Fuel hose	1	(fuel joint-to-fuel filter)
3	Bolt	1	
4	Fuel joint	1	
5	Plastic locking tie	3	<b>Not reusable</b>
6	Fuel hose	1	(fuel filter-to-fuel pump)
7	Nut	1	

Continued on next page.






**INSPECTING THE CHECK VALVE**

1. Inspect:
  - Fuel joint  
Cracks/damage/leaks → Replace.
2. Inspect
  - Fuel joint operation  
Pressure cannot be maintained for 10 seconds → Replace.

**Inspecting steps**

**NOTE:** \_\_\_\_\_  
Do not overpressurize the fuel joint. Excessive pressure may cause air to leak out.




- (1) Install the Mity vac onto the fuel joint as shown.

	<p><b>Mity vac</b> YB-35956 / 90890-06756</p>
--	---

- (2) Apply the specified pressure with the Mity vac.


	<p><b>Check valve pressure</b> 50 kPa (0.5 kg/cm<sup>2</sup>, 7.1 psi)</p>
--	--

**FUEL PUMP  
REMOVING/INSTALLING THE FUEL PUMP**




Order	Job/Part	Q'ty	Remarks
1	Plastic locking tie	8	<b>Not reusable</b>
2	Fuel hose	2	
3	Fuel hose	2	(fuel pump-to-carburetor)
4	Bolt	2	
5	Fuel pump	2	
6	Gasket	2	<b>Not reusable</b>
			For installation, reverse the removal procedure.

**DISASSEMBLING/ASSEMBLING THE FUEL PUMP**



Order	Job/Part	Q'ty	Remarks
1	Screw	3	
2	Diaphragm body	1	
3	Diaphragm	1	
4	Gasket	1	<b>Not reusable</b>
5	Fuel pump base	1	
6	Gasket	1	<b>Not reusable</b>
7	Diaphragm	1	

Continued on next page.




Order	Job/Part	Q'ty	Remarks
8	Spring seat	1	For assembly, reverse the disassembly procedure.
9	Spring	1	
10	Screw	4	
11	Fuel pump valve	4	
12	Nut	4	
13	Fuel pump body	1	



## INSPECTING THE FUEL PUMPS

1. Inspect:
  - Diaphragm
  - Fuel pump valves
  - Damage → Replace.
2. Inspect:
  - Fuel pump
  - Reverse air flow → Replace.



### Inspecting steps

#### NOTE:

Do not overpressurize the fuel pump. Excessive pressure may cause air to leak out.

- (1) Install the Mity vac onto the fuel pump as shown.



**Mity vac**  
YB-35956 / 90890-06756

- (2) Apply the specified pressure with the Mity vac.




**Fuel pump pressure <sup>Ⓐ</sup>**  
50 kPa (0.5 kg/cm<sup>2</sup>, 7.1 psi)  
**Fuel pump negative pressure <sup>Ⓑ</sup>**  
30 kPa (0.3 kg/cm<sup>2</sup>, 4.3 psi)


#### NOTE:

- Make sure no air comes out of the opposite side of the fuel pump.
- To eliminate any gaps between the fuel pump valves and the fuel pump body, and to ensure a better seal, make sure the inside of the fuel pump is wet (i.e., with gas).

**OIL TANK  
REMOVING/INSTALLING THE OIL TANK**




Order	Job/Part	Q'ty	Remarks
	Flywheel magnet assembly cover		Refer to "FLYWHEEL MAGNET ASSEMBLY" on page 5-1.
	CDI unit cover		Refer to "STATOR ASSEMBLY" on page 5-8.
1	Oil level sensor coupler	1	
2	Oil level sensor	1	
3	Oil strainer	1	
4	Washer	1	
5	Oil tank air vent hose	1	(oil tank-to-intake silencer)
6	Plastic locking tie	1	<b>Not reusable</b>
7	Oil hose	1	(sub oil tank-to-oil tank)
			Continued on next page.




Order	Job/Part	Q'ty	Remarks
8	Bolt	3	
9	Collar	3	
10	Grommet	3	
11	Oil tank	1	
12	Plastic locking tie	1	<b>Not reusable</b>
13	Oil hose	1	(oil tank-to-oil pump)
			For installation, reverse the removal procedure.

**CARBURETOR  
REMOVING/INSTALLING THE CARBURETOR**



Order	Job/Part	Q'ty	Remarks
1	Oil tank air vent hose	1	(intake silencer-to-oil tank)
2	Intake manifold air vent hose	1	(intake silencer-to-intake manifold)
3	Screw	12	
4	Intake silencer	1	
5	Rubber gasket	3	
6	Oil pump link rod	1	Oil injection models
7	Choke link rod	1	
8	O-ring	1	
9	Fuel enrichment valve rod	1	

Continued on next page.




Order	Job/Part	Q'ty	Remarks
10	Fuel enrichment valve link rod	2	
11	Throttle link rod	1	
12	Nut	12	
13	Carburetor #1	1	
14	Plastic locking tie	3	<b>Not reusable</b>
15	Gasket	3	<b>Not reusable</b>
16	Carburetor #2	1	
17	Carburetor #3	1	

For installation, reverse the removal procedure.




DISASSEMBLING/ASSEMBLING THE CARBURETOR




Order	Job/Part	Q'ty	Remarks
1	Screw	4	
2	Float chamber	1	
3	Float pin	2	
4	Float	2	
5	Needle valve	2	
6	Clip	2	
7	Gasket	1	
8	Drank bolt	2	
9	Gasket	2	<b>Not reusable</b>

Continued on next page.







Order	Job/Part	Q'ty	Remarks
10	Main jet	2	
11	Pilot jet plug	2	
12	Pilot jet	2	
13	Screw	1	
14	Carburetor top cover	1	
15	Screw	2	
16	Gasket	2	
17	Screw	2	
18	Spring	2	

Continued on next page.



Order	Job/Part	Q'ty	Remarks
19	Screw	1	
20	Gasket	1	
21	Pilot air jet	2	
22	Screw	2	
23	Carburetor body	1	
24	Throttle stop screw	1	
25	Spring	1	
			For assembly, reverse the disassembly procedure.



## INSPECTING THE CARBURETOR

### CAUTION:

Do not use a steel wire to clean the jets. This may enlarge the jet diameters and seriously affect performance.


1. Inspect:
  - Carburetor body
    - Cracks/damage → Replace.
    - Contamination → Clean.
2. Inspect:
  - Pilot screw
    - Bends/wear → Replace.
3. Inspect:
  - Main jet
  - Pilot jet
  - Pilot air jet
    - Contamination → Clean.
4. Inspect:
  - Needle valve
    - Grooved wear → Replace.
5. Inspect:
  - Float
    - Cracks/damage → Replace.

## ASSEMBLING THE CARBURETOR

1. Install:
  - Needle valve
  - Float
  - Float pin

### NOTE:

- When installing the float into the carburetor, place the needle valve into the needle valve seat.
- After installation, make sure that the float operates smoothly.



**2. Measure:**

- Float height ①  
(without the gasket)


Out of specification → Adjust the float height by bending the tab ①.



**Float height**  
**16.0 ± 0.5 mm (0.63 ± 0.02 in)**

**NOTE:**

- The float should be resting on the needle valve, but not compressing it.
- Take measurements at the end of the float, opposite the side it pivots on.



**3. Adjust:**

- Pilot screw

**Adjustment steps**

- (1) Turn in the pilot screw until it is lightly seated.
- (2) Turn out the pilot screw to specification.




<b>Pilot screw (turns out)</b>	
150A, L150A, 150F/ C150TR:	<b>1 ± 1/4</b>
S150F, LS150F/ S150TR, L150TR:	<b>1-1/4 ± 1/4</b>
150G, D150H/ P150TR, D150TR:	
	(S) <b>1-9/16 ± 1/4</b>
	(P) <b>1-1/16 ± 1/4</b>
175A, 175D:	<b>1-1/16 ± 1/4</b>
S175D/S175TR:	<b>1-1/8 ± 1/4</b>
200A, L200A, 200F, L200F/200TR:	<b>1-1/8 ± 1/4</b>
175F/P175TR:	(S) <b>1-5/8 ± 1/4</b>
	(P) <b>1-1/8 ± 1/4</b>
S200F, LS200F/ S200TR, L200TR:	(S) <b>1-1/8 ± 1/4</b>
	(P) <b>5/8 ± 1/4</b>
200G, 225D/P200TR:	
	(S) <b>1-1/4 ± 1/4</b>
	(P) <b>3/4 ± 1/4</b>




**OIL PUMP**

**REMOVING/INSTALLING THE OIL PUMP (FOR 150G, 175F, S200F, 200G, 225D/ P150TR, P175TR, S200TR P200TR MODELS)**



Order	Job/Part	Q'ty	Remarks
1	Clip	1	
2	Washer	1	
3	Oil pump link rod	1	
4	Oil hose	1	(oil tank-to-oil pump)
5	Bolt	2	
6	Oil pump	1	


Continued on next page.



Order	Job/Part	Q'ty	Remarks
7	Oil pump drive gear	1	
8	Metal plate	1	
9	O-ring	1	<b>Not reusable</b>
10	Clip	24	
11	Oil delivery hose	12	(oil pump-to-intake manifold)
12	Check valve	6	
			For installation, reverse the removal procedure.




**REMOVING/INSTALLING THE OIL PUMP (EXCEPT FOR 150G, 175F, S200F, 200G, 225D/P150TR, P175TR, S200TR, P200TR MODELS)**



Order	Job/Part	Q'ty	Remarks
1	Clip	1	
2	Washer	1	
3	Oil pump link rod	1	
4	Oil hose	1	(oil tank-to-oil pump)
5	Bolt	2	
6	Oil pump	1	

Continued on next page.



Order	Job/Part	Q'ty	Remarks
7	Oil pump drive gear	1	
8	Metal plate	1	
9	O-ring	1	<b>Not reusable</b>
10	Clip	24	
11	Oil delivery hose	12	(oil pump-to-intake manifold)
12	Check valve	6	
			For installation, reverse the removal procedure.

**INSPECTING THE CHECK VALVE**


Inspect:

- Check valve operation  
Damage/reverse air flow → Replace.

**Inspecting steps**

**NOTE:** \_\_\_\_\_

Do not overpressurize the check valve. Excessive pressure may cause air to leak out.



- (1) Install the Mity vac onto the check valve as shown.

	<p><b>Mity vac</b> YB-35956 / 90890-06756</p>
---	---

- (2) Apply the specified pressure with the Mity vac.

	<p><b>Check valve pressure</b> 80 kPa (0.8 kg/cm<sup>2</sup>, 11.4 psi)</p>
--	---

**NOTE:** \_\_\_\_\_

Make sure no air comes out of the opposite side of the check valve.



## **CHAPTER 5 POWER UNIT**

<b>FLYWHEEL MAGNET ASSEMBLY</b> .....	5-1
REMOVING/INSTALLING THE FLYWHEEL MAGNET ASSEMBLY .....	5-1
REMOVING THE FLYWHEEL MAGNET ASSEMBLY .....	5-2
INSTALLING THE FLYWHEEL MAGNET ASSEMBLY .....	5-3
<b>POWER UNIT</b> .....	5-4
DISCONNECTING/CONNECTING THE LEADS .....	5-4
DISCONNECTING/CONNECTING THE HOSES .....	5-5
REMOVING/INSTALLING THE POWER UNIT .....	5-6
<b>STATOR ASSEMBLY</b> .....	5-8
REMOVING/INSTALLING THE STATOR ASSEMBLY .....	5-8
<b>CDI UNIT</b> .....	5-10
REMOVING/INSTALLING THE CDI UNIT ASSEMBLY .....	5-10
REMOVING/INSTALLING THE CDI UNIT .....	5-12
<b>RECTIFIER/REGULATOR</b> .....	5-14
REMOVING/INSTALLING THE RECTIFIER/REGULATOR .....	5-14
<b>RELAY ASSEMBLY AND STARTER MOTOR</b> .....	5-16
REMOVING/INSTALLING THE RELAY ASSEMBLY AND STARTER MOTOR .....	5-16
<b>CONTROL UNIT</b> .....	5-18
REMOVING/INSTALLING THE CONTROL UNIT .....	5-18
INSTALLING THE CONTROL UNIT .....	5-20
<b>INTAKE MANIFOLD</b> .....	5-21
REMOVING/INSTALLING THE INTAKE MANIFOLD (FOR 150G, 175F, S200F, 200G, 225D/P150TR, P175TR, S200TR, P200TR MODELS) .....	5-21
REMOVING/INSTALLING THE INATAKE MANIFOLD (EXCEPT FOR 150G, 175F, S200F, 200G, 225D/P150TR, P175TR, S200TR, P200TR MODELS) .....	5-23

**REED VALVES** ..... 5-25  
 REMOVING/INSTALLING THE REED VALVES ..... 5-25  
 INSPECTING THE REED VALVE ASSEMBLY ..... 5-26


**CYLINDER HEADS** ..... 5-27  
 REMOVING/INSTALLING THE CYLINDER HEADS ..... 5-27  
 INSPECTING THE THERMOSTATS ..... 5-29  
 INSPECTING THE CYLINDER HEADS ..... 5-29

**EXHAUST COVERS** ..... 5-31  
 REMOVING/INSTALLING THE EXHAUST COVERS ..... 5-31  
 INSPECTING THE PRESSURE CONTROL VALVE ..... 5-33

**CRANKCASE** ..... 5-34  
 REMOVING/INSTALLING THE CRANKCASE ..... 5-34  
 ASSEMBLING THE OIL SEAL HOUSING ..... 5-36  
 INSTALLING THE CRANKCASE ..... 5-36

**CYLINDER BODY ASSEMBLY** ..... 5-37  
 DISASSEMBLING/ASSEMBLING THE CYLINDER BODY  
 ASSEMBLY ..... 5-37  
 DISASSEMBLING/ASSEMBLING THE PISTON AND  
 CONNECTING ROD ASSEMBLIES ..... 5-40  
 DISASSEMBLING/ASSEMBLING THE CRANKSHAFT  
 ASSEMBLY ..... 5-41  
 DISASSEMBLING THE UPPER BEARING HOUSING ..... 5-42  
 REMOVING THE BEARING AND OIL PUMP DRIVE GEAR ..... 5-42  
 INSPECTING THE CYLINDER BODY ..... 5-43  
 INSPECTING THE PISTONS ..... 5-44  
 CALCULATING THE PISTON-TO-CYLINDER CLEARANCE ..... 5-44  
 INSPECTING THE PISTON PINS AND SMALL-END BEARINGS ..... 5-45  
 INSPECTING THE PISTON RINGS ..... 5-45  
 INSPECTING THE OIL PUMP DRIVEN GEAR ..... 5-46  
 INSPECTING THE LABYRINTH RINGS ..... 5-47  
 INSPECTING THE CRANKSHAFT ..... 5-47  
 INSTALLING THE OIL PUMP DRIVE GEAR ..... 5-48  
 INSTALLING THE BEARING ..... 5-48  
 INSTALLING THE PISTON RINGS AND PISTON ..... 5-48  
 ASSEMBLING THE UPPER BEARING HOUSING ..... 5-49  
 INSTALLING THE CRANKSHAFT ASSEMBLY ..... 5-50  
 INSTALLING THE PISTON AND CONNECTING ROD  
 ASSEMBLIES ..... 5-50

**FLYWHEEL MAGNET ASSEMBLY  
REMOVING/INSTALLING THE FLYWHEEL MAGNET ASSEMBLY**







Order	Job/Part	Q'ty	Remarks
1	Flywheel magnet assembly cover	1	For installation, reverse the removal procedure.
2	Flywheel magnet assembly nut	1	
3	Washer	1	
4	Flywheel magnet assembly	1	
5	Woodruff key	1	

**[A]** S150F, LS150F, S175D, S200F, LS200F/S150TR, L150TR, S175TR, S200TR, L200TR

**[B]** Oil injection and 225DET models

**[C]** Pre-mix except for 225DET models



**REMOVING THE FLYWHEEL MAGNET ASSEMBLY**

Remove:

- Flywheel magnet assembly

**Removing steps**

(1) Remove the flywheel magnet assembly nut.



**Flywheel magnet assembly holder**  
YB-06139 / 90890-06522

A For USA and Canada

B Except for USA and Canada

**NOTE:**

The major load should be applied in the direction of the arrows. If the load is not applied as shown, the flywheel magnet assembly holder may easily slip off of the flywheel magnet assembly.

(2) Remove the flywheel magnet assembly.



**Universal puller**  
YB-06117 / 90890-06521

A For USA and Canada




B Except for USA and Canada

**NOTE:**

- The major load should be applied in the direction of the arrows.
- Apply the load until the flywheel magnet assembly comes off the tapered portion of the crankshaft.

**CAUTION:**

To prevent damage to the engine or tools, screw in the universal puller set-bolts evenly and completely so that the puller plate is parallel to the flywheel magnet assembly.



**INSTALLING THE FLYWHEEL MAGNET ASSEMBLY**

Install:

- Flywheel magnet assembly nut



**Flywheel magnet assembly holder**  
YB-06139 / 90890-06522


- A** For USA and Canada
- B** Except for USA and Canada

**NOTE:**


The major load should be applied in the direction of the arrows. If the load is not applied as shown, the flywheel magnet assembly holder may easily slip off of the flywheel magnet assembly.



**Flywheel magnet assembly nut (oil injection and 225DET models)**  
190 Nm (19 m • kgf, 137 ft • lb)  
**Flywheel magnet assembly nut (pre-mix except for 225DET models)**  
165 Nm (16.5 m • kgf, 120 ft • lb)




**POWER UNIT  
DISCONNECTING/CONNECTING THE LEADS**




Order	Job/Part	Q'ty	Remarks
	Battery leads		(from the battery)
	Remote control shift and throttle rods and cables		
1	Choke rod	1	
2	Remote control coupler	1	
3	Trim sensor coupler and connector	2	
4	Negative battery lead	1	
5	Positive battery lead	1	
			For installation, reverse the removal procedure.

**DISCONNECTING/CONNECTING THE HOSES**




Order	Job/Part	Q'ty	Remarks
1	Pilot water hose	1	
2	Cooling water hose	1	
3	Bolt	1	
4	Metal clamp	1	
5	Ground lead	1	
6	Trailer switch coupler	1	
7	Bolt	1	
8	Cable guide	1	
9	Power trim and tilt lead	1	(blue)
10	Power trim and tilt lead	1	(green)
			For installation, reverse the removal procedure.

**REMOVING/INSTALLING THE POWER UNIT**



Order	Job/Part	Q'ty	Remarks
1	Bolt	2	
2	Bolt	2	
3	Bolt	2	
4	Forward apron	1	
5	Bolt	2	
6	Bolt	2	
7	Rear apron	1	

Continued on next page.




Order	Job/Part	Q'ty	Remarks
8	Nut	2	
9	Bolt	4	
10	Bolt	6	
11	Power unit	1	
12	Gasket	1	<b>Not reusable</b>
13	Dowel pin	2	

For installation, reverse the removal procedure.




**STATOR ASSEMBLY**

**REMOVING/INSTALLING THE STATOR ASSEMBLY**




Order	Job/Part	Q'ty	Remarks
	Flywheel magnet assembly		Refer to "FLYWHEEL MAGNET ASSEMBLY" on page 5-1.
1	Screw	4	
2	CDI unit cover	1	
3	Crank position sensor connector	2	Oil injection and 225DET models
4	Screw	2	Oil injection and 225DET models
5	Crank position sensor	1	Oil injection and 225DET models
6	Charge coil coupler	1	
7	Lighting coil coupler	1	

Continued on next page.





Order	Job/Part	Q'ty	Remarks
8	Bolt	4	
9	Stator assembly	1	
10	Pulser coil coupler	1	
11	Screw	4	
12	Pulser coil bushing retainer	4	
13	Pulser coil assembly	1	
14	Pulser coil bushing	1	
			For installation, reverse the removal procedure.

**CDI UNIT  
REMOVING/INSTALLING THE CDI UNIT ASSEMBLY**



Order	Job/Part	Q'ty	Remarks
	CDI unit cover		Refer to "DISCONNECTING/CONNECTING THE HOSES" on page 5-5.
1	Crank position sensor connector	2	
2	Charge coil coupler	1	
3	Pulser coil coupler	1	
4	Bolt	2	
5	Ground lead	2	
6	Spark plug cap	6	


Continued on next page.



Order	Job/Part	Q'ty	Remarks
7	Emergency switch connector	2	For installation, reverse the removal procedure.
8	Engine cooling water temperature sensor coupler	1	
9	Oil level sensor coupler	1	
10	CDI unit coupler	1	
11	Bolt	3	
12	CDI unit assembly	1	




**REMOVING/INSTALLING THE CDI UNIT**



Order	Job/Part	Q'ty	Remarks
1	Ignition coil connector	6	
2	Bolt	6	
3	Ground lead	6	
4	Ignition coil	6	
5	Screw	4	
6	Ground lead	1	
7	CDI unit	1	

Continued on next page.




Order	Job/Part	Q'ty	Remarks
8	Emergency switch cap	1	For installation, reverse the removal procedure.
9	Emergency switch	1	
10	Collar	3	
11	Grommet	3	
12	CDI unit case	1	





**RECTIFIER/REGULATOR**

**REMOVING/INSTALLING THE RECTIFIER/REGULATOR**



Order	Job/Part	Q'ty	Remarks
	Negative battery lead		Refer to "POWER UNIT" on page 5-4.
	Positive battery lead		Refer to "POWER UNIT" on page 5-4.
	Lighting coil coupler		Refer to "STATOR ASSEMBLY" on page 5-8.
1	Bolt	1	
2	Ground lead	2	
3	Bolt	2	
4	Rectifier/regulator cover	1	
5	Collar	2	

Continued on next page.




Order	Job/Part	Q'ty	Remarks
6	Accessory lead	1	
7	Rectifier/regulator coupler	1	
8	Rectifier/regulator lead	3	Pre-mix models (except for 225DET)
9	Lighting coil lead	2	Pre-mix models (except for 225DET)
10	Rectifier/regulator	1	
11	Bolt	2	
12	Spacer	2	
13	Battery lead terminal	1	
			For installation, reverse the removal procedure.

A Pre-mix models (except for 225DET)




**RELAY ASSEMBLY AND STARTER MOTOR**

**REMOVING/INSTALLING THE RELAY ASSEMBLY AND STARTER MOTOR**




Order	Job/Part	Q'ty	Remarks
	Power trim and tilt leads		Refer to "POWER UNIT" on page 5-4.
	Oil tank		Refer to "OIL TANK" on page 4-10.
1	Plastic locking tie	1	
2	Plastic tube	1	
3	Starter motor lead	1	
4	Positive battery lead	1	
5	Relay assembly lead	3	
6	Bolt	2	

Continued on next page.




Order	Job/Part	Q'ty	Remarks
7	Relay assembly	1	For installation, reverse the removal procedure.
8	Bolt	1	
9	Negative battery lead	1	
10	Bolt	3	
11	Starter motor	1	

**CONTROL UNIT  
REMOVING/INSTALLING THE CONTROL UNIT**




Order	Job/Part	Q'ty	Remarks
1	Throttle cam control link	2	
2	Bolt	1	
3	Accelerator control lever assembly	1	
4	Nylon washer	1	
5	Washer	1	
6	Spacer	1	
7	Spacer	1	
8	Bushing	1	

Continued on next page.



Order	Job/Part	Q'ty	Remarks
9	Throttle lever	1	For installation, reverse the removal procedure.
10	Spring	1	
11	Bushing	1	
12	Accelerator control lever	1	
13	Bolt	1	
14	Collar	1	
15	Wave washer	1	
16	Throttle cam	1	




### INSTALLING THE CONTROL UNIT

#### 1. Install:

- Bushing ①
- Spring ②

#### NOTE:

Mesh the spring hook with the slit in the accelerator control lever.




#### 2. Install:

- Throttle lever ①


#### NOTE:

- Mesh the throttle lever hook with the spring hook.
- Turn the throttle lever clockwise and hook the projection (a) on the throttle lever with the notch (b) in the accelerator control lever.




#### 3. Adjust:

- Ignition timing  
Refer to "CONTROL SYSTEM" on page 3-3.





**INTAKE MANIFOLD**

**REMOVING/INSTALLING THE INTAKE MANIFOLD (FOR 150G, 175F, S200F, 200G, 225D/P150TR, P175TR, S200TR, P200TR MODELS)**



Order	Job/Part	Q'ty	Remarks
	Carburetor assembly		Refer to "CARBURETOR" on page 4-12.
	Fuel pump		Refer to "FUEL PUMP" on page 4-6.
1	Screw	1	
2	Timing plate	1	
3	Bolt	2	
4	Fuel enrichment valve	1	
5	Intake manifold air vent hose	1	
6	Oil hose	6	


Continued on next page.



Order	Job/Part	Q'ty	Remarks
7	Recirculation hose	6	
8	Bolt	16	
9	Intake manifold	1	
10	Gasket	1	<b>Not reusable</b>
11	Reed valve plate	1	
12	Gasket	1	<b>Not reusable</b>
			For installation, reverse the removal procedure.




**REMOVING/INSTALLING THE INATAKE MANIFOLD (EXCEPT FOR 150G, 175F, S200F, 200G, 225D/P150TR, P175TR, S200TR, P200TR MODELS)**



Order	Job/Part	Q'ty	Remarks
	Carburetor assembly		Refer to "CARBURETOR" on page 4-12. Refer to "FUEL PUMP" on page 4-6.
	Fuel pump		
1	Screw	1	
2	Timing plate	1	
3	Bolt	2	
4	Fuel enrichment valve	1	
5	Intake manifold air vent hose	1	


Continued on next page.



Order	Job/Part	Q'ty	Remarks
6	Oil hose	6	<p><b>Not reusable</b> For installation, reverse the removal procedure.</p>
7	Recirculation hose	12	
8	Bolt	16	
9	Intake manifold	1	
10	Gasket	1	



**REED VALVES**  
**REMOVING/INSTALLING THE REED VALVES**




Order	Job/Part	Q'ty	Remarks
	Intake manifold		Refer to "INTAKE MANIFOLD" on page 5-21.
1	Screw	12	
2	Reed valve assembly	6	
3	Gasket	6	<b>Not reusable</b>
4	Screw	8 (4)	(Pre-mix 150 models)
5	Reed valve stopper	4 (2)	(Pre-mix 150 models)
6	Reed valve	4 (2)	(Pre-mix 150 models)
7	Reed valve seat	1	
			For installation, reverse the removal procedure.

[A] For 150G, 175F, S200F, 200G, 225D/P150TR, P175TR, S200TR, P200TR models

[B] Except for 150G, 175F, S200F, 200G, 225D/P150TR, P175TR, S200TR, P200TR models


**INSPECTING THE REED VALVE ASSEMBLY**

1. Inspect:
  - Reed valve  
Cracks/damage → Replace.




2. Measure:
  - Warpage limit **a**  
Out of specification → Replace.

	<b>Warpage limit</b> <b>0.2 mm (0.008 in)</b>
---	--




3. Measure:
  - Reed valve stopper height **a**  
Out of specification → Replace.

	<b>Reed valve stopper height</b> <b>6.5 ± 0.3 mm (0.26 ± 0.01 in)</b>
---	--




**CYLINDER HEADS**  
**REMOVING/INSTALLING THE CYLINDER HEADS**





Order	Job/Part	Q'ty	Remarks
	Spark plug cap		Refer to "CDI UNIT" on page 5-10.
1	Spark plug	6	
2	Bolt	8	
3	Thermostat cover	2	
4	Gasket	2	<b>Not reusable</b>
5	Thermostat	2	
6	Bolt	36	
7	Clamp	1	(starboard side)
8	Cylinder head cover	2	

Continued on next page.



Order	Job/Part	Q'ty	Remarks
9	Gasket	2	<b>Not reusable</b>
10	Thermo switch	2	
11	Engine cooling water temperature sensor	1	
12	Bolt	2	
13	Ground lead	2	
14	Bolt	28	
15	Cylinder head	2	
16	Gasket	2	<b>Not reusable</b>
For installation, reverse the removal procedure.			




**INSPECTING THE THERMOSTATS**

1. Inspect:
  - Thermostat
  - Damage/valve does not open → Replace.
2. Measure:
  - Thermostat opening temperature
  - Valve lift @
  - Out of specification → Replace.

	Water temperature	Valve lift
	<b>Below 48 - 52 °C</b> (118 - 126 °F)	<b>0 mm</b> (0 in)
	<b>Above 60 °C</b> (140 °F)	<b>Min. 3 mm</b> (0.12 in)

**Measuring steps**

- (1) Suspend the thermostat in a container filled with water.
- (2) Place a thermometer in the water.
- (3) Slowly heat the water.
- (4) While stirring the water, check that the thermostat opens at the specified temperature.





**INSPECTING THE CYLINDER HEADS**

1. Inspect:
  - Combustion chamber
  - Carbon deposits → Clean.
  - Water jacket
  - Mineral deposits/rust → Clean.

**CAUTION:** \_\_\_\_\_


**Do not scratch the contacting surfaces of the cylinder head and cylinder head cover.**

**2. Measure:**

- Cylinder head warpage  
(with a straightedge and thickness gauge)  
Out of specification → Resurface or replace.




**Warpage limit**  
**0.1 mm (0.004 in)**


**Resurfacing steps**

- (1) Place a 400 - 600 grit wet sandpaper on the surface plate.
- (2) Resurface the cylinder head by moving it in a figure-eight motion along the sandpaper.

**NOTE:**


Rotate the cylinder head several times to ensure an even surface.






EXHAUST COVERS

REMOVING/INSTALLING THE EXHAUST COVERS




Order	Job/Part	Q'ty	Remarks
	Pilot water hose		Refer to "POWER UNIT" on page 5-4.
	Cooling water hose		Refer to "POWER UNIT" on page 5-4.
	CDI unit assembly		Refer to "CDI UNIT" on page 5-10.
1	Bolt	2	
2	Pressure control valve cover	1	
3	Gasket	1	<b>Not reusable</b>
4	Spring	1	
5	Pressure control valve	1	
6	Pressure control valve seat	1	

Continued on next page.



Order	Job/Part	Q'ty	Remarks
7	Bolt	1	
8	Lead holder	1	
9	Bolt	29	
10	Lead holder	2	
11	Exhaust outer cover	1	
12	Gasket	1	<b>Not reusable</b>
13	Exhaust inner cover	1	
14	Gasket	1	<b>Not reusable</b>

For installation, reverse the removal procedure.




### INSPECTING THE PRESSURE CONTROL VALVE

Inspect:



- Pressure control valve seat ①
- Pressure control valve ②
- Pressure control valve cover ③  
Cracks/damage → Replace any defective parts.
- Spring ④  
Damage/wear → Replace.

**CRANKCASE  
REMOVING/INSTALLING THE CRANKCASE**



Order	Job/Part	Q'ty	Remarks
	Flywheel magnet assembly		Refer to "FLYWHEEL MAGNET ASSEMBLY" on page 5-1.
	Power unit		Refer to "POWER UNIT" on page 5-4.
	Pulser coil bushing		Refer to "STATOR ASSEMBLY" on page 5-8.
	Intake manifold		Refer to "INTAKE MANIFOLD" on page 5-21.
1	Bolt	12	
2	Bolt	8	
3	Bolt	3	





Continued on next page.



Order	Job/Part	Q'ty	Remarks
4	Bolt	4	For installation, reverse the removal procedure.
5	Crankcase	1	
6	Oil seal housing	1	
7	O-ring	1	
8	Oil seal	2	
9	Dowel pin	2	

**A** For 150G, 175F, S200F, 200G, 225D/P150TR, P175TR, S200TR, P200TR models

**B** Except for 150G, 175F, S200F, 200G, 225D/P150TR, P175TR, S200TR, P200TR models



**ASSEMBLING THE OIL SEAL HOUSING**

- Install:
- Oil seal

	<b>Bearing/oil seal attachment ....</b> ①
	<b>YB-06195 / 90890-06637</b> <b>90890-06631</b>
	<b>Driver rod .....</b> ②
	<b>YB-06071 / 90890-06606</b>

- A** For USA and Canada
- B** Except for USA and Canada

**INSTALLING THE CRANKCASE**


- Apply:
- Gasket Maker®  
(onto the crankcase mating surfaces)

- NOTE:** \_\_\_\_\_
- Clean the mating surfaces of the crankcase and cylinder body before applying Gasket Maker®.
  - Do not allow any sealant to overflow from the mating surfaces.





**CYLINDER BODY ASSEMBLY**

**DISASSEMBLING/ASSEMBLING THE CYLINDER BODY ASSEMBLY**




Order	Job/Part	Q'ty	Remarks
	Cylinder heads		Refer to "CYLINDER HEADS" on page 5-27.
	Crankcase		Refer to "CRANKCASE" on page 5-34.
1	Upper bearing housing	1	
2	Oil seal	1	
3	O-ring	2	
4	Needle bearing	1	
5	Connecting rod bolt	12	
6	Connecting rod cap	6	
7	Big-end bearing	6	

Continued on next page.



Order	Job/Part	Q'ty	Remarks
8	Piston/connecting rod assembly	6	
9	Crankshaft assembly	1	
10	Clip	2	
11	Main journal bearing	2	
12	Screw	8	
13	Anode	8	
14	Bolt	7	
15	Lead holder	1	
16	Cylinder cover	1	


Continued on next page.



Order	Job/Part	Q'ty	Remarks
17	Gasket	1	<b>Not reusable</b>
18	Bolt	2	
19	Engine hanger	1	
20	Bolt	4	
21	Damper bracket	2	
22	Oil pump driven gear	1	Oil injection models
23	Cylinder body	1	For assembly, reverse the disassembly procedure.




DISASSEMBLING/ASSEMBLING THE PISTON AND CONNECTING ROD ASSEMBLIES




Order	Job/Part	Q'ty	Remarks
1	Piston pin clip	12	<b>Not reusable</b>
2	Piston pin	6	
3	Piston	6	
4	Washer	12	
5	Small-end bearing	6	
6	Piston ring	12	
7	Connecting rod	6	
			For assembly, reverse the disassembly procedure.

**DISASSEMBLING/ASSEMBLING THE CRANKSHAFT ASSEMBLY**



Order	Job/Part	Q'ty	Remarks
1	Labyrinth ring	9	
2	Circlip	1	
3	Ball bearing	1	
4	Oil pump drive gear	1	Oil injection models
5	Crankshaft	1	For assembly, reverse the disassembly procedure.



**DISASSEMBLING THE UPPER BEARING HOUSING**

Remove:



- Needle bearing



- Needle bearing attachment..... ①**  
YB-06205 / 90890-06663
- Driver rod ..... ②**  
90890-06606

**A** For USA and Canada

**B** Except for USA and Canada




**REMOVING THE BEARING AND OIL PUMP DRIVE GEAR**

Remove:

- Bearing
- Oil pump drive gear



- Bearing separator ..... ①**  
YB-06219 / 90890-06534
- Guide plate stand ..... ②**  
90890-06538
- Guide plate ..... ③**  
90890-06501
- Bearing puller ..... ④**  
90890-06535



**INSPECTING THE CYLINDER BODY**

1. Inspect:
  - Cylinder sleeves  
Cracks/score marks → Replace.
  - Cylinder body water jacket  
Mineral deposits/rust → Clean.




**CAUTION:**

**Do not scratch the contacting surfaces of the crankcase and cylinder head.**

2. Inspect:
  - Exhaust passages  
Cracks/damage → Replace.
  - Carbon deposits → Clean.

**CAUTION:**

**Do not scratch the contacting surfaces of the cylinder and exhaust inner cover.**





3. Measure:
  - Cylinder bore diameter "D"  
(with a cylinder bore gauge)  
Out of specification → Replace.

**NOTE:**

Measure the cylinder bore diameter at three positions for both D<sub>1</sub> and D<sub>2</sub>. Then, average the measurements.

	Standard	Wear limit
Cylinder bore diameter "D"	90.00 - 90.02 mm (3.543 - 3.544 in)	90.1 mm (3.55 in)
Taper limit T	—	0.08 mm (0.003 in)
Out of round limit R	—	0.05 mm (0.002 in)
$T = (\text{maximum } D_1 \text{ or } D_2) - (\text{minimum } D_5 \text{ or } D_6)$ $R = \text{Maximum } (D_1 - D_2) \text{ or } (D_3 - D_4) \text{ or } (D_5 - D_6)$		

- A: 10 mm (0.4 in) below the top of the cylinder
- B: 5 mm (0.2 in) above the exhaust port
- C: 5 mm (0.2 in) below the scavenging port



**INSPECTING THE PISTONS**

Measure:

- Piston diameter  
(with a micrometer)  
Out of specification → Replace.


	Measuring point "H"	Piston diameter
Standard	10 mm (0.4 in)	89.895 - 89.915 mm (3.5392 - 3.5400 in)

	<b>Oversize piston diameter</b>	
	<b>1st oversize*</b>	
	90.15 mm (3.549 in)	
	<b>2nd oversize</b>	
	90.40 mm (3.559 in)	

\*: Except for USA

**NOTE:**

When measuring the piston diameter, position the micrometer in relation to the piston pin hole as shown.



**CALCULATING THE PISTON-TO-CYLINDER CLEARANCE**

Calculate:

- Piston-to-cylinder clearance (a)  
Out of specification → Replace the piston and piston rings, the cylinder or both.

Piston-to-cylinder clearance	=	Cylinder bore diameter	-	Piston diameter
------------------------------	---	------------------------	---	-----------------


	<b>Piston-to-cylinder clearance</b>	
	0.100 - 0.106 mm (0.0039 - 0.0042 in)	



## INSPECTING THE PISTON PINS AND SMALL-END BEARINGS

### 1. Inspect:

- Piston pin
  - Small-end bearing
- Heat discoloration → Replace.  
Damage/scratches → Replace.




### 2. Measure:

- Piston pin diameter  
(with a micrometer)
- Out of specification → Replace.



**Piston pin diameter**  
**23.065 - 23.070 mm**  
**(0.9081 - 0.9083 in)**



### 3. Measure:

- Piston pin boss diameter  
(with a micrometer)
- Out of specification → Replace.






**Piston pin boss diameter**  
**23.074 - 23.085 mm**  
**(0.9084 - 0.9089 in)**

## INSPECTING THE PISTON RINGS

### NOTE:

- Before inspecting the piston rings, be sure to inspect the cylinder body.
- Piston rings should always be replaced as a set (per piston).



**1. Measure:**

- Piston ring end gap **a**  
(with a thickness gauge)  
Out of specification → Replace.



**Piston ring end gap**  
**0.30 - 0.40 mm**  
**(0.012 - 0.016 in)**  
**Piston ring end gap limit**  
**0.60 mm (0.024 in)**  
**Measuring point "H"**  
**20 mm (0.8 in)**

**NOTE:**

Push the piston ring into the cylinder with the piston crown.

**2. Measure:**


- Piston ring side clearance **b**  
(with a thickness gauge)  
Out of specification → Replace the piston and piston rings as a set.



**Piston ring side clearance**  
**0.02 - 0.06 mm**  
**(0.001 - 0.002 in)**

**NOTE:**


When measuring the piston ring side clearance, the outside of the piston ring should be flush with the piston wall.



**INSPECTING THE OIL PUMP DRIVEN GEAR**

**Inspect:**

- Oil pump driven gear  
Cracks/pitting/wear → Replace.




**INSPECTING THE LABYRINTH RINGS**

1. Inspect:
  - Labyrinth ring ①  
Cracks/damage/wear → Replace.
2. Measure:
  - Labyrinth ring wear ② or ③ + ④  
Out of specification → Replace.



**Labyrinth ring wear limit**  
0.10 mm (0.004 in)




**INSPECTING THE CRANKSHAFT**

1. Measure:
  - Crankshaft runout  
(with V-blocks and a dial gauge)  
Out of specification → Replace.




**Runout limit**  
0.05 mm (0.002 in)



2. Measure:
  - Small-end axial play  
Out of specification → Replace the connecting rod.



**Small-end axial play limit**  
2.0 mm (0.08 in)




3. Measure:
  - Big-end side clearance  
Out of specification → Replace the connecting rod.



**Big-end side clearance**  
0.12 - 0.26 mm (0.005 - 0.010 in)

4. Inspect:
  - Crankshaft bearing  
Pitting/rumbling → Replace.
5. Inspect:
  - Oil pump drive gear  
Cracks/pitting/wear → Replace.




**INSTALLING THE OIL PUMP DRIVE GEAR**

Install:

- Oil pump drive gear

	<b>Bearing separator</b> ..... ①
	<b>YB-06219 / 90890-06534</b>
	<b>Bearing/oil seal attachment</b> .... ②
	<b>90890-06661</b>
	<b>90890-06622</b>




**INSTALLING THE BEARING**

Install:

- Bearing

	<b>Bearing separator</b> ..... ①
	<b>YB-06219 / 90890-06534</b>
	<b>Bearing/oil seal attachment</b> .... ②
	<b>90890-06662</b>
	<b>90890-06622</b>




**INSTALLING THE PISTON RINGS AND PISTON**

1. Install:

- 2nd piston ring
- Top piston ring

**CAUTION:**

- Align each piston ring end gap with its respective locating pin.
- After installing the piston rings, check that they move smoothly.




2. Install:
- Small-end bearing ①
  - Washers ②
  - Piston ③
  - Piston pin ④
  - Piston pin clips ⑤

**CAUTION:**

The washers must be installed with their convex sides facing towards the piston.

**NOTE:**

The embossed YAMAHA mark (a) on the connecting rod must face the same direction as the "UP" mark on the piston.




**ASSEMBLING THE UPPER BEARING HOUSING**


1. Install:
- Needle bearing



**Needle bearing attachment..... ①**  
**YB-06205 / 90890-06663**  
**Driver rod ..... ②**  
**90890-06606**




- Ⓐ For USA and Canada
- Ⓑ Except for USA and Canada



2. Install:
- Oil seal



**Bearing/oil seal attachment .... ①**  
**YB-06195 / 90890-06624**  
**Driver rod ..... ②**  
**YB-06071 / 90890-06606**




### INSTALLING THE CRANKSHAFT ASSEMBLY

Install:

- Cylinder body
- Crankshaft assembly

#### NOTE:

- Align the crankshaft labyrinth ring end gaps with their respective locating pins.
- Install the bearing locating pins into the cylinder body.



### INSTALLING THE PISTON AND CONNECTING ROD ASSEMBLIES

Install:


- Piston and connecting rod assembly



**Piston ring compressor**  
YU-33294 / 90890-06530

#### NOTE:

- Before installing the piston and connecting rod assemblies, lubricate the cylinder walls with 2-stroke outboard engine oil.
- Reinstall the piston and connecting rod assemblies in their original cylinders.
- Install the piston and connecting rod assemblies with the "S" mark in the starboard side cylinders, and those with the "P" mark in the port side cylinders.
- The "UP" mark on the piston crown must face towards the flywheel.





## CHAPTER 6 LOWER UNIT

<b>LOWER UNIT (REGULAR ROTATION MODELS)</b> .....	6-1
REMOVING/INSTALLING THE LOWER UNIT .....	6-1
REMOVING THE PROPELLER .....	6-3
INSPECTING THE PROPELLER .....	6-3
INSTALLING THE PROPELLER.....	6-3
<b>WATER PUMP (REGULAR ROTATION MODELS)</b> .....	6-4
REMOVING/INSTALLING THE WATER PUMP.....	6-4
INSPECTING THE IMPELLER HOUSING .....	6-6
INSPECTING THE IMPELLER AND IMPELLER HOUSING CUP .....	6-6
INSPECTING THE WOODRUFF KEY.....	6-6
INSTALLING THE IMPELLER AND IMPELLER HOUSING.....	6-6
<b>SHIFT ROD ASSEMBLY (REGULAR ROTATION MODELS)</b> .....	6-7
REMOVING/INSTALLING THE SHIFT ROD ASSEMBLY .....	6-7
REMOVING THE SHIFT ROD ASSEMBLY .....	6-8
<b>PROPELLER SHAFT HOUSING ASSEMBLY (REGULAR ROTATION MODELS)</b> .....	6-9
REMOVING/INSTALLING THE PROPELLER SHAFT HOUSING ASSEMBLY.....	6-9
DISASSEMBLING/ASSEMBLING THE PROPELLER SHAFT HOUSING .....	6-11
DISASSEMBLING/ASSEMBLING THE PROPELLER SHAFT ASSEMBLY.....	6-12
REMOVING THE PROPELLER SHAFT HOUSING ASSEMBLY.....	6-13
DISASSEMBLING THE PROPELLER SHAFT HOUSING .....	6-13
INSPECTING THE REVERSE GEAR.....	6-14
INSPECTING THE BEARING.....	6-14
INSPECTING THE PROPELLER SHAFT HOUSING .....	6-14
INSPECTING THE DOG CLUTCH .....	6-15
INSPECTING THE PROPELLER SHAFT.....	6-15
ASSEMBLING THE PROPELLER SHAFT HOUSING .....	6-15
INSTALLING THE PROPELLER SHAFT HOUSING ASSEMBLY.....	6-16



**DRIVE SHAFT (REGULAR ROTATION MODELS)..... 6-17**  
 REMOVING/INSTALLING THE DRIVE SHAFT ..... 6-17  
 REMOVING THE DRIVE SHAFT ..... 6-19  
 DISASSEMBLING THE DRIVE SHAFT HOUSING ASSEMBLY ..... 6-19  
 DISASSEMBLING THE FORWARD GEAR ASSEMBLY ..... 6-19  
 INSPECTING THE PINION ..... 6-20  
 INSPECTING THE DRIVE SHAFT ..... 6-20  
 INSPECTING THE DRIVE SHAFT HOUSING ..... 6-20  
 INSPECTING THE BEARINGS ..... 6-20  
 ASSEMBLING THE FORWARD GEAR ASSEMBLY ..... 6-20  
 ASSEMBLING THE DRIVE SHAFT HOUSING ASSEMBLY ..... 6-21  
 INSTALLING THE DRIVE SHAFT..... 6-22

**LOWER CASE ASSEMBLY (REGULAR ROTATION MODELS)..... 6-23**  
 DISASSEMBLING/ASSEMBLING THE LOWER CASE  
 ASSEMBLY..... 6-23  
 DISASSEMBLING THE LOWER CASE ASSEMBLY ..... 6-24  
 INSPECTING THE DRIVE SHAFT SLEEVE ..... 6-24  
 INSPECTING THE NEEDLE BEARING..... 6-24  
 ASSEMBLING THE LOWER CASE ASSEMBLY ..... 6-24

**LOWER UNIT (COUNTER ROTATION MODELS)..... 6-25**  
 REMOVING/INSTALLING THE LOWER UNIT ..... 6-25  
 REMOVING THE PROPELLER ..... 6-27  
 INSPECTING THE PROPELLER ..... 6-27  
 INSTALLING THE PROPELLER..... 6-27

**WATER PUMP (COUNTER ROTATION MODELS) ..... 6-28**  
 REMOVING/INSTALLING THE WATER PUMP..... 6-28  
 INSPECTING THE IMPELLER HOUSING ..... 6-30  
 INSPECTING THE IMPELLER AND IMPELLER HOUSING CUP ..... 6-30  
 INSPECTING THE WOODRUFF KEY..... 6-30  
 INSTALLING THE IMPELLER AND IMPELLER HOUSING ..... 6-30

**SHIFT ROD ASSEMBLY (COUNTER ROTATION MODELS)..... 6-31**  
 REMOVING/INSTALLING THE SHIFT ROD ASSEMBLY ..... 6-31  
 REMOVING THE SHIFT ROD ASSEMBLY ..... 6-32



<b>PROPELLER SHAFT HOUSING ASSEMBLY (COUNTER ROTATION MODELS)</b> .....	6-33
REMOVING/INSTALLING THE PROPELLER SHAFT HOUSING ASSEMBLY.....	6-33
DISASSEMBLING/ASSEMBLING THE PROPELLER SHAFT HOUSING ASSEMBLY.....	6-34
DISASSEMBLING/ASSEMBLING THE PROPELLER SHAFT ASSEMBLY.....	6-36
REMOVING THE PROPELLER SHAFT HOUSING ASSEMBLY.....	6-37
REMOVING THE PROPELLER SHAFT ASSEMBLY.....	6-37
DISASSEMBLING THE PROPELLER SHAFT HOUSING ASSEMBLY .	6-38
DISASSEMBLING THE FORWARD GEAR ASSEMBLY .....	6-38
INSPECTING THE FORWARD GEAR .....	6-38
INSPECTING THE BEARING.....	6-38
INSPECTING THE PROPELLER SHAFT HOUSING .....	6-38
INSPECTING THE DOG CLUTCH .....	6-39
INSPECTING THE PROPELLER SHAFT.....	6-39
ASSEMBLING THE PROPELLER SHAFT HOUSING .....	6-39
INSTALLING THE PROPELLER SHAFT ASSEMBLY.....	6-40
INSTALLING THE PROPELLER SHAFT HOUSING ASSEMBLY.....	6-40
<b>DRIVE SHAFT (COUNTER ROTATION MODELS)</b> .....	6-41
REMOVING/INSTALLING THE DRIVE SHAFT.....	6-41
REMOVING THE DRIVE SHAFT .....	6-43
REMOVING THE REVERSE GEAR.....	6-43
DISASSEMBLING THE DRIVE SHAFT HOUSING ASSEMBLY .....	6-43
DISASSEMBLING THE REVERSE GEAR ASSEMBLY.....	6-43
INSPECTING THE PINION .....	6-44
INSPECTING THE DRIVE SHAFT .....	6-44
INSPECTING THE DRIVE SHAFT HOUSING .....	6-44
INSPECTING THE BEARINGS .....	6-44
ASSEMBLING THE REVERSE GEAR ASSEMBLY.....	6-45
ASSEMBLING THE DRIVE SHAFT HOUSING ASSEMBLY .....	6-45
INSTALLING THE REVERSE GEAR.....	6-46
INSTALLING THE DRIVE SHAFT.....	6-46
<b>LOWER CASE ASSEMBLY (COUNTER ROTATION MODELS)</b> .....	6-47
DISASSEMBLING/ASSEMBLING THE LOWER CASE ASSEMBLY.....	6-47
DISASSEMBLING THE LOWER CASE ASSEMBLY .....	6-48
INSPECTING THE DRIVE SHAFT SLEEVE .....	6-48
INSPECTING THE NEEDLE BEARING.....	6-48
ASSEMBLING THE LOWER CASE ASSEMBLY .....	6-48



<b>LOWER UNIT (DUAL PROPELLER MODELS)</b> .....	6-49
REMOVING/INSTALLING THE LOWER UNIT .....	6-49
REMOVING THE PROPELLERS .....	6-51
INSPECTING THE PROPELLERS .....	6-51
INSTALLING THE PROPELLERS .....	6-52
<b>WATER PUMP (DUAL PROPELLER MODELS)</b> .....	6-53
REMOVING/INSTALLING THE WATER PUMP .....	6-53
INSPECTING THE IMPELLER HOUSING .....	6-55
INSPECTING THE IMPELLER AND IMPELLER HOUSING CUP .....	6-55
INSPECTING THE WOODRUFF KEY .....	6-55
INSTALLING THE IMPELLER AND IMPELLER HOUSING .....	6-55
<b>SHIFT ROD (DUAL PROPELLER MODELS)</b> .....	6-56
REMOVING/INSTALLING THE SHIFT ROD .....	6-56
REMOVING THE SHIFT ROD .....	6-57
<b>PROPELLER SHAFT HOUSING ASSEMBLY (DUAL PROPELLER MODELS)</b> .....	6-58
REMOVING/INSTALLING THE PROPELLER SHAFT HOUSING ASSEMBLY .....	6-58
DISASSEMBLING/ASSEMBLING THE PROPELLER SHAFT HOUSING ASSEMBLY .....	6-59
REMOVING THE PROPELLER SHAFT HOUSING ASSEMBLY .....	6-61
REMOVING THE OUTER PROPELLER SHAFT .....	6-61
DISASSEMBLING THE PROPELLER SHAFT HOUSING ASSEMBLY .....	6-61
DISASSEMBLING THE OUTER PROPELLER SHAFT ASSEMBLY .....	6-62
REMOVING THE REAR GEAR ASSEMBLY .....	6-62
INSPECTING THE BEARINGS .....	6-62
INSPECTING THE PROPELLER SHAFT HOUSING .....	6-62
INSPECTING THE OUTER PROPELLER SHAFT .....	6-62
INSPECTING THE REAR GEAR .....	6-62
ASSEMBLING THE OUTER PROPELLER SHAFT ASSEMBLY .....	6-63
ASSEMBLING THE PROPELLER SHAFT HOUSING ASSEMBLY .....	6-63
INSTALLING THE PROPELLER SHAFT HOUSING ASSEMBLY .....	6-65
<b>DRIVE SHAFT (DUAL PROPELLER MODELS)</b> .....	6-66
REMOVING/INSTALLING THE DRIVE SHAFT .....	6-66
REMOVING THE DRIVE SHAFT .....	6-68
INSPECTING THE PINION .....	6-68
INSPECTING THE DRIVE SHAFT .....	6-68
INSTALLING THE DRIVE SHAFT .....	6-68
DISASSEMBLING THE DRIVE SHAFT HOUSING ASSEMBLY .....	6-69
INSPECTING THE DRIVE SHAFT HOUSING .....	6-69
ASSEMBLING THE DRIVE SHAFT HOUSING ASSEMBLY .....	6-69



**INNER PROPELLER SHAFT ASSEMBLY (DUAL PROPELLER MODELS).. 6-70**  
 DISASSEMBLING/ASSEMBLING THE INNER PROPELLER SHAFT  
 ASSEMBLY..... 6-70  
 REMOVING THE SPRING ..... 6-72  
 DISASSEMBLING THE FRONT GEAR ASSEMBLY..... 6-72  
 INSPECTING THE DOG CLUTCHES..... 6-72  
 INSPECTING THE INNER PROPELLER SHAFT ..... 6-72  
 INSPECTING THE BEARING..... 6-72  
 INSPECTING THE FRONT GEAR..... 6-72  
 ASSEMBLING THE FRONT GEAR ASSEMBLY..... 6-73  
 INSTALLING THE SPRING ..... 6-73

**LOWER CASE ASSEMBLY (DUAL PROPELLER MODELS) ..... 6-74**  
 DISASSEMBLING/ASSEMBLING THE LOWER CASE  
 ASSEMBLY..... 6-74  
 DISASSEMBLING THE LOWER CASE ASSEMBLY ..... 6-75  
 INSPECTING THE DRIVE SHAFT SLEEVE ..... 6-75  
 INSPECTING THE NEEDLE BEARING..... 6-75  
 ASSEMBLING THE LOWER CASE ASSEMBLY ..... 6-75

**SHIMMING (REGULAR ROTATION MODELS)..... 6-77**

**SHIMMING (REGULAR ROTATION MODELS)  
 (FOR USA AND CANADA) ..... 6-78**  
 SELECTING THE PINION SHIMS ..... 6-78  
 SELECTING THE FORWARD GEAR SHIMS ..... 6-80  
 SELECTING THE REVERSE GEAR SHIMS..... 6-82

**SHIMMING (REGULAR ROTATION MODELS)  
 (EXCEPT FOR USA AND CANADA) ..... 6-84**  
 SELECTING THE PINION SHIMS ..... 6-84  
 SELECTING THE FORWARD GEAR SHIMS ..... 6-86  
 SELECTING THE REVERSE GEAR SHIM ..... 6-87

**BACKLASH (REGULAR ROTATION MODELS)..... 6-89**  
 MEASURING THE FORWARD GEAR BACKLASH ..... 6-89  
 MEASURING THE REVERSE GEAR BACKLASH..... 6-91

**SHIMMING (COUNTER ROTATION MODELS) ..... 6-94**

**SHIMMING (COUNTER ROTATION MODELS)  
 (FOR USA AND CANADA) ..... 6-95**  
 SELECTING THE PINION SHIMS ..... 6-95  
 SELECTING THE REVERSE GEAR SHIMS..... 6-97  
 SELECTING THE FORWARD GEAR SHIMS ..... 6-98  
 SELECTING THE PROPELLER SHAFT SHIMS..... 6-100




---

<b>SHIMMING (COUNTER ROTATION MODELS)</b>	
<b>(EXCEPT FOR USA AND CANADA)</b> .....	6-101
SELECTING THE PINION SHIMS .....	6-101
SELECTING THE REVERSE GEAR SHIMS.....	6-103
SELECTING THE FORWARD GEAR SHIMS .....	6-104
SELECTING THE PROPELLER SHAFT SHIMS.....	6-106
<b>BACKLASH (COUNTER ROTATION MODELS)</b> .....	6-107
MEASURING THE FORWARD GEAR BACKLASH .....	6-107
MEASURING THE REVERSE GEAR BACKLASH.....	6-108
<b>SHIMMING (DUAL PROPELLER MODELS)</b> .....	6-111
SELECTING THE PINION SHIMS .....	6-112
SELECTING THE FRONT GEAR SHIMS.....	6-114
SELECTING THE REAR GEAR SHIMS .....	6-115
SELECTING THE OUTER PROPELLER SHAFT SHIMS .....	6-117
<b>BACKLASH (DUAL PROPELLER MODELS)</b> .....	6-118
MEASURING THE FRONT GEAR BACKLASH.....	6-118
MEASURING THE REAR GEAR BACKLASH .....	6-120




**LOWER UNIT (REGULAR ROTATION MODELS)  
REMOVING/INSTALLING THE LOWER UNIT**





Order	Job/Part	Q'ty	Remarks
1	Speedometer hose	1	
2	Cotter pin	1	
3	Propeller nut	1	
4	Washer	1	
5	Washer	1	
6	Propeller	1	
7	Spacer	1	

Continued on next page.



Order	Job/Part	Q'ty	Remarks
8	Bolt	1	
9	Trim tab	1	
10	Bolt	1	(with washer)
11	Bolt	6	(with washer)
12	Lower unit	1	
13	Dowel pin	2	
			For installation, reverse the removal procedure.



## REMOVING THE PROPELLER

Remove:

- Propeller

### **⚠ WARNING**


Do not hold the propeller with your hands when removing or installing it. Be sure to remove the battery leads from the batteries and the lanyard engine stop switch. Put a block of wood between the cavitation plate and propeller to keep the propeller from turning.

## INSPECTING THE PROPELLER

Inspect:

- Blades
- Splines

Cracks/damage/wear → Replace.



## INSTALLING THE PROPELLER

Install:

- Propeller

### **⚠ WARNING**


Do not hold the propeller with your hands when removing or installing it. Be sure to remove the battery leads from the batteries and the lanyard engine stop switch. Put a block of wood between the cavitation plate and propeller to keep the propeller from turning.

### **NOTE:**

If the groove in the propeller nut is not aligned with the cotter pin hole, tighten the nut further until they are aligned.




**WATER PUMP (REGULAR ROTATION MODELS)  
REMOVING/INSTALLING THE WATER PUMP**



Order	Job/Part	Q'ty	Remarks
	Lower unit		Refer to "LOWER UNIT (REGULAR ROTATION MODELS)" on page 6-1.
1	Bolt	4	
2	Plate washer	4	
3	Impeller housing	1	
4	Impeller housing cup	1	
5	Grommet	1	
6	Spacer	1	
7	Collar	1	

Continued on next page.



Order	Job/Part	Q'ty	Remarks
8	Spacer	1	
9	Washer	2	
10	Wave washer	1	
11	Impeller	1	
12	Woodruff key	1	
13	Impeller plate	1	
14	Gasket	1	<b>Not reusable</b>
15	Dowel pin	2	

For installation, reverse the removal procedure.



**INSPECTING THE IMPELLER HOUSING**

Inspect:

- Impeller housing  
Cracks/damage → Replace.

**INSPECTING THE IMPELLER AND IMPELLER HOUSING CUP**


Inspect:

- Impeller
- Impeller housing cup  
Cracks/damage → Replace any defective parts.

**INSPECTING THE WOODRUFF KEY**

Inspect:

- Woodruff key  
Damage/wear → Replace.



**INSTALLING THE IMPELLER AND IMPELLER HOUSING**

1. Install:

- Washers ①
- Wave washer ②
- Spacer ③
- Collar ④

**NOTE:**


- The collar and spacer should fit together firmly.
- Install the collar with some appropriate tool ③ that fits over the drive shaft as shown.

2. Install:


- O-ring ①
- Impeller housing cup ②
- Impeller housing ③
- O-ring ④

**NOTE:**

- When installing the impeller housing cup, align its projection with the hole in the impeller housing.
- When installing the water pump housing, turn the drive shaft clockwise.



**SHIFT ROD ASSEMBLY (REGULAR ROTATION MODELS)  
REMOVING/INSTALLING THE SHIFT ROD ASSEMBLY**



Order	Job/Part	Q'ty	Remarks
	Impeller plate		Refer to "WATER PUMP (REGULAR ROTATION MODELS)" on page 6-4.
1	Bolt	3	(with washer)
2	Shift rod assembly	1	
3	Shift rod	1	
4	Spring	1	
5	Oil seal housing	1	
6	Oil seal	1	
			For installation, reverse the removal procedure.



## SHIFT ROD ASSEMBLY (REGULAR ROTATION MODELS)

E

---

### REMOVING THE SHIFT ROD ASSEMBLY

Remove:


- Shift rod assembly

**NOTE:** \_\_\_\_\_

Remove the shift rod assembly when the shift rod is in the neutral position.



---

**PROPELLER SHAFT HOUSING ASSEMBLY  
(REGULAR ROTATION MODELS)  
REMOVING/INSTALLING THE PROPELLER SHAFT HOUSING ASSEMBLY**



Order	Job/Part	Q'ty	Remarks
	Gear oil		Refer to "CHANGING AND INSPECTING THE GEAR OIL" on page 3-17.
	Shift rod assembly		Refer to "SHIFT ROD ASSEMBLY (REGULAR ROTATION MODELS)" on page 6-7.
1	Ring nut	1	
2	Claw washer	1	
3	Propeller shaft housing assembly	1	
4	Straight key	1	


Continued on next page.




Order	Job/Part	Q'ty	Remarks
5	Reverse gear shim	*	For installation, reverse the removal procedure.
6	Propeller shaft assembly	1	
7	Washer	1	
8	Propeller shaft housing	1	

\*: As required


**DISASSEMBLING/ASSEMBLING THE PROPELLER SHAFT HOUSING**



Order	Job/Part	Q'ty	Remarks
1	O-ring	1	
2	Reverse gear	1	
3	Thrust washer	1	
4	Ball bearing	1	
5	Oil seal	2	
6	Needle bearing	1	
7	Propeller shaft housing	1	
			For assembly, reverse the disassembly procedure.



DISASSEMBLING/ASSEMBLING THE PROPELLER SHAFT ASSEMBLY




Order	Job/Part	Q'ty	Remarks
1	Spring	1	For assembly, reverse the disassembly procedure.
2	Pin	1	
3	Dog clutch	1	
4	Shift rod joint	1	
5	Shift rod joint slider	1	
6	Ball	4	
7	Spring	1	
8	Ball	2	
9	Propeller shaft	1	

**LOWR**



# PROPELLER SHAFT HOUSING ASSEMBLY (REGULAR ROTATION MODELS)

**E**




## REMOVING THE PROPELLER SHAFT HOUSING ASSEMBLY

1. Straighten:
  - Claw washer tabs
2. Remove:
  - Ring nut
  - Claw washer




**Ring nut wrench** ..... ①  
**YB-34447 / 90890-06512**  
**Ring nut wrench extension** ..... ②  
**90890-06513**




3. Remove:
  - Propeller shaft housing assembly



**Propeller shaft housing puller** . ①  
**YB-06207 / 90890-06502**  
**Universal puller**..... ②  
**YB-06117**  
**Guide plate**..... ③  
**90890-06501**  
**Center bolt** ..... ④  
**90890-06504**



- A** For USA and Canada
- B** Except for USA and Canada




## DISASSEMBLING THE PROPELLER SHAFT HOUSING




1. Remove:
  - Reverse gear



**Slide hammer**..... ①  
**YB-06096**  
**Bearing separator** ..... ②  
**90890-06534**  
**Guide plate**..... ③  
**90890-06501**  
**Guide plate stand** ..... ④  
**90890-06538**  
**Bearing puller**..... ⑤  
**90890-06535**  
**Small universal claws** ..... ⑥  
**90890-06536**



- A** For USA and Canada
- B** Except for USA and Canada



2. Remove:
- Ball bearing

	<b>Slide hammer</b> ..... ① <b>YB-06096</b>
	<b>Guide plate</b> ..... ② <b>90890-06501</b>
	<b>Guide plate stand</b> ..... ③ <b>90890-06538</b>
	<b>Bearing puller</b> ..... ④ <b>90890-06535</b>
	<b>Small universal claws</b> ..... ⑤ <b>90890-06536</b>

- A** For USA and Canada  
**B** Except for USA and Canada

3. Remove:
- Oil seal
  - Needle bearing

	<b>Bearing/oil seal attachment</b> .... ① <b>YB-06196 / 90890-06610</b>
	<b>Driver rod</b> ..... ② <b>YB-06071 / 90890-06652</b>

**INSPECTING THE REVERSE GEAR**

- Inspect:
- Teeth
  - Dogs
- Wear/damage → Replace the reverse gear.

**INSPECTING THE BEARING**

- Inspect:
- Bearing
- Pitting/rumbling → Replace.

**INSPECTING THE PROPELLER SHAFT HOUSING**

- Inspect:
- Propeller shaft housing
- Cracks/damage → Replace.



**INSPECTING THE DOG CLUTCH**

Inspect:

- Dog clutch  
Damage/wear → Replace.

**INSPECTING THE PROPELLER SHAFT**


Inspect:

- Propeller shaft  
Damage/wear → Replace.


**ASSEMBLING THE PROPELLER  
SHAFT HOUSING**

1. Install:

- Needle bearing



	<b>Needle bearing installation position <sup>Ⓐ</sup></b> 24.75 - 25.25 mm (0.974 - 0.994 in)
--	--




	<b>Bearing/oil seal attachment .... <sup>Ⓚ</sup></b> YB-06196 / 90890-06610
	<b>Driver rod ..... <sup>Ⓚ</sup></b> YB-06071 / 90890-06604
	<b>Bearing/oil seal depth plate .... <sup>Ⓚ</sup></b> 90890-06603

- <sup>Ⓐ</sup> For USA and Canada
- <sup>Ⓑ</sup> Except for USA and Canada


2. Install:

- Oil seal



	<b>Oil seal installation position <sup>Ⓐ</sup></b> 4.75 - 5.25 mm (0.187 - 0.207 in)
--	---

	<b>Bearing/oil seal attachment</b> YB-06195 / 90890-06633
--	--



**INSTALLING THE PROPELLER SHAFT HOUSING ASSEMBLY**

Install:

- Propeller shaft housing assembly
- Claw washer
- Ring nut




- Ring nut wrench ..... ①  
YB-34447 / 90890-06512
- Ring nut wrench extension ..... ②  
90890-06513

**NOTE:** \_\_\_\_\_

To secure the ring nut, bend one tab into the slot in the ring nut and the other tabs toward the propeller shaft housing assembly.




**DRIVE SHAFT (REGULAR ROTATION MODELS)  
REMOVING/INSTALLING THE DRIVE SHAFT**




Order	Job/Part	Q'ty	Remarks
	Propeller shaft housing assembly		Refer to "PROPELLER SHAFT HOUSING ASSEMBLY (REGULAR ROTATION MODELS)" on page 6-9.
1	Nut	1	
2	Pinion	1	
3	Bolt	4	(with washer)
4	Drive shaft housing assembly	1	
5	Pinion shim	*	
6	Thrust bearing	1	
7	Drive shaft	1	

Continued on next page.

\*: As required



Order	Job/Part	Q'ty	Remarks
8	Forward gear assembly	1	
9	O-ring	1	
10	Oil seal cover	1	
11	Oil seal	2	
12	Needle bearing	1	
13	Drive shaft housing	1	
14	Tapered roller bearing	1	<b>Not reusable</b>
15	Needle bearing	2	
16	Forward gear	1	
			For installation, reverse the removal procedure.




**REMOVING THE DRIVE SHAFT**

Loosen:

- Pinion nut



- Drive shaft holder** ..... ①  
YB-06201 / 90890-06520
- Pinion nut holder** ..... ②  
90890-06505
- Pinion nut holder attachment** . ③  
90890-06508




**DISASSEMBLING THE DRIVE SHAFT HOUSING ASSEMBLY**

Remove:

- Needle bearing



- Bearing/oil seal attachment** .... ①  
YB-06196 / 90890-06610
- Driver rod** ..... ②  
YB-06071 / 90890-06652



**DISASSEMBLING THE FORWARD GEAR ASSEMBLY**

1. Remove:

- Tapered roller bearing




- Bearing separator**  
YB-06219 / 90890-06534

**CAUTION:**

**Do not reuse the bearing, always replace it with a new one.**

2. Remove:

- Needle bearing



- Slide hammer**..... ①  
YB-06096
- Guide plate**..... ②  
90890-06501
- Guide plate stand** ..... ③  
90890-06538
- Bearing puller**..... ④  
90890-06535
- Small universal claws** ..... ⑤  
90890-06536



**INSPECTING THE PINION**

Inspect:

- Teeth

Damage/wear → Replace.

**INSPECTING THE DRIVE SHAFT**

Inspect:

- Drive shaft

Damage/wear → Replace.

**INSPECTING THE DRIVE SHAFT HOUSING**

Inspect:

- Drive shaft housing


Cracks/damage → Replace.

**INSPECTING THE BEARINGS**

Inspect:

- Bearings

Pitting/rumbling → Replace.



**ASSEMBLING THE FORWARD GEAR ASSEMBLY**

1. Install:

- Needle bearing



**Needle bearing installation position ①**

21.0 - 21.4 mm (0.827 - 0.843 in)

**Needle bearing installation position ②**

4.5 - 4.9 mm (0.177 - 0.193 in)



**Bearing/oil seal attachment .... ①**  
YB-06200 / 90890-06612

**Driver rod ..... ②**  
YB-06071 / 90890-06604


**Bearing/oil seal depth plate .... ③**  
90890-06603

LOWR



# DRIVE SHAFT (REGULAR ROTATION MODELS)

E




2. Install:

- Tapered roller bearing



**Bearing/oil seal attachment**  
**90890-06659**



## ASSEMBLING THE DRIVE SHAFT HOUSING ASSEMBLY

1. Install:


- Needle bearing



**Position ①**  
**5.75 - 6.25 mm (0.226 - 0.246 in)**




**Bearing/oil seal attachment .... ①**  
**YB-06196 / 90890-06610**  
**Driver rod ..... ②**  
**YB-06071 / 90890-06604**  
**Bearing/oil seal depth plate .... ③**  
**90890-06603**



Ⓐ For USA and Canada

Ⓑ Except for USA and Canada



2. Install:

- Oil seal



**Oil seal installation position ①**  
**0.25 - 0.75 mm (0.010 - 0.030 in)**



**Bearing/oil seal attachment .... ①**  
**YB-06195 / 90890-06633**  
**Driver rod ..... ②**  
**YB-06071 / 90890-06652**



## DRIVE SHAFT (REGULAR ROTATION MODELS)

E

### INSTALLING THE DRIVE SHAFT

Tighten:

- Pinion nut





**Pinion nut**  
**95 Nm (9.5 m • kgf, 68 ft • lb)**

**NOTE:** \_\_\_\_\_

Tighten the pinion nut with the same tools that were used for removal.

\_\_\_\_\_






**DISASSEMBLING THE LOWER CASE ASSEMBLY**

1. Remove:
  - Needle bearing

	<b>Bearing/oil seal attachment ....</b> ①
	<b>YB-06194 / 90890-06636</b>
	<b>Driver rod .....</b> ②
	<b>YB-06071 / 90890-06605</b>



2. Remove:
  - Tapered roller bearing outer race


	<b>Slide hammer.....</b> ①
	<b>YB-06096</b>
	<b>Bearing puller.....</b> ②
	<b>90890-06523</b>
	<b>Large universal claws.....</b> ③
	<b>90890-06532</b>

**INSPECTING THE DRIVE SHAFT SLEEVE**

- Inspect:
- Drive shaft sleeve
- Damage/wear → Replace.

**INSPECTING THE NEEDLE BEARING**


- Inspect:
- Needle bearing
- Pitting/rumbling → Replace.



**ASSEMBLING THE LOWER CASE ASSEMBLY**

1. Install:
  - Tapered roller bearing outer race

	<b>Bearing/oil seal attachment ....</b> ①
	<b>YB-06258 / 90890-06619</b>
	<b>Driver rod .....</b> ②
	<b>YB-06071 / 90890-06605</b>




2. Install:
  - Needle bearing

	<b>Bearing/oil seal attachment ....</b> ①
	<b>YB-06246 / 90890-06636</b>
	<b>Bearing puller.....</b> ②
	<b>YB-06029 / 90890-06523</b>
	<b>Needle bearing installation plate .....</b> ③
	<b>YB-06247</b>




**LOWER UNIT (COUNTER ROTATION MODELS)  
REMOVING/INSTALLING THE LOWER UNIT**




Order	Job/Part	Q'ty	Remarks
1	Speedometer hose	1	
2	Cotter pin	1	
3	Propeller nut	1	
4	Washer	1	
5	Washer	1	
6	Propeller	1	
7	Spacer	1	

Continued on next page.



Order	Job/Part	Q'ty	Remarks
8	Bolt	1	
9	Trim tab	1	
10	Bolt	1	(with washer)
11	Bolt	6	(with washer)
12	Lower unit	1	
13	Dowel pin	2	
			For installation, reverse the removal procedure.



## REMOVING THE PROPELLER

Remove:

- Propeller

### **⚠ WARNING**


Do not hold the propeller with your hands when removing or installing it. Be sure to remove the battery leads from the batteries and the lanyard engine stop switch. Put a block of wood between the cavitation plate and propeller to keep the propeller from turning.

## INSPECTING THE PROPELLER

Inspect:

- Blades
- Splines

Cracks/damage/wear → Replace.



## INSTALLING THE PROPELLER

Install:

- Propeller

### **⚠ WARNING**


Do not hold the propeller with your hands when removing or installing it. Be sure to remove the battery leads from the batteries and the lanyard engine stop switch. Put a block of wood between the cavitation plate and propeller to keep the propeller from turning.

### **NOTE:**

If the groove in the propeller nut is not aligned with the cotter pin hole, tighten the nut further until they are aligned.




**WATER PUMP (COUNTER ROTATION MODELS)  
REMOVING/INSTALLING THE WATER PUMP**



Order	Job/Part	Q'ty	Remarks
	Lower unit		Refer to "LOWER UNIT (COUNTER ROTATION MODELS)" on page 6-25.
1	Bolt	4	
2	Plate washer	4	
3	Impeller housing	1	
4	Impeller housing cup	1	
5	Grommet	1	
6	Spacer	1	
7	Collar	1	

Continued on next page.



Order	Job/Part	Q'ty	Remarks
8	Spacer	1	
9	Washer	2	
10	Wave washer	1	
11	Impeller	1	
12	Woodruff key	1	
13	Impeller plate	1	
14	Gasket	1	<b>Not reusable</b>
15	Dowel pin	2	

For installation, reverse the removal procedure.



**INSPECTING THE IMPELLER HOUSING**

Inspect:

- Impeller housing  
Cracks/damage → Replace.

**INSPECTING THE IMPELLER AND IMPELLER HOUSING CUP**


Inspect:

- Impeller
- Impeller housing cup  
Cracks/damage → Replace any defective parts.

**INSPECTING THE WOODRUFF KEY**

Inspect:

- Woodruff key  
Damage/wear → Replace.



**INSTALLING THE IMPELLER AND IMPELLER HOUSING**

1. Install:

- Washers ①
- Wave washer ②
- Spacer ③
- Collar ④

**NOTE:** \_\_\_\_\_


- The collar and spacer should fit together firmly.
- Install the collar with some appropriate tool ③ that fits over the drive shaft as shown.

2. Install:

- O-ring ①
- Impeller housing cup ②
- Impeller housing ③
- O-ring ④


**NOTE:** \_\_\_\_\_

- When installing the impeller housing cup, align its projection with the hole in the impeller housing.
- When installing the water pump housing, turn the drive shaft clockwise.





**SHIFT ROD ASSEMBLY (COUNTER ROTATION MODELS)  
REMOVING/INSTALLING THE SHIFT ROD ASSEMBLY**



Order	Job/Part	Q'ty	Remarks
	Impeller plate		Refer to "WATER PUMP (COUNTER ROTATION MODELS)" on page 6-28.
1	Bolt	3	(with washer)
2	Shift rod assembly	1	
3	Shift rod	1	
4	Spring	1	
5	Oil seal housing	1	
6	Oil seal	1	
			For installation, reverse the removal procedure.



## SHIFT ROD ASSEMBLY (COUNTER ROTATION MODELS)

E

---


### REMOVING THE SHIFT ROD ASSEMBLY

Remove:

- Shift rod assembly


**NOTE:** \_\_\_\_\_  
Remove the shift rod assembly when the  
shift rod is in the neutral position.  
\_\_\_\_\_

**PROPELLER SHAFT HOUSING ASSEMBLY  
(COUNTER ROTATION MODELS)  
REMOVING/INSTALLING THE PROPELLER SHAFT HOUSING ASSEMBLY**




Order	Job/Part	Q'ty	Remarks
	Gear oil		Refer to "CHANGING AND INSPECTING THE GEAR OIL" on page 3-17.
	Shift rod assembly		Refer to "SHIFT ROD ASSEMBLY (COUNTER ROTATION MODELS)" on page 6-31.
1	Ring nut	1	
2	Claw washer	1	
3	Propeller shaft housing assembly	1	
4	Straight key	1	
5	Reverse gear shim	*	
			For installation, reverse the removal procedure.

\*: As required





**DISASSEMBLING/ASSEMBLING THE PROPELLER SHAFT HOUSING ASSEMBLY**



Order	Job/Part	Q'ty	Remarks
1	O-ring	1	
2	Spring	1	
3	Pin	1	
4	Dog clutch	1	
5	Forward gear assembly	1	
6	Propeller shaft assembly	1	
7	Thrust bearing	1	
8	Propeller shaft shim	*	


Continued on next page.

\*: As required



Order	Job/Part	Q'ty	Remarks
9	Oil seal	2	
10	Needle bearing	1	
11	Propeller shaft housing	1	
12	Forward gear	1	
13	Thrust washer	1	
14	Tapered roller bearing outer race	1	
15	Tapered roller bearing	1	<b>Not reusable</b> For assembly, reverse the disassembly procedure.

**DISASSEMBLING/ASSEMBLING THE PROPELLER SHAFT ASSEMBLY**




Order	Job/Part	Q'ty	Remarks
1	Shift rod joint	1	For assembly, reverse the disassembly procedure.
2	Shift rod joint slider	1	
3	Ball	4	
4	Spring	1	
5	Ball	2	
6	Propeller shaft	1	

**LOWR**



# PROPELLER SHAFT HOUSING ASSEMBLY (COUNTER ROTATION MODELS)

E




## REMOVING THE PROPELLER SHAFT HOUSING ASSEMBLY

1. Straighten:
  - Claw washer tabs.
2. Remove:
  - Ring nut
  - Claw washer




**Ring nut wrench** ..... ①  
**YB-34447 / 90890-06512**  
**Ring nut wrench extension** ..... ②  
**90890-06513**



3. Remove:
  - Propeller shaft housing assembly



**Slide hammer attachment**..... ①  
**YB-06335 / 90890-06514**  
**Slide hammer**..... ②  
**YB-06096 / 90890-06531**




## REMOVING THE PROPELLER SHAFT ASSEMBLY

- Remove:
- Propeller shaft assembly
  - Forward gear assembly



**Propeller shaft housing puller** . ①  
**YB-06207 / 90890-06502**  
**Universal puller**  
**YB-06117**  
**Guide plate**..... ②  
**90890-06501**  
**Center bolt** ..... ③  
**90890-06504**




**DISASSEMBLING THE PROPELLER  
SHAFT HOUSING ASSEMBLY**

Remove:

- Oil seal
- Needle bearing



**Bearing/oil seal attachment .... ①**  
**YB-06196 / 90890-06653**  
**Driver rod ..... ②**  
**YB-06071 / 90890-06652**



**DISASSEMBLING THE FORWARD  
GEAR ASSEMBLY**

Remove:

- Tapered roller bearing



**Bearing separator**  
**YB-06219 / 90890-06534**

**CAUTION:**

**Do not reuse the bearing, always replace it  
with a new one.**

**INSPECTING THE FORWARD GEAR**

Inspect:

- Teeth
  - Dogs
- Damage/wear → Replace.

**INSPECTING THE BEARING**


Inspect:

- Bearing
- Pitting/rumbling → Replace.

**INSPECTING THE PROPELLER SHAFT  
HOUSING**

Inspect:

- Propeller shaft housing
- Cracks/damage → Replace.



**INSPECTING THE DOG CLUTCH**

Inspect:

- Dog clutch  
Damage/wear → Replace.

**INSPECTING THE PROPELLER SHAFT**




Inspect:

- Propeller shaft  
Damage/wear → Replace.

**ASSEMBLING THE PROPELLER  
SHAFT HOUSING**

1. Install:

- Needle bearing



	<b>Needle bearing installation position ①</b> 24.75 - 25.25 mm (0.974 - 0.994 in)
--	---

	<b>Bearing/oil seal attachment .... ①</b> YB-06196 / 90890-06610
	<b>Driver rod ..... ②</b> YB-06071 / 90890-06604
	<b>Bearing/oil seal depth plate .... ③</b> 90890-06603



- A** For USA and Canada
- B** Except for USA and Canada

2. Install:

- Oil seal

	<b>Oil seal installation position ①</b> 4.75 - 5.25 mm (0.187 - 0.207 in)
--	--


	<b>Bearing/oil seal attachment</b> YB-06195 / 90890-06633
--	--



**INSTALLING THE PROPELLER SHAFT ASSEMBLY**

Install:

- Forward gear assembly
- Propeller shaft assembly



**INSTALLING THE PROPELLER SHAFT HOUSING ASSEMBLY**

Install:

- Propeller shaft housing assembly
- Claw washer
- Ring nut

	<b>Ring nut wrench</b> ..... ① <b>YB-34447 / 90890-06512</b>
	<b>Ring nut wrench extension</b> ..... ② <b>90890-06513</b>


**NOTE:**

To secure the ring nut, bend one tab into the slot in the ring nut and the other tabs toward the propeller shaft housing assembly.



DRIVE SHAFT (COUNTER ROTATION MODELS)



REMOVING/INSTALLING THE DRIVE SHAFT




Order	Job/Part	Q'ty	Remarks
	Propeller shaft housing assembly		Refer to "PROPELLER SHAFT HOUSING ASSEMBLY (COUNTER ROTATION MODELS)" on page 6-33.
1	Nut	1	
2	Pinion	1	
3	Bolt	4	(with washer)
4	Drive shaft housing assembly	1	
5	Pinion shim	*	
6	Thrust bearing	1	
7	Drive shaft	1	

Continued on next page.

\*: As required



Order	Job/Part	Q'ty	Remarks
8	Reverse gear assembly	1	For installation, reverse the removal procedure.
9	Thrust bearing	1	
10	O-ring	1	
11	Oil seal cover	1	
12	Oil seal	2	
13	Needle bearing	1	
14	Drive shaft housing	1	
15	Roller bearing inner race	1	
16	Needle bearing	2	
17	Reverse gear	1	




**REMOVING THE DRIVE SHAFT**

Loosen:

- Pinion nut



- Drive shaft holder** ..... ①  
YB-06201 / 90890-06520
- Pinion nut holder** ..... ②  
90890-06505
- Pinion nut holder attachment** . ③  
90890-06508




**REMOVING THE REVERSE GEAR**

Remove:

- Reverse gear assembly
- Thrust bearing



- Slide hammer**..... ①  
YB-06096
- Bearing puller**..... ②  
90890-06535
- Small universal claws** ..... ③  
90890-06536




**DISASSEMBLING THE DRIVE SHAFT HOUSING ASSEMBLY**

Remove:

- Needle bearing



- Bearing/oil seal attachment** .... ①  
YB-06196 / 90890-06610
- Driver rod** ..... ②  
YB-06071 / 90890-06652




**DISASSEMBLING THE REVERSE GEAR ASSEMBLY**

1. Remove:

- Roller bearing inner race



- Bearing separator**  
YB-06219 / 90890-06534



**2. Remove:**

- Needle bearing

	<b>Slide hammer.....</b>	<b>①</b>
	<b>YB-06096</b>	
	<b>Guide plate.....</b>	<b>②</b>
	<b>90890-06501</b>	
	<b>Guide plate stand .....</b>	<b>③</b>
	<b>90890-06538</b>	
	<b>Bearing puller.....</b>	<b>④</b>
	<b>90890-06535</b>	
	<b>Small universal claws .....</b>	<b>⑤</b>
	<b>90890-06536</b>	

**INSPECTING THE PINION**

Inspect:

- Teeth  
Damage/wear → Replace.

**INSPECTING THE DRIVE SHAFT**

Inspect:

- Drive shaft  
Damage/wear → Replace.

**INSPECTING THE DRIVE SHAFT HOUSING**


Inspect:

- Drive shaft housing  
Cracks/damage → Replace.

**INSPECTING THE BEARINGS**

Inspect:

- Bearings  
Pitting/rumbling → Replace.



**ASSEMBLING THE REVERSE GEAR ASSEMBLY**


1. Install:
- Needle bearing



**Needle bearing installation position ①**  
 21.0 - 21.4 mm (0.827 - 0.843 in)  
**Needle bearing installation position ②**  
 4.5 - 4.9 mm (0.177 - 0.193 in)




**Bearing/oil seal attachment .... ①**  
 YB-06200 / 90890-06612  
**Driver rod ..... ②**  
 YB-06071 / 90890-06604  
**Bearing/oil seal depth plate .... ③**  
 90890-06603



2. Install:
- Roller bearing inner race



**Bearing/oil seal attachment**  
 90890-06660



**ASSEMBLING THE DRIVE SHAFT HOUSING ASSEMBLY**


1. Install:
- Needle bearing



**Position ①**  
 5.75 - 6.25 mm (0.226 - 0.246 in)



**Bearing/oil seal attachment .... ①**  
 YB-06196 / 90890-06610  
**Driver rod ..... ②**  
 YB-06071 / 90890-06604  
**Bearing/oil seal depth plate .... ③**  
 90890-06603




- A** For USA and Canada  
**B** Except for USA and Canada

LOWR



# DRIVE SHAFT (COUNTER ROTATION MODELS)

E




2. Install:
- Oil seal



**Oil seal installation position (a)**  
0.25 - 0.75 mm (0.010 - 0.030 in)



**Bearing/oil seal attachment .... (1)**  
YB-06195 / 90890-06633  
**Driver rod ..... (2)**  
YB-06071 / 90890-06652



## INSTALLING THE REVERSE GEAR

- Install:
- Thrust bearing
  - Reverse gear assembly

**NOTE:** \_\_\_\_\_  
Install the thrust bearing onto the reverse gear assembly and position the thrust bearing so its rounded side faces away from the reverse gear.

## INSTALLING THE DRIVE SHAFT


- Tighten:
- Pinion nut



**Pinion nut**  
95 Nm (9.5 m • kgf, 68 ft • lb)



**NOTE:** \_\_\_\_\_  
Tighten the pinion nut with the same tools that were used for removal.

**LOWER CASE ASSEMBLY (COUNTER ROTATION MODELS)  
DISASSEMBLING/ASSEMBLING THE LOWER CASE ASSEMBLY**



Order	Job/Part	Q'ty	Remarks
	Reverse gear		Refer to "DRIVE SHAFT (COUNTER ROTATION MODELS)" on page 6-41.
1	Drive shaft sleeve	1	
2	Needle bearing	18	
3	Needle bearing outer case	1	
4	Roller bearing	1	
5	Reverse gear shim	*	
6	Water seal	1	
7	Plate	1	
			For assembly, reverse the disassembly procedure.


\*: As required



**DISASSEMBLING THE LOWER CASE ASSEMBLY**

1. Remove:
- Needle bearing outer race

	<b>Bearing/oil seal attachment ....</b> ① YB-06194 / 90890-06636
	<b>Driver rod .....</b> ② YB-06071 / 90890-06605



2. Remove:
- Roller bearing


	<b>Slide hammer.....</b> ① YB-06096
	<b>Bearing puller.....</b> ② 90890-06523
	<b>Large universal claws.....</b> ③ 90890-06532

**INSPECTING THE DRIVE SHAFT SLEEVE**

- Inspect:
- Drive shaft sleeve
- Damage/wear → Replace.

**INSPECTING THE NEEDLE BEARING**


- Inspect:
- Needle bearing
- Pitting/rumbling → Replace.



**ASSEMBLING THE LOWER CASE ASSEMBLY**

1. Install:
- Roller bearing

	<b>Bearing/oil seal attachment ....</b> ① YB-06336 / 90890-06629
	<b>Driver rod .....</b> ② YB-06071 / 90890-06605




2. Install:
- Needle bearing outer race

	<b>Bearing/oil seal attachment ....</b> ① YB-06246 / 90890-06636
	<b>Bearing puller.....</b> ② YB-06029 / 90890-06523
	<b>Needle bearing installation plate .....</b> ③
	YB-06247




**LOWER UNIT (DUAL PROPELLER MODELS)  
REMOVING/INSTALLING THE LOWER UNIT**




Order	Job/Part	Q'ty	Remarks
1	Speedometer hose	1	
2	Cotter pin	1	
3	Propeller nut	1	
4	Washer	1	
5	Washer	1	
6	Rear propeller	1	
7	Rear spacer	1	
8	Propeller nut	1	

Continued on next page.



Order	Job/Part	Q'ty	Remarks
9	Toothed washer	1	
10	Forward propeller	1	
11	Forward spacer	1	
12	Bolt	7	(with washer)
13	Lower unit	1	
14	Dowel pin	2	
For installation, reverse the removal procedure.			




## REMOVING THE PROPELLERS

1. Remove:
  - Rear propeller

### **⚠ WARNING**

Do not hold the propeller with your hands when removing or installing it. Be sure to remove the battery leads from the batteries and the lanyard engine stop switch. Put a block of wood between the cavitation plate and propeller to keep the propeller from turning.

2. Straighten:
  - Toothed washer teeth




3. Remove:
  - Forward propeller

### **⚠ WARNING**

Do not hold the propeller with your hands when removing or installing it. Be sure to remove the battery leads from the batteries and the lanyard engine stop switch. Put a block of wood between the cavitation plate and propeller to keep the propeller from turning.

## INSPECTING THE PROPELLERS

- Inspect:
- Blades
  - Splines
- Cracks/damage/wear → Replace.




## INSTALLING THE PROPELLERS

1. Install:
  - Forward propeller

### **⚠ WARNING**

Do not hold the propeller with your hands when removing or installing it. Be sure to remove the battery leads from the batteries and the lanyard engine stop switch. Put a block of wood between the cavitation plate and propeller to keep the propeller from turning.



2. Bend:
  - Toothed washer teeth
3. Install:
  - Rear propeller

### **⚠ WARNING**


Do not hold the propeller with your hands when removing or installing it. Be sure to remove the battery leads from the batteries and the lanyard engine stop switch. Put a block of wood between the cavitation plate and propeller to keep the propeller from turning.

### **NOTE:**

If the groove in the propeller nut is not aligned with the cotter pin hole, tighten the nut further until they are aligned.




**WATER PUMP (DUAL PROPELLER MODELS)  
REMOVING/INSTALLING THE WATER PUMP**




Order	Job/Part	Q'ty	Remarks
	Lower unit		Refer to "LOWER UNIT (DUAL PROPELLER MODELS)" on page 6-49.
1	Bolt	4	
2	Plate washer	4	
3	Impeller housing	1	
4	Impeller housing cup	1	
5	Grommet	1	
6	Spacer	1	
7	Drive shaft collar	1	

Continued on next page.



Order	Job/Part	Q'ty	Remarks
8	Spacer	1	For installation, reverse the removal procedure.
9	Washer	2	
10	Wave washer	1	
11	Impeller	1	
12	Woodruff key	1	



**INSPECTING THE IMPELLER HOUSING**

Inspect:

- Impeller housing
- Cracks/damage → Replace.

**INSPECTING THE IMPELLER AND IMPELLER HOUSING CUP**


Inspect:

- Impeller
- Impeller housing cup
- Cracks/damage → Replace any defective parts.

**INSPECTING THE WOODRUFF KEY**

Inspect:

- Woodruff key
- Damage/wear → Replace.



**INSTALLING THE IMPELLER AND IMPELLER HOUSING**

1. Install:

- Washers ①
- Wave washer ②
- Spacer ③
- Collar ④

**NOTE:**


- The collar and spacer should fit together firmly.
- Install the collar with some appropriate tool ③ that fits over the drive shaft as shown.

2. Install:

- O-ring ①
- Impeller housing cup ②
- Impeller housing ③
- O-ring ④


**NOTE:**

- When installing the impeller housing cup, align its projection with the hole in the impeller housing.
- When installing the water pump housing, turn the drive shaft clockwise.






**SHIFT ROD (DUAL PROPELLER MODELS)**  
**REMOVING/INSTALLING THE SHIFT ROD**



Order	Job/Part	Q'ty	Remarks
	Woodruff key		Refer to "WATER PUMP (DUAL PROPELLER MODELS)" on page 6-53.
1	Bolt	3	(with washer)
2	Plate washer	3	
3	Oil seal housing cover	1	
4	Impeller plate	1	
5	Gasket	1	<b>Not reusable</b>
6	Oil seal housing	1	<b>Not reusable</b>
7	O-ring	1	
8	Shift rod	1	
			For installation, reverse the removal procedure.



## REMOVING THE SHIFT ROD

1. Remove:
  - Oil seal housing

### Removing steps


- (1) Insert a flat-head screwdriver under each projection (a).
- (2) Alternating between each side of the oil seal housing (1), slowly lift the oil seal housing until it is fully removed from the lower unit.

2. Remove:
  - Shift rod

**NOTE:** \_\_\_\_\_  
Remove the shift rod when it is in the neutral position.  
\_\_\_\_\_

**PROPELLER SHAFT HOUSING ASSEMBLY  
(DUAL PROPELLER MODELS)**


**REMOVING/INSTALLING THE PROPELLER SHAFT HOUSING ASSEMBLY**



Order	Job/Part	Q'ty	Remarks
	Gear oil		Refer to "CHANGING AND INSPECTING THE GEAR OIL" on page 3-17.
1	Ring nut	1	
2	Claw washer	1	
3	Propeller shaft housing assembly	1	
4	Washer	1	
5	Rear gear shim	*	
			For installation, reverse the removal procedure.


\*: As required

**DISASSEMBLING/ASSEMBLING THE PROPELLER SHAFT HOUSING ASSEMBLY**



Order	Job/Part	Q'ty	Remarks
1	O-ring	3	
2	Rear gear assembly	1	
3	Outer propeller shaft	1	
4	Thrust bearing	1	
5	Outer propeller shaft shim	*	
6	Oil seal	2	
7	Needle bearing	2	
			Continued on next page.

\*: As required




Order	Job/Part	Q'ty	Remarks
8	Oil seal	2	
9	Needle bearing	1	
10	Propeller shaft housing	1	
11	Rear gear	1	
12	Thrust washer	1	
13	Tapered roller bearing outer race	1	
14	Tapered roller bearing	1	
			For assembly, reverse the disassembly procedure.

**LOWR**



# PROPELLER SHAFT HOUSING ASSEMBLY (DUAL PROPELLER MODELS)

E




## REMOVING THE PROPELLER SHAFT HOUSING ASSEMBLY

1. Straighten:
  - Claw washer tabs
2. Remove:
  - Ring nut
  - Claw washer




**Ring nut wrench**  
YB-42223



3. Remove:
  - Propeller shaft housing




**Propeller shaft housing puller . ①**  
YB-06502 / 90890-06502  
**Universal puller..... ②**  
YB-06540 / 90890-06540



## REMOVING THE OUTER PROPELLER SHAFT

- Remove:
- Rear gear assembly ①
  - Outer propeller shaft ②
  - Thrust bearing ③
  - Outer propeller shaft shim ④



## DISASSEMBLING THE PROPELLER SHAFT HOUSING ASSEMBLY

- Remove:
- Needle bearing




**Slide hammer**  
YB-06096

**LOWR**

## PROPELLER SHAFT HOUSING ASSEMBLY (DUAL PROPELLER MODELS)

E




### DISASSEMBLING THE OUTER PROPELLER SHAFT ASSEMBLY

Remove:

- Needle bearing



**Slide hammer**  
YB-06096



### REMOVING THE REAR GEAR ASSEMBLY

Remove:

- Rear gear ①
- Thrust washer ②
- Tapered roller bearing ③
- Tapered roller bearing outer race ④



**Bearing separator**  
YB-06219 / 90890-06534

### INSPECTING THE BEARINGS

Inspect:

- Needle bearing
  - Thrust bearing
  - Tapered roller bearing
- Pitting/rumbling → Replace.

### INSPECTING THE PROPELLER SHAFT HOUSING

Inspect:

- Propeller shaft housing
- Cracks/damage → Replace.

### INSPECTING THE OUTER PROPELLER SHAFT






Inspect:

- Splines
- Damage/wear → Replace.

### INSPECTING THE REAR GEAR

Inspect:

- Teeth
  - Dogs
- Damage/wear → Replace.



**ASSEMBLING THE OUTER  
PROPELLER SHAFT ASSEMBLY**

1. Install:
- Needle bearing



**Needle bearing installation  
position (a)**  
34.75 - 35.25 mm  
(1.368 - 1.388 in)



**Bearing/oil seal attachment .... (1)**  
YB-42225 / 90890-06653  
**Driver rod ..... (2)**  
YB-06071 / 90890-06604  
**Bearing/oil seal depth plate .... (3)**  
90890-06603

- A** For USA and Canada  
**B** Except for USA and Canada

2. Install:
- Oil seal



**Oil seal installation position (a)**  
2.75 - 3.25 mm (0.108 - 0.128 in)



**Bearing/oil seal attachment .... (1)**  
YB-42225 / 90890-06636  
**Driver rod ..... (2)**  
YB-06071 / 90890-06606

**ASSEMBLING THE PROPELLER  
SHAFT HOUSING ASSEMBLY**

1. Install:
- Rear needle bearing




**Rear needle bearing installation  
position (a)**  
24.75 - 25.25 mm  
(0.974 - 0.994 in)



**Bearing/oil seal attachment .... (1)**  
YB-42227 / 90890-06607  
**Driver rod ..... (2)**  
YB-06071 / 90890-06604  
**Bearing/oil seal depth plate .... (3)**  
90890-06603

- A** For USA and Canada  
**B** Except for USA and Canada




2. Install:  
• Oil seal



**Oil seal installation position (a)**  
4.75 - 5.25 mm (0.187 - 0.207 in)



**Bearing/oil seal attachment .... (1)**  
YB-42227 / 90890-06623  
**Driver rod ..... (2)**  
YB-06071 / 90890-06606




3. Install:  
• Front needle bearing



**Front needle bearing installation position (a)**  
0.75 - 1.25 mm (0.030 - 0.049 in)




**Bearing/oil seal attachment .... (1)**  
YB-42229 / 90890-06607  
**Driver rod ..... (2)**  
YB-06071 / 90890-06604




4. Install:  
• Outer propeller shaft

**NOTE:**

When installing the outer propeller shaft into the propeller shaft housing assembly, wrap the entire threaded and splined portion of the outer propeller shaft to protect the oil seal lip from damage.



5. Install:  
• Tapered roller bearing (1)  
• Tapered roller bearing outer race (2)





6. Install:  
• Thrust washer (1)  
• Rear gear (2)

**LOWR**



## PROPELLER SHAFT HOUSING ASSEMBLY (DUAL PROPELLER MODELS)

E



### INSTALLING THE PROPELLER SHAFT HOUSING ASSEMBLY

1. Install:

- Propeller shaft housing assembly

**NOTE:** \_\_\_\_\_

Engage the pinion with the rear gear by turning the drive shaft to the right and left. Then, push the propeller shaft housing assembly into the lower case until the claw washer's insertion slot comes out.

2. Install:

- Claw washer
- Ring nut




**Ring nut wrench  
YB-42223**

**NOTE:** \_\_\_\_\_

- To secure the ring nut, bend one tab into the slot in the ring nut and the other tabs toward the propeller shaft housing assembly
- Check that the outer propeller shaft turns smoothly by turning the drive shaft clockwise.





**DRIVE SHAFT (DUAL PROPELLER MODELS)  
REMOVING/INSTALLING THE DRIVE SHAFT**




Order	Job/Part	Q'ty	Remarks
	Propeller shaft housing assembly		Refer to "PROPELLER SHAFT HOUSING ASSEMBLY (DUAL PROPELLER MODELS)" on page 6-58.
	Shift rod		Refer to "SHIFT ROD (DUAL PROPELLER MODELS)" on page 6-56.
1	Nut	1	
2	Pinion	1	
3	Bolt	4	
4	Drive shaft housing assembly	1	
5	Pinion shim	*	

Continued on next page.

\*: As required



Order	Job/Part	Q'ty	Remarks
6	Thrust bearing	1	
7	Drive shaft	1	
8	Inner propeller shaft assembly	1	
9	O-ring	1	
10	Oil seal cover	1	
11	Oil seal	2	
12	Needle bearing	1	
13	Drive shaft housing	1	
			For installation, reverse the removal procedure.



**REMOVING THE DRIVE SHAFT**

Loosen:

- Pinion nut



Drive shaft holder .....	①
YB-06201 / 90890-06520	
Pinion nut holder .....	②
YB-42224	

**NOTE:**

- First, loosen the drive shaft housing assembly bolts. Then, pull up the drive shaft and insert the pinion nut holder.
- Retighten the drive shaft housing assembly bolts and then loosen the pinion nut.

**INSPECTING THE PINION**


Inspect:

- Teeth  
Damage/wear → Replace.

**INSPECTING THE DRIVE SHAFT**

Inspect:

- Drive shaft  
Damage/wear → Replace.



**INSTALLING THE DRIVE SHAFT**

Tighten:


- Pinion nut



<b>Pinion nut</b>
<b>95 Nm (9.5 m • kgf, 68 ft • lb)</b>

**NOTE:**

- Tighten the pinion nut with the same tools that were used for removal.
- Tighten the pinion nut while slightly lifting the inner propeller shaft assembly ①.




**DISASSEMBLING THE DRIVE SHAFT HOUSING ASSEMBLY**

- Remove:
- Needle bearing

	<b>Bearing/oil seal attachment ....</b> ①
	<b>YB-06196 / 90890-06610</b>
	<b>Driver rod ..... ②</b>
	<b>YB-06071 / 90890-06652</b>

**INSPECTING THE DRIVE SHAFT HOUSING**

- Inspect:
- Drive shaft housing
- Cracks/damage → Replace.




**ASSEMBLING THE DRIVE SHAFT HOUSING ASSEMBLY**

1. Install:
- Needle bearing

	<b>Position ①</b>
	<b>5.75 - 6.25 mm (0.226 - 0.246 in)</b>

	<b>Bearing/oil seal attachment ....</b> ①
	<b>YB-06196 / 90890-06610</b>
	<b>Driver rod ..... ②</b>
	<b>YB-06071 / 90890-06604</b>
	<b>Bearing/oil seal depth plate .... ③</b>
	<b>90890-06603</b>


- A** For USA and Canada
- B** Except for USA and Canada



2. Install:
- Oil seal


	<b>Oil seal installation position ①</b>
	<b>0.25 - 0.75 mm (0.010 - 0.030 in)</b>

	<b>Bearing/oil seal attachment ....</b> ①
	<b>YB-06195 / 90890-06633</b>
	<b>Driver rod ..... ②</b>
	<b>YB-06071 / 90890-06652</b>







INNER PROPELLER SHAFT ASSEMBLY (DUAL PROPELLER MODELS)  
DISASSEMBLING/ASSEMBLING THE INNER PROPELLER SHAFT ASSEMBLY




Order	Job/Part	Q'ty	Remarks
1	Spring	1	
2	Pin	1	
3	Front dog clutch	1	
4	Front gear assembly	1	
5	Washer	1	(with oil groove Ⓐ)
6	Spring	1	

Continued on next page.



Order	Job/Part	Q'ty	Remarks
7	Rear dog clutch	1	
8	Washer	2	
9	Pin	1	
10	Collar	1	
11	Tapered roller bearing	1	<b>Not reusable</b>
12	Front gear	1	

For assembly, reverse the disassembly procedure.




## REMOVING THE SPRING

Remove:

- Spring ①

### NOTE:

Pry the end of the spring out of the groove in the dog clutch and then gradually remove it.



## DISASSEMBLING THE FRONT GEAR ASSEMBLY

Remove:

- Bearing inner race



**Bearing separator**  
YB-06219 / 90890-06534

### CAUTION:

Do not reuse the bearing, always replace it with a new one.

## INSPECTING THE DOG CLUTCHES

Inspect:

- Dog clutches  
Damage/wear → Replace.

## INSPECTING THE INNER PROPELLER SHAFT

Inspect:

- Inner propeller shaft  
Damage/wear → Replace.

## INSPECTING THE BEARING

Inspect:


- Tapered roller bearing  
Pitting/rumbling → Replace.

## INSPECTING THE FRONT GEAR

Inspect:


- Teeth
- Dogs  
Damage/wear → Replace.

LOWR



## INNER PROPELLER SHAFT ASSEMBLY (DUAL PROPELLER MODELS)

E




### ASSEMBLING THE FRONT GEAR ASSEMBLY

Install:

- Bearing inner race ①



**Bearing/oil seal attachment**  
YB-06276 / 90890-06659



### INSTALLING THE SPRING

Install:


- Spring ①

**NOTE:** \_\_\_\_\_

Push the end of the spring into the groove in the dog clutch and then gradually install it.


\_\_\_\_\_

**LOWER CASE ASSEMBLY (DUAL PROPELLER MODELS)  
DISASSEMBLING/ASSEMBLING THE LOWER CASE ASSEMBLY**



Order	Job/Part	Q'ty	Remarks
	Inner propeller shaft assembly		Refer to "DRIVE SHAFT (DUAL PROPELLER MODELS)" on page 6-66.
1	Drive shaft sleeve	1	
2	Needle bearing	1	
3	Tapered roller bearing outer race	1	
4	Front gear shim	*	
			For assembly, reverse the disassembly procedure.


\*: As required



**DISASSEMBLING THE LOWER CASE ASSEMBLY**

1. Remove:
- Needle bearing

	<b>Bearing/oil seal attachment ....</b> ①
	<b>YB-06194 / 90890-06636</b>
	<b>Driver rod ..... ②</b>
	<b>YB-06071 / 90890-06605</b>



2. Remove:
- Tapered roller bearing outer race


	<b>Slide hammer.....</b> ①
	<b>YB-06096</b>
	<b>Bearing puller..... ②</b>
	<b>90890-06523</b>
	<b>Large universal claws..... ③</b>
	<b>90890-06532</b>

**INSPECTING THE DRIVE SHAFT SLEEVE**

- Inspect:
- Drive shaft sleeve
- Damage/wear → Replace.

**INSPECTING THE NEEDLE BEARING**



- Inspect:
- Needle bearing
- Pitting/rumbling → Replace.



**ASSEMBLING THE LOWER CASE ASSEMBLY**

1. Install:
- Tapered roller bearing outer race

	<b>Bearing/oil seal attachment ....</b> ①
	<b>YB-06258 / 90890-06619</b>
	<b>Driver rod ..... ②</b>
	<b>YB-06071 / 90890-06605</b>



2. Install:
- Needle bearing




**Needle bearing installation position ①**  
**10.0 mm (0.39 in)**  
**Needle bearing installation position ②**  
**139.0 mm (5.47 in)**



**Bearing/oil seal attachment .... ①**  
**YB-06194 / 90890-06609**  
**Driver rod ..... ②**  
**YB-06071 / 90890-06602**  
**Bearing/oil seal depth plate .... ③**  
**YB-06213 / 90890-06603**  
**YB-34474**


- A** For USA and Canada  
**B** Except for USA and Canada




SHIMMING (REGULAR ROTATION MODELS)

**NOTE:**


- There is no need to select shims when reassembling with the original case and inner parts.
- Shim calculations are required when reassembling with the original inner parts and a new case (the difference between the original inner parts and the new case).
- Measurements and adjustments are required when replacing the inner part(s).





**SELECTING THE PINION SHIMS**

**NOTE:** \_\_\_\_\_  
Find the shim thickness (T3) by selecting shims until the specified value (M0) is obtained with the special tool.




1. Measure:
- Specified measurement (M)
  - Out of specified value (M0) → Adjust.

	<b>Specified value (M0) =</b> <b>1.00 + P/100 mm</b>
--	---

**Measuring steps**

- (1) Calculate the specified value (M0).



**NOTE:** \_\_\_\_\_

- "P" is the deviation of the lower case dimension from standard. It is stamped on the trim tab mounting surface of the lower case in 0.01-mm units. If the "P" mark is missing or unreadable, assume a "P" value of "0", and check the backlash when the unit is assembled.
- If the "P" mark is negative (-), then subtract the "P" value from the measurement.

Example:

If "P" is "+5", then

$$M0 = 1.00 + (+5)/100 \text{ mm}$$

$$= 1.00 + 0.05 \text{ mm}$$


$$= 1.05 \text{ mm}$$

If "P" is "-3", then

$$M0 = 1.00 + (-3)/100 \text{ mm}$$

$$= 1.00 - 0.03 \text{ mm}$$

$$= 0.97 \text{ mm}$$



(2) Install the pinion height gauge, drive shaft, thrust bearing ①, and shim(s) ②.




**Pinion height gauge  
YB-34432-7, -11**

**NOTE:** \_\_\_\_\_  
If the original shim(s) is unavailable, start with a 0.50-mm shim.

(3) Install the pinion and pinion nut.



**Pinion nut  
95 Nm (9.5 m • kgf, 69 ft • lb)**



(4) Measure the specified measurement (M).

**NOTE:** \_\_\_\_\_

- Measure the clearance between the pinion height gauge and the lower surface of the pinion as shown.
- Perform the same measurement at three points on the pinion.
- Find the average of the measurements (M).


2. Adjust:

- Shim thickness (T3)  
Remove or add shim(s).



**Available shim thickness  
0.10, 0.12, 0.15, 0.18, 0.30, 0.40  
and 0.50 mm**


**NOTE:** \_\_\_\_\_  
(M0) – (M) should be as close to “0” as possible.



**SELECTING THE FORWARD GEAR SHIMS**

**NOTE:** \_\_\_\_\_

Find the shim thickness (T1) by selecting shims until the specified value (M0) is obtained with the special tool.



1. Measure:

- Specified measurement (M)

Out of specified value (M0) → Adjust.




**Specified value (M0) =**  
**1.60 + F/100 mm**

**Measuring steps**

- (1) Calculate the specified value (M0).

**NOTE:** \_\_\_\_\_

- "F" is the deviation of the lower case dimension from standard. It is stamped on the trim tab mounting surface of the lower case in 0.01-mm units. If the "F" mark is missing or unreadable, assume an "F" value of "0", and check the backlash when the unit is assembled.
- If the "F" mark is negative (-), then subtract the "F" value from the measurement.





**Example:**

If "F" is "+5", then

$$\begin{aligned} M0 &= 1.60 + (+5)/100 \text{ mm} \\ &= 1.60 + 0.05 \text{ mm} \\ &= 1.65 \text{ mm} \end{aligned}$$

If "F" is "-3", then

$$\begin{aligned} M0 &= 1.60 + (-3)/100 \text{ mm} \\ &= 1.60 - 0.03 \text{ mm} \\ &= 1.57 \text{ mm} \end{aligned}$$



(2) Install the shimming gauge, bearing ①, and shim(s) ②.



**Shimming gauge  
YB-34446-1, -3, -4, -8**

**NOTE:** \_\_\_\_\_  
If the original shim(s) is unavailable, start with a 0.50-mm shim.

(3) Measure the specified measurement (M).


2. Adjust:
- Shim thickness (T1)
- Remove or add shim(s).



**Available shim thickness  
0.10, 0.12, 0.15, 0.18, 0.30, 0.40  
and 0.50 mm**

**NOTE:** \_\_\_\_\_  
(M0) – (M) should be as close to “0” as possible.





(2) Install the shimming gauge, bearing, thrust washer, reverse gear, and shim(s).



**Shimming gauge**  
(150A - 225D/C150TR - P200TR models)  
**YB-34468-1**  
(150G/P150TR models)  
**YB-34468-6**

- NOTE:** \_\_\_\_\_
- If the original shim(s) is unavailable, start with a 0.50-mm shim.
  - Turn the reverse gear assembly a few times until the gear and bearing are horizontal.




(3) Measure the specified measurement (M).

2. Adjust:
- Shim thickness (T2)  
Remove or add shim(s).



**Available shim thickness**  
**0.10, 0.12, 0.15, 0.18, 0.30, 0.40**  
**and 0.50 mm**

**NOTE:** \_\_\_\_\_  
(M0) – (M) should be as close to “0” as possible.



**SELECTING THE PINION SHIMS**

**NOTE:** \_\_\_\_\_  
Select the shim thickness (T3) by using the specified measurement(s) and the calculation formula

- Select:
- Shim thickness (T3)

**Selecting steps**

(1) Measure (M3).

	<b>Digital caliper</b> 90890-06704
--	---------------------------------------

**NOTE:** \_\_\_\_\_  
Install the bearing housing ①, thrust bearing ②, and washer ③.

(2) Install the pinion and pinion nut.

	<b>Pinion nut</b> 95 Nm (9.5 m • kgf, 69 ft • lb)
--	--

(3) Install the pinion height gauge.

	<b>Pinion height gauge</b> 90890-06702
--	---


**NOTE:** \_\_\_\_\_  
After the wing nuts contact the fixing plate, tighten them another 1/4 of a turn.

(4) Measure (M4).

	<b>Digital caliper</b> 90890-06704
--	---------------------------------------

**NOTE:** \_\_\_\_\_

- Measure the clearance between the pinion height gauge and the pinion, as shown.
- Perform the same measurement at three points on the pinion.
- Find the average of the measurements (M4).



(5) Calculate the pinion shim thickness (T3).



**Pinion shim thickness (T3) =**  
**80.0 + P/100 – M3 – M4**

**NOTE:**

- "P" is the deviation of the lower case dimension from standard. It is stamped on the trim tab mounting surface of the lower case in 0.01-mm units. If the "P" mark is missing or unreadable, assume a "P" value of "0", and check the backlash when the unit is assembled.
- If the "P" mark is negative (-), then add the "P" value to the measurement.

Example:

If M3 is "46.85 mm", M4 is "32.52 mm" and P is "-5", then





$$\begin{aligned}
 T3 &= 80.0 + (-5)/100 - 46.85 - 32.52 \text{ mm} \\
 &= 80.0 - 0.05 - 46.85 - 32.52 \text{ mm} \\
 &= 0.58 \text{ mm}
 \end{aligned}$$

(6) Select the pinion shim(s) (T3).

Calculated numeral at 1/100th place		Rounded numeral
More than	or less	
0.00	0.02	0.00
0.02	0.05	0.02
0.05	0.08	0.05
0.08	0.10	0.08



**Available shim thickness**  
**0.10, 0.12, 0.15, 0.18, 0.30, 0.40**  
**and 0.50 mm**



**SELECTING THE FORWARD GEAR SHIMS**

**NOTE:** \_\_\_\_\_  
Select the shim thickness (T1) by using the specified measurement(s) and the calculation formula.

- Select:
- Shim thickness (T1)

**Selecting steps**

(1) Measure (M1).

	<b>Shimming plate</b> ..... ① <b>90890-06701</b>
	<b>Digital caliper</b> ..... ② <b>90890-06704</b>

**NOTE:** \_\_\_\_\_

- Turn the roller bearing outer race two or three times so the rollers seat. Then, measure the height of the bearing, as shown.
- Perform the same measurement at three points on the roller bearing outer race.
- Find the average of the measurements (M1).

(2) Calculate the forward gear shim thickness (T1).

	<b>Forward gear shim thickness (T1)</b> <b>(T1) = 28.6 + F/100 - M1</b>
---	--

**NOTE:** \_\_\_\_\_

- "F" is the deviation of the lower case dimension from standard. It is stamped on the trim tab mounting surface of the lower case in 0.01-mm units. If the "F" mark is missing or unreadable, assume an "F" value of "0", and check the backlash when the unit is assembled.
- If the "F" mark is negative (-), then subtract the "F" value from the measurement.

Example:



If M1 is "28.10 mm" and F is "+5", then  
 $T1 = 28.6 + (+5)/100 - 28.10 \text{ mm}$   
 $= 28.6 + 0.05 - 28.10 \text{ mm}$   
 $= 0.55 \text{ mm}$

(3) Select the forward gear shim(s) (T1).

Calculated numeral at 1/100th place		Rounded numeral
More than	or less	
0.00	0.02	0.00
0.02	0.05	0.02
0.05	0.08	0.05
0.08	0.10	0.08



**Available shim thickness**  
0.10, 0.12, 0.15, 0.18, 0.30, 0.40 and 0.50 mm



**SELECTING THE REVERSE GEAR SHIM**

**NOTE:** \_\_\_\_\_  
 Select the shim thickness (T2) by using the specified measurement(s) and the calculation formula.

- Select:
- Shim thickness (T2)

**Selecting steps**

(1) Measure (M2).

	<b>Shimming plate</b> ..... ①
	<b>Digital caliper</b> ..... ②

**NOTE:** \_\_\_\_\_

- Measure the height of the gear as shown.
- Perform the same measurement at three points on the gear.
- Find the average of the measurements (M2).

(2) Calculate the reverse gear shim thickness (T2).




**Reverse gear shim thickness  
(150A - 225D/C150TR - P200TR  
models)**

$$(T2) = M2 - 29.0 - R/100$$

**(150G/P150TR models)**

$$(T2) = M2 - 29.9 - R/100$$



**NOTE:**

- "R" is the deviation of the lower case dimension from standard. It is stamped on the trim tab mounting surface of the lower case in 0.01-mm units. If the "R" mark is missing or unreadable, assume a "R" value of "0", and check the backlash when the unit is assembled.
- If the "R" mark is negative (-), then subtract the "R" value from the measurement.

Example (150G/P150TR models):

If M2 is "30.50 mm", R is "+2", then

$$T2 = 30.50 - 29.9 - (+2)/100 \text{ mm}$$

$$= 30.50 - 29.9 - 0.02 \text{ mm}$$

$$= 0.58 \text{ mm}$$

(3) Select the reverse gear shim(s) (T2).

Calculated numeral at 1/100th place		Rounded numeral
More than	or less	
0.00	0.02	0.02
0.02	0.05	0.05
0.05	0.08	0.08
0.08	0.10	0.10



**Available shim thickness  
0.10, 0.12, 0.15, 0.18, 0.30, 0.40  
and 0.50 mm**



## BACKLASH (REGULAR ROTATION MODELS)

### NOTE:

- Do not install the water pump components when measuring the backlash.
- Measure both the forward and reverse gear backlashes.
- If both the forward and reverse gear backlashes are larger than specification, the pinion may be too high.
- If both the forward and reverse gear backlashes are smaller than specification, the pinion may be too low.

## MEASURING THE FORWARD GEAR BACKLASH

### 1. Measure:

- Forward gear backlash  
Out of specification → Adjust.




### Forward gear backlash (150A - 225D/C150TR - P200TR models)

0.25 - 0.46 mm  
(0.010 - 0.018 in)

(150G/P150TR models)

0.71 - 1.01 mm  
(0.028 - 0.040 in)




### Measuring steps

- (1) Set the shift rod into the neutral position.




**Shift rod wrench**  
YB-06052 / 90890-06052



(2) Install the propeller shaft housing puller so it pushes against the propeller shaft.

	<b>Propeller shaft housing puller</b> ..... ① YB-06207 / 90890-06502
	<b>Universal puller</b> ..... ② YB-06117
	<b>Guide plate</b> ..... ③ 90890-06501
	<b>Center bolt</b> ..... ④ 90890-06504

	<b>Center bolt</b> 10 Nm (1.0 m • kgf, 7.2 ft • lb)
--	--



(3) Install the backlash indicator onto the drive shaft (on the 22.4 mm (0.88 in) diameter portion of the drive shaft).

	<b>Backlash indicator</b> ..... ⑤ YB-06265 / 90890-06706
--	---

(4) Install the dial gauge onto the lower unit and have the dial gauge plunger contact the mark on the backlash indicator.

	<b>Magnetic-base plate</b> ..... ⑥ YB-07003 / 90890-07003
	<b>Dial gauge set</b> ..... ⑦ YU-03097 / 90890-01252
	<b>Magnetic base</b> ..... ⑧ YU-34481 / 90890-06705

- (5) Set the lower unit upside down.
- (6) Slowly turn the drive shaft clockwise and counterclockwise. When the drive shaft stops in each direction, measure the backlash.



2. Adjust:

- Forward gear shim

Remove or add shim(s).

	<b>Forward gear backlash</b>	<b>Shim thickness</b>
	<b>Less than</b> (150A - 225D/ C150TR - P200TR models) 0.25 mm (0.010 in) (150G/P150TR models) 0.71 mm (0.028 in)	<b>To be decreased by</b> (150A - 225D/ C150TR - P200TR models) $(0.36 - M) \times 0.54$ (150G/P150TR models) $(0.86 - M) \times 0.54$
	<b>More than</b> (150A - 225D/ C150TR - P200TR models) 0.46 mm (0.018 in) (150G/P150TR models) 1.01 mm (0.040 in)	<b>To be increased by</b> (150A - 225D/ C150TR - P200TR models) $(M - 0.36) \times 0.54$ (150G/P150TR models) $(M - 0.86) \times 0.54$

M: Measurement


**MEASURING THE REVERSE GEAR BACKLASH**

1. Measure:

- Reverse gear backlash

Out of specification → Adjust.

	<b>Reverse gear backlash</b> (150A - 225D/C150TR - P200TR models)
	0.74 - 1.29 mm (0.029 - 0.051 in) (150G/P150TR models) 0.79 - 1.38 mm (0.031 - 0.054 in)




**Measuring steps**

(1) Set the shift rod into the neutral position.




**Shift rod wrench**  
YB-06052 / 90890-06052



(2) Load the reverse gear by installing the propeller without the spacer ① and then tighten the propeller nut.



**Propeller nut**  
10 Nm (1.0 m • kgf, 7.2 ft • lb)



(3) Install the backlash indicator onto the drive shaft (on the 22.4 mm (0.88 in) diameter portion of the drive shaft).



**Backlash indicator** ..... ①  
YB-06265 / 90890-06706

(4) Install the dial gauge onto the lower unit and have the dial gauge plunger contact the mark on the backlash indicator.



**Magnetic-base plate** ..... ②  
YB-07003 / 90890-07003  
**Dial gauge set** ..... ③  
YU-03097 / 90890-01252  
**Magnetic base** ..... ④  
YU-34481 / 90890-06705

(5) Set the lower unit upside down.  
(6) Slowly turn the drive shaft clockwise and counterclockwise. When the drive shaft stops in each direction, measure the backlash.



2. Adjust:

- Reverse gear shim

Remove or add shim(s).

	<b>Reverse gear backlash</b>	<b>Shim thickness</b>
	<b>Less than</b> (150A - 225D/ C150TR - P200TR models) 0.74 mm (0.029 in) (150G/P150TR models) 0.79 mm (0.031 in)	<b>To be increased by</b> (150A - 225D/ C150TR - P200TR models) $(1.02 - M) \times 0.54$ (150G/P150TR models) $(1.09 - M) \times 0.54$
	<b>More than</b> (150A - 225D/ C150TR - P200TR models) 1.29 mm (0.051 in) (150G/P150TR models) 1.38 mm (0.054 in)	<b>To be decreased by</b> (150A - 225D/ C150TR - P200TR models) $(M - 1.02) \times 0.54$ (150G/P150TR models) $(M - 1.09) \times 0.54$


M: Measurement




SHIMMING (COUNTER ROTATION MODELS)

**NOTE:**


- There is no need to select shims when reassembling with the original case and inner parts.
- Shim calculations are required when reassembling with the original inner parts and a new case (the difference between the original inner parts and the new case).
- Measurements and adjustments are required when replacing the inner part(s).





**SELECTING THE PINION SHIMS**

**NOTE:** \_\_\_\_\_  
Find the shim thickness (T3) by selecting shims until the specified measurement (M) is obtained with the special tool.




1. Measure:
- Specified measurement (M)
  - Out of specified value (M0) → Adjust.

	<b>Specified value (M0) =</b> <b>1.00 + P/100 mm</b>
--	---

**Measuring steps**

- (1) Calculate the specified value (M0).



**NOTE:** \_\_\_\_\_

- "P" is the deviation of the lower case dimension from standard. It is stamped on the trim tab mounting surface of the lower case in 0.01-mm units. If the "P" mark is missing or unreadable, assume a "P" value of "0", and check the backlash when the unit is assembled.
- If the "P" mark is negative (-), then subtract the "P" value from the measurement.

Example:

If "P" is "+5", then

$$M0 = 1.00 + (+5)/100 \text{ mm}$$

$$= 1.00 + 0.05 \text{ mm}$$



$$= 1.05 \text{ mm}$$

If "P" is "-3", then

$$M0 = 1.00 + (-3)/100 \text{ mm}$$

$$= 1.00 - 0.03 \text{ mm}$$

$$= 0.97 \text{ mm}$$



(2) Install the pinion height gauge, drive shaft, thrust bearing ①, and shim(s) ②.




**Pinion height gauge**  
**YB-34432-7, -11**

**NOTE:** \_\_\_\_\_  
If the original shim(s) is unavailable, start with a 0.50-mm shim.

(3) Install the pinion and pinion nut.



**Pinion nut**  
**95 Nm (9.5 m • kgf, 69 ft • lb)**



(4) Measure the specified measurement (M).

**NOTE:** \_\_\_\_\_

- Measure the clearance between the pinion height gauge and the lower surface of the pinion as shown.
- Perform the same measurement at three points on the pinion.
- Find the average of the measurements (M).


2. Adjust:

- Shim thickness (T3)  
Remove or add shim(s).




**Available shim thickness**  
**0.10, 0.12, 0.15, 0.18, 0.30, 0.40**  
**and 0.50 mm**

**NOTE:** \_\_\_\_\_  
(M0) – (M) should be as close to “0” as possible.



**SELECTING THE REVERSE GEAR SHIMS**

**NOTE:** \_\_\_\_\_  
Find the shim thickness (T1) by selecting shims until the specified value (M0) is obtained with the special tool.




1. Measure:
- Specified measurement (M)
  - Out of specified value (M0) → Adjust.

	<p><b>Specified value (M0) =</b> <b>29.10 + F/100 mm</b></p>
--	--

**Measuring steps**

- (1) Calculate the specified value (M0).



**NOTE:** \_\_\_\_\_

- “F” is the deviation of the lower case dimension from standard. It is stamped on the trim tab mounting surface of the lower case in 0.01-mm units. If the “F” mark is missing or unreadable, assume an “F” value of “0”, and check the backlash when the unit is assembled.
- If the “F” mark is negative (-), then subtract the “F” value from the measurement.

Example:

If “F” is “+5”, then

$$M0 = 29.10 + (+5)/100 \text{ mm}$$

$$= 29.10 + 0.05 \text{ mm}$$


$$= 29.15 \text{ mm}$$

If “F” is “-3”, then

$$M0 = 29.10 + (-3)/100 \text{ mm}$$

$$= 29.10 - 0.03 \text{ mm}$$

$$= 29.07 \text{ mm}$$



(2) Install the roller bearing ①, thrust bearing ②, and shim(s) ③.

**NOTE:** \_\_\_\_\_  
If the original shim(s) is unavailable, start with a 0.50-mm shim.

(3) Measure the specified measurement (M).


2. Adjust:

- Shim thickness (T1)
- Remove or add shim(s).




**Available shim thickness**  
**0.10, 0.12, 0.15, 0.18, 0.30, 0.40**  
**and 0.50 mm**

**NOTE:** \_\_\_\_\_  
(M0) – (M) should be as close to “0” as possible.



**SELECTING THE FORWARD GEAR SHIMS**


**NOTE:** \_\_\_\_\_  
Find the shim thickness (T2) by selecting shims until the specified value (M0) is obtained with the special tool.



1. Measure:  
• Specified measurement (M)  
Out of specified value (M0) → Adjust.



**Specified value (M0) =**  
**1.30 – R/100 mm**



**Measuring steps**

(1) Calculate the specified value (M0).

**NOTE:**

- "R" is the deviation of the lower case dimension from standard. It is stamped on the trim tab mounting surface of the lower case in 0.01-mm units. If the "R" mark is missing or unreadable, assume an "R" value of "0", and check the backlash when the unit is assembled.
- If the "R" mark is negative (-), then add the "R" value to the measurement.

Example:

If "R" is "+5", then

$$M0 = 1.30 - (+5)/100 \text{ mm}$$

$$= 1.30 - 0.05 \text{ mm}$$


$$= 1.25 \text{ mm}$$

If "R" is "-3", then

$$M0 = 1.30 - (-3)/100 \text{ mm}$$

$$= 1.30 + 0.03 \text{ mm}$$

$$= 1.33 \text{ mm}$$




(2) Install the shimming gauge, bearing, thrust washer, forward gear, and shim(s).

	<p><b>Shimming gauge YB-34468-2</b></p>
--	---

**NOTE:**

- If the original shim(s) is unavailable, start with a 0.50-mm shim.
- Turn the forward gear assembly a few times until the gear and bearing are horizontal.

(3) Measure the specified measurement (M).




2. Adjust:
- Shim thickness (T2)
- Remove or add shim(s).




**Available shim thickness**  
0.10, 0.12, 0.15, 0.18, 0.30, 0.40  
and 0.50 mm

**NOTE:** \_\_\_\_\_  
(M0) – (M) should be as close to “0” as possible.




**SELECTING THE PROPELLER SHAFT SHIMS**

**NOTE:** \_\_\_\_\_  
Find the shim thickness (T4) by selecting shims until the specified measurement is obtained with the special tool.



1. Install:
- Shim(s) ①
  - Thrust bearing ②
  - Propeller shaft ③
  - Tapered roller bearing ④



2. Measure:
- Propeller shaft free play
- Out of specification → Adjust.



**Propeller shaft free play**  
0.30 ± 0.05 mm






**Magnetic base**..... ①  
**YU-34481**  
**Dial gauge set** ..... ②  
**YU-03097**

3. Adjust:
- Propeller shaft free play
- Remove or add shim(s).



**Available shim thickness**  
0.10, 0.12, 0.15, 0.18, 0.30, 0.40  
and 0.50 mm



**SELECTING THE PINION SHIMS**

**NOTE:** \_\_\_\_\_  
Select the shim thickness (T3) by using the specified measurement(s) and the calculation formula

- Select:
- Shim thickness (T3)

**Selecting steps**

(1) Measure (M3).

	<b>Digital caliper</b> 90890-06704
---	---------------------------------------

**NOTE:** \_\_\_\_\_  
Install the bearing housing ①, thrust bearing ②, and washer ③.

(2) Install the pinion and pinion nut.

	<b>Pinion nut</b> 95 Nm (9.5 m • kgf, 69 ft • lb)
---	--

(3) Install the pinion height gauge.

	<b>Pinion height gauge</b> 90890-06702
---	---


**NOTE:** \_\_\_\_\_  
After the wing nuts contact the fixing plate, tighten them another 1/4 of a turn.

(4) Measure (M4).

	<b>Digital caliper</b> 90890-06704
---	---------------------------------------

**NOTE:** \_\_\_\_\_

- Measure the clearance between the pinion height gauge and the pinion, as shown.
- Perform the same measurement at three points on the pinion.
- Find the average of the measurements (M4).



(5) Calculate the pinion shim thickness (T3).



**Pinion shim thickness (T3) =**  
**80.0 + P/100 – M3 – M4**

**NOTE:**

- "P" is the deviation of the lower case dimension from standard. It is stamped on the trim tab mounting surface of the lower case in 0.01-mm units. If the "P" mark is missing or unreadable, assume a "P" value of "0", and check the backlash when the unit is assembled.
- If the "P" mark is negative (-), then add the "P" value to the measurement.

Example:

If M3 is "46.85 mm", M4 is "32.52 mm" and P is "-5", then



$$\begin{aligned}
 T3 &= 80.0 + (-5)/100 - 46.85 - 32.52 \text{ mm} \\
 &= 80.0 - 0.05 - 46.85 - 32.52 \text{ mm} \\
 &= 0.58 \text{ mm}
 \end{aligned}$$

(6) Select the pinion shim(s) (T3).

Calculated numeral at 1/100th place		Rounded numeral
More than	or less	
0.00	0.02	0.00
0.02	0.05	0.02
0.05	0.08	0.05
0.08	0.10	0.08



**Available shim thickness**  
**0.10, 0.12, 0.15, 0.18, 0.30, 0.40**  
**and 0.50 mm**



**SELECTING THE REVERSE GEAR SHIMS**

**NOTE:** \_\_\_\_\_  
Select the shim thickness (T1) by using the specified measurement(s) and the calculation formula.


- Select:
- Shim thickness (T1)

**Selecting steps**

(1) Measure (M1).



**Digital caliper  
90890-06704**




- NOTE:** \_\_\_\_\_
- Measure the combined thickness of the roller bearing ① and thrust bearing ②.
  - Turn the roller bearing outer race two or three times so the rollers seat. Then, measure the height of the bearing, as shown.
  - Perform the same measurement at three points on the roller bearing outer race.
  - Find the average of the measurements (M1).

(2) Calculate the reverse gear shim thickness (T1).



**Reverse gear shim thickness (T1)  
(T1) = 29.1 + F/100 - M1**

- NOTE:** \_\_\_\_\_
- "F" is the deviation of the lower case dimension from standard. It is stamped on the trim tab mounting surface of the lower case in 0.01-mm units. If the "F" mark is missing or unreadable, assume an "F" value of "0", and check the backlash when the unit is assembled.
  - If the "F" mark is negative (-), then subtract the "F" value from the measurement.



Example:



If M1 is "28.10 mm" and F is "+5", then  
 $T1 = 29.1 + (+5)/100 - 28.10 \text{ mm}$   
 $= 29.1 + 0.05 - 28.10 \text{ mm}$   
 $= 1.05 \text{ mm}$

(3) Select the reverse gear shim(s).

Calculated numeral at 1/100th place		Rounded numeral
More than	or less	
0.00	0.02	0.00
0.02	0.05	0.02
0.05	0.08	0.05
0.08	0.10	0.08



**Available shim thickness**  
 0.10, 0.12, 0.15, 0.18, 0.30, 0.40 and 0.50 mm



**SELECTING THE FORWARD GEAR SHIMS**

**NOTE:** \_\_\_\_\_  
 Select the shim thickness (T2) by using the specified measurement(s) and the calculation formula.

- Select:
- Shim thickness (T2)


**Selecting steps**

(1) Measure (M2).

	<b>Shimming plate</b> ..... ①
	<b>90890-06701</b>
	<b>Digital caliper</b> ..... ②
	<b>90890-06704</b>

**NOTE:** \_\_\_\_\_

- Measure the height of the gear as shown.
- Perform the same measurement at three points on the gear.
- Find the average of the measurements (M2).



(2) Calculate the forward gear shim thickness (T2).



**Forward gear shim thickness  
(T2) = M2 - 29.5 - R/100**

**NOTE:**

- "R" is the deviation of the lower case dimension from standard. It is stamped on the trim tab mounting surface of the lower case in 0.01-mm units. If the "R" mark is missing or unreadable, assume a "R" value of "0", and check the backlash when the unit is assembled.
- If the "R" mark is negative (-), then subtract the "R" value from the measurement.

Example:


If M2 is "30.50 mm", R is "+2", then  
 $T2 = 30.50 - 29.5 - (+2)/100$  mm  
 $= 30.50 - 29.5 - 0.02$  mm  
 $= 0.98$  mm

(3) Select the forward gear shim(s) (T2).

Calculated numeral at 1/100th place		Rounded numeral
More than	or less	
0.00	0.02	0.02
0.02	0.05	0.05
0.05	0.08	0.08
0.08	0.10	0.10




**Available shim thickness  
0.10, 0.12, 0.15, 0.18, 0.30, 0.40  
and 0.50 mm**




**SELECTING THE PROPELLER SHAFT SHIMS**

**NOTE:** \_\_\_\_\_  
Find the shim thickness (T4) by selecting shims until the specified measurement is obtained with the special tool.



1. Install:
- Shim(s) ①
  - Thrust bearing ②
  - Propeller shaft ③
  - Tapered roller bearing ④



2. Measure:
- Propeller shaft free play  
Out of specification → Adjust.

	<b>Propeller shaft free play</b> <b>0.30 ± 0.05 mm</b>
--	---

	<b>Magnetic base..... ①</b> <b>90890-06705</b>
	<b>Dial gauge set ..... ②</b> <b>90890-01252</b>

3. Adjust:
- Propeller shaft free play  
Remove or add shim(s).

	<b>Available shim thickness</b> <b>0.10, 0.12, 0.15, 0.18, 0.30, 0.40</b> <b>and 0.50 mm</b>
--	--



## BACKLASH (COUNTER ROTATION MODELS)

**NOTE:**

- Do not install the water pump components when measuring the backlash.
- Measure both the forward and reverse gear backlashes.
- If both the forward and reverse gear backlashes are larger than specification, the pinion may be too high.
- If both the forward and reverse gear backlashes are smaller than specification, the pinion may be too low.

### MEASURING THE FORWARD GEAR BACKLASH

1. Measure:

- Forward gear backlash
- Out of specification → Adjust.

	<p><b>Forward gear backlash</b> 0.21 - 0.43 mm (0.008 - 0.017 in)</p>
--	---

**Measuring steps**



- (1) Set the shift rod into the neutral position.



	<p><b>Shift rod wrench</b> YB-06052 / 90890-06052</p>
--	---

- (2) Install the propeller shaft housing puller so it pushes against the propeller shaft.

	<p><b>Propeller shaft housing puller .</b> ① YB-06207 / 90890-06502</p> <p><b>Universal puller.....</b> ② YB-06117</p> <p><b>Guide plate.....</b> ③ 90890-06501</p> <p><b>Center bolt .....</b> ④ 90890-06504</p>
--	---

	<p><b>Center bolt</b> 10 Nm (1.0 m • kgf, 7.2 ft • lb)</p>
--	--





(3) Install the backlash indicator onto the drive shaft (on the 22.4 mm (0.88 in) diameter portion of the drive shaft).

	<b>Backlash indicator</b> ..... ⑤ <b>YB-06265 / 90890-06706</b>
--	--

(4) Install the dial gauge onto the lower unit and have the dial gauge plunger contact the mark on the backlash indicator.

	<b>Magnetic-base plate</b> ..... ⑥ <b>YB-07003 / 90890-07003</b>
	<b>Dial gauge set</b> ..... ⑦ <b>YU-03097 / 90890-01252</b>
	<b>Magnetic base</b> ..... ⑧ <b>YU-34481 / 90890-06705</b>

- (5) Set the lower unit upside down.
- (6) Slowly turn the drive shaft clockwise and counterclockwise. When the drive shaft stops in each direction, measure the backlash.

**2. Adjust:**

- Forward gear shim  
Remove or add shim(s).

Forward gear backlash	Shim thickness
<b>Less than 0.21 mm (0.008 in)</b>	<b>To be increased by (0.32 - M) × 0.54</b>
<b>More than 0.43 mm (0.017 in)</b>	<b>To be decreased by (M - 0.32) × 0.54</b>





M: Measurement

**MEASURING THE REVERSE GEAR BACKLASH**

**1. Measure:**

- Reverse gear backlash  
Out of specification → Adjust.

	<b>Reverse gear backlash</b> <b>0.97 - 1.29 mm (0.038 - 0.051 in)</b>
--	--



**Measuring steps**

(1) Set the shift rod into the neutral position.

	<b>Shift rod wrench</b> YB-06052 / 90890-06052
--	---

(2) Load the reverse gear by installing the propeller without the spacer and then tighten the propeller nut.

	<b>Propeller nut</b> 5 Nm (0.5 m • kgf, 3.6 ft • lb)
--	---

(3) Install the backlash indicator onto the drive shaft (on the 22.4 mm (0.88 in) diameter portion of the drive shaft).


	<b>Backlash indicator</b> ..... ① YB-06265 / 90890-06706
--	---

(4) Install the dial gauge onto the lower unit and have the dial gauge plunger contact the mark on the backlash indicator.

	<b>Magnetic-base plate</b> ..... ② YB-07003 / 90890-07003
	<b>Dial gauge set</b> ..... ③ YU-03097 / 90890-01252
	<b>Magnetic base</b> ..... ④ YU-34481 / 90890-06705

(5) Set the lower unit upside down.  
 (6) Turn the shift rod into the reverse position with the shift rod wrench.  
 (7) Turn the drive shaft clockwise until the clutch dog is fully engaged.

(8) Turn the shift rod into the neutral position with the shift rod wrench.  
 (9) Turn the drive shaft counterclockwise approximately 30° more.



- (10) Turn the shift rod into the reverse position with the shift rod wrench.
- (11) Slowly turn the drive shaft clockwise and counterclockwise. When the drive shaft stops in each direction, measure the backlash.

**NOTE:** \_\_\_\_\_

When measuring the reverse gear backlash, turn the shift rod wrench slightly towards the reverse position.

2. Adjust:

- Reverse gear shim  
Remove or add shim(s).

 Reverse gear backlash	Shim thickness
Less than 0.97 mm (0.038 in)	To be decreased by $(1.13 - M) \times 0.54$
More than 1.29 mm (0.051 in)	To be increased by $(M - 1.13) \times 0.54$


M: Measurement




SHIMMING (DUAL PROPELLER MODELS)

**NOTE:**

- There is no need to select shims when reassembling with the original case and inner parts.
- Shim calculations are required when reassembling with the original inner parts and a new case (the difference between the original inner parts and the new case).
- Measurements and adjustments are required when replacing the inner part(s).






**SELECTING THE PINION SHIMS**

**NOTE:**

Find the shim thickness (T3) by selecting shims until the specified value (M0) is obtained with the special tool.



1. Measure:

- Specified measurement (M)


Out of specified value (M0) → Adjust.



**Specified value (M0) =**  
**1.00 + P/100 mm**

**Measuring steps**

- (1) Calculate the specified value (M0).



**NOTE:**

- "P" is the deviation of the lower case dimension from standard. It is stamped on the lower case in 0.01-mm units. If the "P" mark is missing or unreadable, assume a "P" value of "0", and check the backlash when the unit is assembled.
- If the "P" mark is negative (-), then subtract the "P" value from the measurement.

**Example:**

If "P" is "+5", then

$$M0 = 1.00 + (+5)/100 \text{ mm}$$

$$= 1.00 + 0.05 \text{ mm}$$


$$= 1.05 \text{ mm}$$

If "P" is "-3", then

$$M0 = 1.00 + (-3)/100 \text{ mm}$$

$$= 1.00 - 0.03 \text{ mm}$$

$$= 0.97 \text{ mm}$$



(2) Install the pinion height gauge, drive shaft, thrust bearing ①, and shim(s) ②.




**Pinion height gauge**  
**YB-34432-11, -97**

**NOTE:** \_\_\_\_\_  
If the original shim(s) is unavailable, start with a 0.50-mm shim.

(3) Install the pinion and pinion nut.



**Pinion nut**  
**95 Nm (9.5 m • kgf, 68 ft • lb)**



(4) Measure the specified measurement (M).

**NOTE:** \_\_\_\_\_

- Measure the clearance between the pinion height gauge and the lower surface of the pinion as shown.
- Perform the same measurement at three points on the pinion.
- Final the average of the measurements(M).





2. Adjust:

- Shim thickness (T3)  
Remove or add shim(s).



**Available shim thicknesses**  
**0.10, 0.12, 0.15, 0.18, 0.30, 0.40**  
**and 0.50 mm**

**NOTE:** \_\_\_\_\_  
(M0) – (M) should be as close to “0” as possible.



**SELECTING THE FRONT GEAR SHIMS**

**NOTE:** Find the shim thickness (T1) by selecting shims until the specified value (M0) is obtained with the special tool.

1. Measure:
- Specified measurement (M)
- Out of specified value (M0) → Adjust.

	<b>Specified value (M0) =</b> <b>1.00 + F/100 mm</b>
--	---

**Measuring steps**

- (1) Calculate the specified value (M0).

**NOTE:**

- “F” is the deviation of the lower case dimension from standard. It is stamped on the lower case in 0.01-mm units. If the “F” mark is missing or unreadable, assume an “F” value of “0”, and check the backlash when the unit is assembled.
- If the “F” mark is negative (-), then subtract the “F” value from the measurement.

**Example:**

If “F” is “+5”, then  
 $M0 = 1.00 + (+5)/100 \text{ mm}$   
 $= 1.00 + 0.05 \text{ mm}$   
 $= 1.05 \text{ mm}$

If “F” is “-3”, then  
 $M0 = 1.00 + (-3)/100 \text{ mm}$   
 $= 1.00 - 0.03 \text{ mm}$   
 $= 0.97 \text{ mm}$

- (2) Install the shimming gauge, bearing ①, and shim(s) ②.

	<b>Shimming gauge</b> <b>YB-34446-1, -3, -4, -7</b>
--	--

**NOTE:** If the original shim(s) is unavailable, start with a 0.50-mm shim.



(3) Measure the specified measurement (M).

2. Adjust:

- Shim thickness (T1)


Remove or add shim(s).



**Available shim thickness**  
0.10, 0.12, 0.15, 0.18, 0.30, 0.40  
and 0.50 mm

**NOTE:** \_\_\_\_\_

(M0) – (M) should be as close to “0” as possible.



**SELECTING THE REAR GEAR SHIMS**

**NOTE:** \_\_\_\_\_

Find the shim thickness (T2) by selecting shims until the specified value (M0) is obtained with the special tool.


1. Measure:

- Specified measurement (M)

Out of specified value (M0) → Adjust.



**Specified measurement (M0) =**  
**1.60 – R/100 mm**




**Measuring steps**

(1) Calculate the specified value (M0).

**NOTE:** \_\_\_\_\_

- “R” is the deviation of the lower case dimension from standard. It is stamped on the lower case in 0.01-mm units. If the “R” mark is missing or unreadable, assume an “R” value of “0”, and check the backlash when the unit is assembled.
- If the “R” mark is negative (–), then add the “R” value to the measurement.





Example:

If "R" is "+5", then

$$M0 = 1.60 - (+5)/100 \text{ mm}$$

$$= 1.60 - 0.05 \text{ mm}$$


$$= 1.55 \text{ mm}$$

If "R" is "-3", then

$$M0 = 1.60 - (-3)/100 \text{ mm}$$

$$= 1.60 + 0.03 \text{ mm}$$

$$= 1.63 \text{ mm}$$



(2) Install the shimming gauge, bearing, thrust washer, rear gear, and shim(s).



**Shimming gauge  
YB-34468-1**

**NOTE:**

- If the original shim(s) is unavailable, start with a 0.50-mm shim.
- Turn the rear gear assembly a few times until the gear and bearing are horizontal.

(3) Measure the specified measurement (M).

2. Adjust:


- Shim thickness (T2)  
Remove or add shim(s).



**Available shim thicknesses  
0.10, 0.12, 0.15, 0.18, 0.30, 0.40  
and 0.50 mm**


**NOTE:**

(M0) – (M) should be as close to "0" as possible.




**SELECTING THE OUTER PROPELLER SHAFT SHIMS**

**NOTE:** Find the shim thickness (T4) by selecting shims until the specified measurement is obtained with the special tool.



1. Install:
- Shim(s) ①
  - Thrust bearing ②
  - Outer propeller shaft ③
  - Tapered roller bearing ④



2. Measure:
- Outer propeller shaft free play  
Out of specification → Adjust.

	<b>Propeller shaft free play</b> <b>0.30 ± 0.05 mm</b>
--	---

	<b>Magnetic base..... ①</b> <b>YU-34481</b>
	<b>Dial gauge set ..... ②</b> <b>YU-03097</b>

3. Adjust:
- Outer propeller shaft free play  
Remove or add shim(s).

	<b>Available shim thickness</b> <b>0.10, 0.12, 0.15, 0.18, 0.30, 0.40</b> <b>and 0.50 mm</b>
--	--



## BACKLASH (DUAL PROPELLER MODELS)

**NOTE:** \_\_\_\_\_

- Do not install the water pump components when measuring the backlash.
- Measure both the forward and reverse gear backlashes.
- If both the forward and reverse gear backlashes are larger than specification, the pinion may be too high.
- If both the forward and reverse gear backlashes are smaller than specification, the pinion may be too low.

### MEASURING THE FRONT GEAR BACKLASH

1. Measure:

- Front gear backlash

Out of specification → Adjust.

	<p><b>Front gear backlash</b> 0.19 - 0.59 mm (0.007 - 0.023 in)</p>
--	---

**Measuring steps**



- (1) Set the shift rod into the neutral position.


	<p><b>Shift rod wrench</b> YB-06052 / 90890-06052</p>
--	---

- (2) Install the propeller shaft housing puller so it pushes against the inner propeller shaft.

	<p><b>Propeller shaft housing puller . ①</b> YB-06502 / 90890-06502</p>
	<p><b>Universal puller..... ②</b> YB-06540 / 90890-06540</p>

	<p><b>Universal puller</b> 10 Nm (1.0 m • kgf, 7.2 ft • lb)</p>
--	---






(3) Install the backlash indicator onto the drive shaft (on the 22.4 mm (0.88 in) diameter portion of the drive shaft (a)).

	<b>Backlash indicator</b> ..... ③ <b>YB-06265 / 90890-06706</b>
---	--

(4) Install the dial gauge onto the lower unit and have the dial gauge plunger contact the mark on the backlash indicator.

	<b>Magnetic-base plate</b> ..... ④ <b>YB-07003 / 90890-07003</b>
	<b>Dial gauge set</b> ..... ⑤ <b>YU-03097 / 90890-01252</b>
	<b>Magnetic base</b> ..... ⑥ <b>YU-34481 / 90890-06705</b>


(5) Set the lower unit upside down.  
 (6) Slowly turn the drive shaft clockwise and counterclockwise. When the drive shaft stops in each direction, measure the backlash.



2. Adjust:  
 • Front gear shim  
 Remove or add shim(s).

 Front gear backlash	Shim thickness
Less than 0.19 mm (0.007 in)	To be decreased by $(0.39 - M) \times 0.50$
More than 0.59 mm (0.023 in)	To be increased by $(M - 0.39) \times 0.50$
 Available shim thickness	0.10, 0.12, 0.15, 0.18, 0.30, 0.40 and 0.50 mm

M: Measurement




**MEASURING THE REAR GEAR BACKLASH**

1. Measure:

- Rear gear backlash
- Out of specification → Adjust.



**Rear gear backlash**  
0.39 - 0.70 mm (0.015 - 0.027 in)




**Measuring steps**

(1) Set the shift rod into the neutral position.



**Shift rod wrench**  
YB-06052 / 90890-06052




(2) Install the propeller shaft housing puller so it pushes against the outer propeller shaft.



**Propeller shaft housing puller . ①**  
YB-06502 / 90890-06502  
**Propeller shaft housing puller extension..... ②**  
YB-06513 / 90890-06513  
**Universal puller..... ③**  
YB-06540 / 90890-06540



**Universal puller**  
10 Nm (1.0 m • kgf, 7.2 ft • lb)



(3) Install the backlash indicator onto the drive shaft (on the 22.4 mm (0.88 in) diameter portion of the drive shaft (a)).




**Backlash indicator** ..... (4)  
**YB-06265 / 90890-06706**

(4) Install the dial gauge onto the lower unit and have the dial gauge plunger contact the mark on the backlash indicator.



**Magnetic-base plate** ..... (5)  
**YB-07003 / 90890-07003**  
**Dial gauge set** ..... (6)  
**YU-03097 / 90890-01252**  
**Magnetic base** ..... (7)  
**YU-34481 / 90890-06705**

(5) Set the lower unit upside down.  
 (6) Slowly turn the drive shaft clockwise and counterclockwise. When the drive shaft stops in each direction, measure the backlash.



**2. Adjust:**

- Rear gear backlash  
 Remove or add shim(s).

 Rear gear backlash	Shim thickness
Less than 0.39 mm (0.015 in)	To be increased by $(0.55 - M) \times 0.50$
More than 0.70 mm (0.027 in)	To be decreased by $(M - 0.55) \times 0.50$
 Available shim thickness	0.10, 0.12, 0.15, 0.18, 0.30, 0.40 and 0.50 mm

M: Measurement



## CHAPTER 7 BRACKET UNIT

<b>BOTTOM COWLING</b> .....	7-1
REMOVING/INSTALLING THE BOTTOM COWLING .....	7-1
DISASSEMBLING/ASSEMBLING THE BOTTOM COWLING (FOR PRE-MIX MODELS, EXCEPT FOR 225DET).....	7-3
DISASSEMBLING/ASSEMBLING THE BOTTOM COWLING (FOR OIL INJECTION MODELS, AND 225DET).....	7-5
<b>SHIFT ROD ASSEMBLY</b> .....	7-8
DISASSEMBLING/ASSEMBLING THE SHIFT ROD ASSEMBLY .....	7-8
<b>UPPER CASE ASSEMBLY</b> .....	7-10
REMOVING/INSTALLING THE UPPER CASE ASSEMBLY .....	7-10
DISASSEMBLING/ASSEMBLING THE UPPER CASE ASSEMBLY .....	7-11
<b>EXHAUST MANIFOLD ASSEMBLY</b> .....	7-14
DISASSEMBLING/ASSEMBLING THE EXHAUST MANIFOLD ASSEMBLY.....	7-14
<b>CLAMP BRACKETS</b> .....	7-16
REMOVING/INSTALLING THE CLAMP BRACKETS.....	7-16
<b>STEERING ARM</b> .....	7-18
REMOVING/INSTALLING THE STEERING ARM.....	7-18
<b>SWIVEL BRACKET ASSEMBLY</b> .....	7-19
DISASSEMBLING/ASSEMBLING THE SWIVEL BRACKET ASSEMBLY.....	7-19
<b>POWER TRIM AND TILT UNIT</b> .....	7-21
REMOVING/INSTALLING THE POWER TRIM AND TILT UNIT .....	7-21
REMOVING THE POWER TRIM AND TILT UNIT .....	7-22
BLEEDING THE POWER TRIM AND TILT UNIT .....	7-22

**RESERVOIR AND POWER TRIM AND TILT MOTOR** ..... 7-24

    REMOVING/INSTALLING THE RESERVOIR AND POWER TRIM  
    AND TILT MOTOR..... 7-24

    INSPECTING THE RESERVOIR..... 7-25

    INSPECTING THE GEAR PUMP HOUSING FILTER ..... 7-25

    INSTALLING THE POWER TRIM AND TILT MOTOR..... 7-26

    FILLING THE RESERVOIR..... 7-27

    BLEEDING THE POWER TRIM AND TILT UNIT ..... 7-27

    MEASURING THE HYDRAULIC PRESSURE ..... 7-29

**TILT RAM ASSEMBLY AND GEAR PUMP UNIT** ..... 7-32

    REMOVING/INSTALLING THE TILT RAM ASSEMBLY AND  
    GEAR PUMP UNIT ..... 7-32

    REMOVING THE TILT RAM END SCREW ..... 7-34

    REMOVING THE GEAR PUMP UNIT ..... 7-34

    DISASSEMBLING THE GEAR PUMP UNIT ..... 7-34

    INSPECTING THE TILT RAM..... 7-35

    INSPECTING THE GEAR PUMP UNIT ..... 7-35

    ASSEMBLING THE GEAR PUMP UNIT ..... 7-36

    INSTALLING THE GEAR PUMP UNIT..... 7-37

    INSTALLING THE TILT RAM ASSEMBLY ..... 7-37

**TRIM RAM ASSEMBLIES AND FREE PISTON** ..... 7-39

    REMOVING/INSTALLING THE TRIM RAM ASSEMBLIES AND  
    FREE PISTON ..... 7-39

    REMOVING THE TRIM RAM END SCREWS ..... 7-40

    REMOVING THE FREE PISTON..... 7-40

    INSPECTING THE TRIM RAMS..... 7-41


    INSPECTING THE FREE PISTON..... 7-41

    INSPECTING THE TRIM RAM CYLINDERS ..... 7-41

    INSTALLING THE FREE PISTON..... 7-41


    INSTALLING THE TRIM RAMS ..... 7-42

**BOTTOM COWLING  
REMOVING/INSTALLING THE BOTTOM COWLING**



Order	Job/Part	Q'ty	Remarks
	Power unit		Refer to "POWER UNIT" on page 5-4.
1	Shift rod assembly	1	
2	Bolt	1	
3	Holder	1	
4	Bolt	2	
5	Bracket	1	
6	Battery lead	2	
7	Hose guide	1	

Continued on next page.




Order	Job/Part	Q'ty	Remarks
8	Power trim and tilt lead	1	
9	Trim sensor lead	1	
10	Bolt	4	
11	Ground lead	1	
12	Speedometer hose	1	
13	Flushing hose	1	Salt water models
14	Bottom cowling	1	

For installation, reverse the removal procedure.


**A** Pre-mix models, except for 225DET

**DISASSEMBLING/ASSEMBLING THE BOTTOM COWLING  
(FOR PRE-MIX MODELS, EXCEPT FOR 225DET)**




Order	Job/Part	Q'ty	Remarks
1	Bolt	3	
2	Clamp lever	3	
3	Bushing	6	
4	Hook	3	
5	Wave washer	3	
6	Pilot water hose	1	
7	Pilot water outlet	1	
8	Cable holder	2	
9	Bolt	2	

Continued on next page.




Order	Job/Part	Q'ty	Remarks
10	Fuel hose holder	2	
11	Bolt	1	
12	Fuel hose holder	1	
13	Bolt	1	
14	Ground lead	1	
15	Grommet	4	
16	Collar	4	
17	Bottom cowling	1	
			For assembly, reverse the disassembly procedure.

**DISASSEMBLING/ASSEMBLING THE BOTTOM COWLING  
(FOR OIL INJECTION MODELS, AND 225DET)**




Order	Job/Part	Q'ty	Remarks
1	Bolt	3	
2	Lower spring holder	3	
3	Spring	3	
4	Bolt	3	
5	Upper spring holder	3	
6	Wave washer	3	
7	Set pin	3	
8	Bushing	6	
9	Clamp lever	3	

Continued on next page.



Order	Job/Part	Q'ty	Remarks
10	Pilot water hose	1	
11	Pilot water outlet	1	
12	Wire harness clamp	1	
13	Bolt	1	
14	Cable holder	1	
15	Choke link guide	1	
16	Bolt	1	
17	Cable guide	1	
18	Bolt	2	


Continued on next page.




Order	Job/Part	Q'ty	Remarks
19	Trailer switch holder	1	
20	Trailer switch	1	
21	Bolt	1	
22	Ground lead	1	
23	Grommet	4	
24	Collar	4	
25	Bottom cowling	1	
			For assembly, reverse the disassembly procedure.

**SHIFT ROD ASSEMBLY**

**DISASSEMBLING/ASSEMBLING THE SHIFT ROD ASSEMBLY**




Order	Job/Part	Q'ty	Remarks
1	Screw	1	
2	Spring	1	
3	Ball	1	
4	Clip	1	
5	Shift rod lever	1	
6	Clip	1	
7	Bushing	1	
			Continued on next page.




Order	Job/Part	Q'ty	Remarks
8	Shift rod lever bracket	1	
9	Rubber seal	1	
10	Circlip	1	
11	Shift rod bracket	1	
12	Bushing	1	
13	Shift rod	1	
			For assembly, reverse the disassembly procedure.

**UPPER CASE ASSEMBLY  
REMOVING/INSTALLING THE UPPER CASE ASSEMBLY**




Order	Job/Part	Q'ty	Remarks
	Lower unit		Refer to "LOWER UNIT (REGULAR ROTATION MODELS)" on page 6-1.
	Bottom cowling		Refer to "BOTTOM COWLING" on page 7-1.
1	Bolt	1	
2	Ground lead	1	(upper case-to-swivel bracket)
3	Screw	2	
4	Lower mount cover	2	
5	Cap nut	2	
6	Self-locking nut	2	
7	Upper case assembly	1	
8	Rubber seal	1	
			For installation, reverse the removal procedure.

**DISASSEMBLING/ASSEMBLING THE UPPER CASE ASSEMBLY**




Order	Job/Part	Q'ty	Remarks
1	Bolt	3	
2	Upper mount bracket	1	
3	Upper mount	2	
4	Bolt	2	
5	Bolt	4	
6	Lower mount bracket	2	
7	Spring	2	
8	Lower mount	2	

Continued on next page.




Order	Job/Part	Q'ty	Remarks
9	Ground lead	1	
10	Bolt	2	
11	Bolt	2	
12	Bolt	2	
13	Muffler assembly	1	
14	Rubber seal	1	
15	Muffler	1	X transom models
16	Rubber seal	1	X transom models
17	Rubber seal	1	X transom models

Continued on next page.




Order	Job/Part	Q'ty	Remarks
18	Upper case	1	
19	Dowel pin	2	
20	Circlip	1	X transom models
21	Bushing	1	X transom models
For assembly, reverse the disassembly procedure.			

## EXHAUST MANIFOLD ASSEMBLY DISASSEMBLING/ASSEMBLING THE EXHAUST MANIFOLD ASSEMBLY




Order	Job/Part	Q'ty	Remarks
1	Bolt	5	
2	Muffler	1	
3	Gasket	1	<b>Not reusable</b>
4	Water tube	1	
5	Water seal	1	
6	Bolt	4	
7	Exhaust manifold	1	
8	Gasket	1	<b>Not reusable</b>
9	Bolt	4	

Continued on next page.




Order	Job/Part	Q'ty	Remarks
10	Lower exhaust manifold guide	1	
11	Gasket	1	<b>Not reusable</b>
12	Upper exhaust manifold guide	1	
13	Plastic locking tie	1	<b>Not reusable</b> Salt water models
14	Flushing hose	1	Salt water models
15	Plastic locking tie	1	<b>Not reusable</b>
16	Cooling water hose	1	
			For assembly, reverse the disassembly procedure.

**CLAMP BRACKETS**  
**REMOVING/INSTALLING THE CLAMP BRACKETS**




Order	Job/Part	Q'ty	Remarks
	Upper case assembly		Refer to "UPPER CASE ASSEMBLY" on page 7-10.
1	Rubber cap	3	
2	Grease nipple	3	
3	Ground lead	1	
4	Bolt	4	
5	Ground lead	1	
6	Anode bracket	2	
7	Anode	1	
8	Trim sensor	1	

Continued on next page.



Order	Job/Part	Q'ty	Remarks
9	Self-locking nut	1	For installation, reverse the removal procedure.
10	Bolt	2	
11	Clamp bracket bolt	1	
12	Starboard clamp bracket	1	
13	Port clamp bracket	1	
14	Bushing	2	
15	Swivel bracket assembly	1	


**STEERING ARM  
REMOVING/INSTALLING THE STEERING ARM**



Order	Job/Part	Q'ty	Remarks
	Upper case assembly		Refer to "UPPER CASE ASSEMBLY" on page 7-10.
1	Circlip	1	
2	Steering arm yoke	1	
3	Washer	1	
4	Washer	1	
5	O-ring	1	
6	Steering arm	1	
7	Washer	1	
8	Bushing	2	
9	Swivel bracket assembly	1	
			For installation, reverse the removal procedure.


**SWIVEL BRACKET ASSEMBLY**

**DISASSEMBLING/ASSEMBLING THE SWIVEL BRACKET ASSEMBLY**



Order	Job/Part	Q'ty	Remarks
	Steering arm		Refer to "STEERING ARM" on page 7-18.
1	Nut	2	
2	Trim stopper	2	
3	Bolt	1	
4	Spring holder	1	
5	Spring	1	
6	Pin	2	


Continued on next page.



Order	Job/Part	Q'ty	Remarks
7	Starboard tilt stop lever	1	For assembly, reverse the disassembly procedure.
8	Port tilt stop lever	1	
9	Bushing	2	
10	Bushing	2	
11	Tilt stop lever joint assembly	1	

**POWER TRIM AND TILT UNIT**

**REMOVING/INSTALLING THE POWER TRIM AND TILT UNIT**




Order	Job/Part	Q'ty	Remarks
	Tilt up the outboard		
1	Power trim and tilt lead	2	
2	Plastic locking tie	3	<b>Not reusable</b>
3	Ground lead	1	
4	Circlip	3	
5	Upper mounting pin	1	
6	Lower mounting pin	1	
7	Power trim and tilt unit	1	
8	Collar	6	
			For installation, reverse the removal procedure.

**REMOVING THE POWER TRIM AND TILT UNIT**

**⚠ WARNING**

After tilting up the outboard, be sure to support it with the tilt stop levers. Otherwise, the outboard could suddenly lower if the power trim and tilt unit should lose fluid pressure.



**NOTE:** Tilt up the outboard and then turn the tilt stop levers ① to support it.

- Remove:
- Power trim and tilt unit

**NOTE:** Slightly lower the tilt ram assembly and then remove the power trim and tilt unit.


**BLEEDING THE POWER TRIM AND TILT UNIT**



**NOTE:** Install the power trim and tilt unit onto the outboard before bleeding.

- Bleed:
- Air bubbles (from the power trim and tilt unit)

**Bleeding steps**

- (1) Connect the battery leads to the battery.
- (2) Loosen the manual valve ① by turning it counterclockwise until it stops.






- (3) Tilt up the outboard fully, then release it, and let it lower by its own weight.
- (4) Tighten the manual valve by turning it clockwise.
- (5) Let the power trim and tilt fluid settle for about 5 minutes.
- (6) Push and hold the power trim and tilt switch in the up position until the outboard is fully tilted up.
- (7) Turn the tilt stop levers to support the outboard. Then, let the power trim and tilt fluid settle for about 5 minutes.
- (8) Remove the reservoir cap ② and check that fluid is up to the brim as shown. Add fluid if the level is below the brim.
- (9) Install the power trim and tilt reservoir cap.
- (10) Repeat the above steps two or three times until the power trim and tilt fluid is at the correct level.

**RESERVOIR AND POWER TRIM AND TILT MOTOR**

**REMOVING/INSTALLING THE RESERVOIR AND POWER TRIM AND TILT MOTOR**



Order	Job/Part	Q'ty	Remarks
	Power trim and tilt unit		Refer to "POWER TRIM AND TILT UNIT" on page 7-21.
1	Reservoir cap	1	
2	Bolt	3	
3	Reservoir	1	
4	Bolt	4	
5	Power trim and tilt motor	1	
6	O-ring	1	
7	Drive pin	1	
8	Gear pump housing filter	1	
			For installation, reverse the removal procedure.

**⚠ WARNING**

- To prevent the hydraulic fluid from spurt-  
ing out due to internal pressure, the out-  
board should be kept fully tilted up (the  
tilt rod at full length).
- After removing the power trim and tilt  
motor or reservoir, do not push the tilt  
ram down. This may cause hydraulic fluid  
to spurt out from the port.

**CAUTION:**


Do not wipe hydraulic system components  
with rags, paper, tissues, or the like, as  
fibers from such material will cause mal-  
functions if they enter the system.

**INSPECTING THE RESERVOIR**

1. Drain:
  - Power trim and tilt fluid
2. Inspect:
  - Reservoir  
Cracks/damage/leaks → Replace.

**INSPECTING THE GEAR PUMP  
HOUSING FILTER**

- Inspect:
- Gear pump housing filter  
Damage/tears → Replace.  
Foreign matter → Clean.




## INSTALLING THE POWER TRIM AND TILT MOTOR

1. Install:
  - Gear pump housing filter ①
  - Drive pin ②
2. Fill:
  - Gear pump housing




**Recommended power trim and tilt fluid**  
ATF Dexron II

**NOTE:** \_\_\_\_\_  
Add power trim and tilt fluid until it reaches the top of the gear pump housing.



3. Bleed:
  - Air bubbles

**NOTE:** \_\_\_\_\_  
• Remove all of the air bubbles with a syringe or suitable tool as shown.  
• Turn the gear pump gears with a screwdriver and then remove any air between the gear teeth.



4. Install:
  - O-ring ①
  - Power trim and tilt motor ②
  - Bolt ③

**NOTE:** \_\_\_\_\_  
Align the armature shaft with the recess in the drive pin.




## FILLING THE RESERVOIR

### ⚠ WARNING

To prevent the hydraulic fluid from spurt-  
ing out due to internal pressure, the tilt  
ram should be kept at full length.

1. Fill:
  - Reservoir



**Recommended power trim and  
tilt fluid**  
ATF Dexron II

2. Inspect:
  - Power trim and tilt fluid level  
Level is low → Add power trim and tilt  
fluid to the proper level.

## BLEEDING THE POWER TRIM AND TILT UNIT

### NOTE:

This bleeding must be done before install-  
ing the power trim and tilt unit onto the out-  
board.

1. Bleed:
  - Air bubbles  
(from the power trim and tilt unit)



### Bleeding steps

- (1) Set the power trim and tilt unit upright.
- (2) Connect the leads of the power trim and tilt on the battery terminals until the trim and tilt ram assemblies are fully compressed.


### NOTE:

If the rams will not go down, refer to the fol-  
lowing.


- A. Connect the leads of the power trim and tilt on the battery terminals until the trim and tilt ram assemblies are fully extended. Then, reverse the leads on the battery terminals until the trim and tilt ram assemblies are fully compressed.



- B. If step A was unsuccessful, connect the leads on the battery terminals and fully compress the tilt ram assembly by hand.
- C. If step B was unsuccessful, loosen the manual valve, compress the trim and tilt ram assemblies fully by hand, and then tighten the manual valve. Then, compress and extend the trim and tilt ram assemblies by connecting the leads on the battery terminals in the up and down positions.
- D. If step C was unsuccessful, disassemble, check, and correct any problems with the power trim and tilt unit.



- (3) Connect the leads on the battery terminals in the up position until the trim and tilt ram assemblies are fully extended.



- (4) Remove the power trim and tilt reservoir cap and inspect that fluid is up to the brim as shown. Add power trim and tilt fluid if the level is below the brim.
- (5) Repeat the above steps two or three times until the fluid is at the correct level.

**2. Inspect:**

- Power trim and tilt unit operation  
Unsmooth operation → Bleed the power trim and tilt unit again.

**MEASURING THE HYDRAULIC PRESSURE**



Inspect:

- Hydraulic pressure
- Out of specification → Repair.

	<b>Hydraulic pressure</b>
	<b>(with the power trim and tilt ram assemblies fully extended)</b>
	<b>9.8 - 11.8 MPa</b> <b>(100 - 120 kg/cm<sup>2</sup>)</b>
	<b>(with the power trim and tilt ram assemblies fully compressed)</b>
	<b>5.9 - 8.8 MPa (60 - 90 kg/cm<sup>2</sup>)</b>

**NOTE:** \_\_\_\_\_

Before measuring the hydraulic pressure, bleed the power trim and tilt unit.



**Measuring steps**


- (1) Fully tilt up the power trim and tilt ram assemblies.
- (2) Remove the circlip ①.
- (3) Remove the manual valve ② and install the up-relief valve attachment and hydraulic pressure gauge and tighten them to the specified torque.

	<b>Up-relief valve attachment..... ③</b>
	<b>90890-06773</b>
	<b>Hydraulic pressure gauge..... ④</b>
	<b>90890-06776</b>


	<b>Hydraulic pressure gauge</b>
	<b>9 Nm (0.9 m • kgf, 6.5 ft • lb)</b>
	<b>Up-relief valve attachment</b>
	<b>4 Nm (0.4 m • kgf, 2.9 ft • lb)</b>

**NOTE:** \_\_\_\_\_

Remove the manual valve and then quickly attach the special tools before any fluid comes out.




- (4) Connect the leads on the battery terminals in the down position until the power trim and tilt ram assemblies are fully compressed.



- (5) Connect the leads on the battery terminals in the up position until the power trim and tilt ram assemblies are fully extended. Then, measure the hydraulic pressure.



**Hydraulic pressure  
(with the power trim and tilt ram  
assemblies fully extended)**  
9.8 - 11.8 MPa  
(100 - 120 kg/cm<sup>2</sup>)




- (6) After measuring the hydraulic pressure, remove the special tools and quickly attach the down-relief valve attachment.



**Hydraulic pressure gauge ..... ④**  
90890-06776  
**Down-relief valve attachment. ⑤**  
90890-06774





**Hydraulic pressure gauge**  
9 Nm (0.9 m • kgf, 6.5 ft • lb)  
**Down-relief valve attachment**  
4 Nm (0.4 m • kgf, 2.9 ft • lb)



- (7) Remove the reservoir cap and check that fluid is up to the brim as shown. Add fluid if the level is below the brim.  
(8) Install the reservoir cap.  
(9) Connect the leads on the battery terminals in the down position until the power trim and tilt ram assemblies are fully compressed. Then, measure the hydraulic pressure.



**Hydraulic pressure  
(with the power trim and tilt ram  
assemblies fully compressed)**  
5.9 - 8.8 MPa (60 - 90 kg/cm<sup>2</sup>)



(10) After measuring the hydraulic pressure, connect the leads on the battery terminals in the up position until the power trim and tilt ram assemblies are fully extended.

(11) Remove the special tools.


(12) Install the manual valve and circlip.

**NOTE:** \_\_\_\_\_

After measuring the hydraulic pressure, bleed the power trim and tilt unit.


\_\_\_\_\_

**TILT RAM ASSEMBLY AND GEAR PUMP UNIT  
REMOVING/INSTALLING THE TILT RAM ASSEMBLY AND GEAR PUMP UNIT**




Order	Job/Part	Q'ty	Remarks
	Reservoir and power trim and tilt motor		Refer to "RESERVOIR AND POWER TRIM AND TILT MOTOR" on page 7-24.
1	Manual valve	1	
2	Tilt ram end screw	1	
3	Tilt ram assembly	1	
4	O-ring	2	
5	Bolt	3	
6	Gear pump unit	1	

Continued on next page.



Order	Job/Part	Q'ty	Remarks
7	Check valve assembly	1	For installation, reverse the removal procedure.
8	Gear pump	1	
9	Shuttle valve	2	
10	Check valve	2	
11	Up-relief valve assembly	1	
12	Down-relief valve assembly	1	



## REMOVING THE TILT RAM END SCREW

Loosen:


- Tilt ram end screw



**End screw wrench**  
YB-06548 / 90890-06548

### NOTE:

Hold the power trim and tilt unit in a vise using aluminum plates on both sides.




## REMOVING THE GEAR PUMP UNIT

Remove:

- Bolt ①
- Gear pump unit ②
- O-ring ③
- Check valve ④

### NOTE:

Place a container under the power trim and tilt unit.




## DISASSEMBLING THE GEAR PUMP UNIT

1. Remove:

- Bolt ①
- Pump gear ②
- Up-relief valve assembly ③
- Ball (4.76 mm/0.187 in) ④
- Shuttle valve ⑤
- Ball (3.18 mm/0.125 in) ⑥

### NOTE:

When removing the pump gears, note their original direction and position for proper assembly.



2. Remove:

- Check valves ① and ②


**NOTE:** \_\_\_\_\_

To remove the check valves, cover the gear pump housing with a clean cloth and then blow compressed air through holes ① and ②.

### INSPECTING THE TILT RAM

Inspect:

- Tilt ram  
Excessive scratches → Replace.  
Bends/excessive corrosion → Replace.  
Rust → Polish.  
(with 400 - 600 grit sandpaper)



### INSPECTING THE GEAR PUMP UNIT

Inspect:


- Shuttle valves ①
- Check valve assemblies ②  
Clogs/damage/wear → Replace.
- Pump gears ③  
Damage/wear → Replace the gear pump unit.
- Up-relief valve assembly ④
- Down-relief valve assembly ⑤  
Damage/wear → Replace the gear pump unit.
- Balls ⑥  
Damage/wear → Replace.

**ASSEMBLING THE GEAR PUMP UNIT**

**CAUTION:** \_\_\_\_\_

Install all components in their original direction and position for proper assembly and operation.

---




1. Install:
- Balls (3.18 mm/0.125 in) ①
  - Shuttle valves ②


**NOTE:** \_\_\_\_\_

Apply grease to the balls to prevent them from falling out of the gear pump.


---



2. Install:
- O-ring ①
  - Ball (3.18 mm/0.125 in) ②
  - Up-relief valve pin ③
  - Spring ④
  - Up-relief valve ⑤
  - Up-relief valve assembly ⑥



3. Install:
- O-rings ①
  - Check valves ②
  - Balls (4.76 mm/0.187 in) ③
  - Pump gears ④




4. Install:
- Gear pump ①
  - Bolt ②
  - Filter ③
  - O-ring ④
  - Down-relief valve ⑤
  - Filter ⑥

**NOTE:** \_\_\_\_\_

Tighten the bolts evenly and make sure the pump gears turn smoothly.

---




### INSTALLING THE GEAR PUMP UNIT

#### 1. Install:

- O-rings ①
- Ball ②
- Pin ③
- Check valve ④
- Check valve assembly ⑤

#### NOTE:

When installing the check valve assembly, make sure the pin is on the tilt ram cylinder side as shown.



#### 2. Install:

- Gear pump unit ①
- Bolt ②

### INSTALLING THE TILT RAM ASSEMBLY

#### ⚠ WARNING


To prevent the hydraulic fluid from spurt-ing out due to internal pressure, the tilt ram should be kept at full length.

#### 1. Fill:

- Tilt ram cylinder




**Recommended power trim and  
tilt fluid  
ATF Dexron II**



#### NOTE:

Hold the power trim and tilt unit in a vise using aluminum plates on both sides.



## 2. Fill:


- Gear pump housing



**Recommended power trim and tilt fluid**  
ATF Dexron II

**NOTE:**

Add power trim and tilt fluid through the hole ① until the fluid level is to the top of the gear pump unit.




## 3. Install:

- Tilt ram assembly

**NOTE:**

Place the tilt ram end screw at the bottom of the tilt ram and install the tilt ram assembly into the tilt ram cylinder.



## 4. Tighten:

- Tilt ram end screw




**End screw wrench**  
YB-06548 / 90890-06548




**Tilt ram end screw**  
130 Nm (13 m • kgf, 94 ft • lb)

**TRIM RAM ASSEMBLIES AND FREE PISTON**

**REMOVING/INSTALLING THE TRIM RAM ASSEMBLIES AND FREE PISTON**



Order	Job/Part	Q'ty	Remarks
	Tilt ram assembly and gear pump unit		Refer to "TILT RAM ASSEMBLY AND GEAR PUMP UNIT" on page 7-32.
1	Trim ram end screw	2	
2	Trim ram	2	
3	O-ring	2	
4	Seal ring	2	
5	Free piston	1	
6	O-ring	1	
7	Piston ring	1	
			For installation, reverse the removal procedure.



## REMOVING THE TRIM RAM END SCREWS

Loosen:

- Trim ram end screw



**End screw wrench**  
YB-06175-1A / 90890-06548

**A** For USA and Canada

**B** Except for USA and Canada

### NOTE:

Hold the power trim and tilt unit in a vise using aluminum plates on both sides.


## REMOVING THE FREE PISTON

1. Drain:

- Power trim and tilt fluid

### NOTE:

After removing the trim ram assemblies, drain the fluid from the power trim and tilt unit.



2. Install:


- Trim ram assemblies ①

### NOTE:

Finger-tighten the trim ram assemblies and then cover the tilt cylinder openings with a clean cloth.

3. Remove:

- Free piston ②



### **⚠ WARNING**

**Never look into the tilt cylinder opening because the free piston and hydraulic fluid may be expelled out forcefully.**

### NOTE:

Remove the free piston by blowing compressed air through the hole ②.

**INSPECTING THE TRIM RAMS**

Inspect:

- Trim ram  
Excessive scratches → Replace.  
Bends/excessive corrosion → Replace.  
Rust → Polish.  
(with 400 - 600 grit sandpaper)

**INSPECTING THE FREE PISTON**

Inspect:

- Free piston  
Excessive scratches → Replace.

**INSPECTING THE TRIM RAM CYLINDERS**

Inspect:


- Trim ram cylinder  
Cracks/excessive scratches →  
Replace the power trim and tilt unit.

**INSTALLING THE FREE PISTON**

1. Fill:


- Fluid passages

	<p><b>Recommended power trim and tilt fluid</b> <b>ATF Dexron II</b> <b>Quantity</b> <b>30 cm<sup>3</sup> (1.0 US oz, 1.1 Imp oz)</b></p>
---	---



**NOTE:** \_\_\_\_\_

- Hold the power trim and tilt unit in a vise using aluminum plates on both sides.
- Add power trim and tilt fluid through the hole Ⓐ.



2. Install:

- Piston ring ①
- O-ring ②
- Free piston ③

**NOTE:** \_\_\_\_\_

Push the free piston into the trim ram cylinder until it bottoms out.


## INSTALLING THE TRIM RAMS

### ⚠ WARNING \_\_\_\_\_

Do not push the trim rams down while installing them into the trim ram cylinders. Otherwise, the hydraulic fluid may spurt out from the unit.

1. Fill:

- Trim ram cylinders




**Recommended power trim and tilt fluid**  
**ATF Dexron II**

**NOTE:** \_\_\_\_\_

Hold the power trim and tilt unit in a vise using aluminum plates on both sides.

2. Fill:


- Fluid passages



**Recommended power trim and tilt fluid**  
**ATF Dexron II**

**NOTE:** \_\_\_\_\_

Add power trim and tilt fluid through holes ①, ② and ③ until all of the passages are filled.




**3. Install:**

- Trim ram assemblies ①

**NOTE:**

Place each trim ram end screw at the bottom of each trim ram and install them into the trim ram cylinders.



**4. Tighten:**

- Trim ram end screw

	<b>End screw wrench</b> <b>YB-06175-1A / 90890-06548</b>
---	---

	<b>Trim ram end screw</b> <b>80 Nm (8.0 m • kgf, 58 ft • lb)</b>
---	---

**A** For USA and Canada

**B** Except for USA and Canada



## CHAPTER 8 ELECTRICAL SYSTEMS

<b>ELECTRICAL COMPONENTS</b>	
<b>(OIL INJECTION AND 225DET MODELS)</b> .....	8-1
(Port view) .....	8-1
(Starboard view) .....	8-2
(Aft view) .....	8-3
<b>ELECTRICAL COMPONENTS</b>	
<b>(PRE-MIX EXCEPT FOR 225DET MODELS)</b> .....	8-4
(Port view) .....	8-4
(Starboard view) .....	8-5
(Aft view) .....	8-6
<b>ELECTRICAL COMPONENTS ANALYSIS</b> .....	
DIGITAL CIRCUIT TESTER.....	8-7
MEASURING THE PEAK VOLTAGE.....	8-7
PEAK VOLTAGE ADAPTOR.....	8-7
MEASURING A LOW RESISTANCE.....	8-8
<b>IGNITION SYSTEM (OIL INJECTION AND 225DET MODELS)</b> .....	8-9
<b>IGNITION SYSTEM (PRE-MIX EXCEPT FOR 225DET MODELS)</b> .....	8-10
INSPECTING THE IGNITION SPARK GAP.....	8-11
MEASURING THE IGNITION SYSTEM PEAK VOLTAGE .....	8-12
INSPECTING THE SPARK PLUG CAPS .....	8-15
<b>IGNITION CONTROL SYSTEM</b>	
<b>(OIL INJECTION AND 225DET MODELS)</b> .....	8-16
<b>IGNITION CONTROL SYSTEM</b>	
<b>(PRE-MIX EXCEPT FOR 225DET MODELS)</b> .....	8-17
MEASURING THE CRANK POSITION SENSOR OUTPUT PEAK VOLTAGE .....	8-18
MEASURING THE ENGINE COOLING WATER TEMPERATURE SENSOR RESISTANCE .....	8-18
INSPECTING THE THERMO SWITCH CONTINUITY.....	8-19
INSPECTING THE OIL LEVEL SENSOR CONTINUITY .....	8-19
INSPECTING THE EMERGENCY SWITCH.....	8-20

**STARTING SYSTEM**..... 8-21

- INSPECTING THE BATTERY ..... 8-22
- INSPECTING THE FUSES ..... 8-22
- INSPECTING THE WIRE HARNESS CONTINUITY ..... 8-22
- INSPECTING THE WIRE CONNECTIONS ..... 8-22
- INSPECTING THE STARTER RELAY ..... 8-23
- MEASURING THE FUEL ENRICHMENT VALVE..... 8-23

**STARTER MOTOR**..... 8-24

- DISASSEMBLING/ASSEMBLING THE STARTER MOTOR..... 8-24
- REMOVING THE STARTER MOTOR PINION ..... 8-27
- INSPECTING THE STARTER MOTOR PINION ..... 8-27
- INSPECTING THE ARMATURE ..... 8-27
- MEASURING THE BRUSHES ..... 8-28

**CHARGING SYSTEM**..... 8-30

- INSPECTING THE RECTIFIER/REGULATOR..... 8-31
- MEASURING THE LIGHTING COIL OUTPUT PEAK VOLTAGE ..... 8-32
- INSPECTING THE FUSES ..... 8-32
- INSPECTING THE BATTERY ..... 8-32


**POWER TRIM AND TILT SYSTEM** ..... 8-33

- INSPECTING THE FUSES ..... 8-34
- INSPECTING THE BATTERY ..... 8-34
- INSPECTING THE POWER TRIM AND TILT RELAY..... 8-34
- INSPECTING THE TRAILER SWITCH CONTINUITY ..... 8-35
- MEASURING THE TRIM SENSOR RESISTANCE..... 8-36

**POWER TRIM AND TILT MOTOR**..... 8-37

- DISASSEMBLING/ASSEMBLING THE POWER TRIM AND TILT MOTOR..... 8-37
- REMOVING THE STATOR ..... 8-39
- REMOVING THE BRUSH ..... 8-39
- INSPECTING THE BRUSH ..... 8-39
- INSPECTING THE ARMATURE ..... 8-40
- INSTALLING THE BRUSH ..... 8-41
- INSTALLING THE ARMATURE ..... 8-41
- INSTALLING THE STATOR ..... 8-41

**ELECTRICAL COMPONENTS (OIL INJECTION AND 225DET MODELS)  
(Port view)**




- ① Oil level sensor
- ② Starter motor
- ③ Power trim and tilt relay
- ④ Starter relay
- ⑤ Trailer switch
- ⑥ Fuse (30A)
- ⑦ Fuse (20A)

- A** To trim meter
- B** To battery
- C** To CDI unit
- D** To CDI unit and 10P coupler
- E** To power trim and tilt motor
- F** To trim sensor

- B** : Black
- Br** : Brown
- G** : Green
- L** : Blue
- Lg** : Light green
- R** : Red
- Sb** : Sky blue

**(Starboard view)**




- ① Charge coil lead
- ② Lighting coil lead
- ③ Pulser coil lead
- ④ Fuel enrichment valve
- ⑤ Terminal (for USA)
- ⑥ Fuse (30A)
- ⑦ Rectifier/regulator
- ⑧ Thermo switch
- ⑨ Fuel hose
- ⑩ Oil hose


- ⑪ Shift cable
- ⑫ Throttle cable
- ⑬ Speedometer hose

- A** To trim sensor
- B** To relay assembly
- C** To battery
- D** To trim meter and tachometer
- E** To remote oil tank
- F** To remote control
- G** To CDI unit
- H** To CDI unit
- I** To thermo switch and emergency switch

- B** : Black
- G** : Green
- L** : Blue
- P** : Pink
- R** : Red
- Gy/B** : Gray/black



**(Aft view)**




- ① Thermo switch
- ② Ignition coil
- ③ Emergency switch
- ④ Crank position sensor
- ⑤ CDI unit
- ⑥ Engine cooling water temperature sensor

- [A] To charge coil
- [B] To wire harness
- [C] To 10P coupler
- [D] To pulser coil
- [E] To relay assembly
- [F] To oil level sensor

- B : Black
- G : Green
- L : Blue
- P : Pink
- B/W : Black/white
- Gy/B : Gray/black

**ELECTRICAL COMPONENTS (PRE-MIX EXCEPT FOR 225DET MODELS)  
(Port view)**




- ① Starter motor
- ② Power trim and tilt relay
- ③ Starter relay
- ④ Fuse (20A)

- A To trim meter
- B To battery
- C To CDI unit and 10P coupler
- D To power trim and tilt motor
- E To trim sensor

- B : Black
- Br : Brown
- G : Green
- L : Blue
- Lg : Light green
- R : Red
- Sb : Sky blue


**(Starboard view)**




- ① Fuel enrichment valve
- ② Thermo switch
- ③ Rectifier/regulator
- ④ Charge coil lead
- ⑤ Lighting coil lead
- ⑥ Pulser coil lead
- ⑦ Fuel hose
- ⑧ Speedometer hose
- ⑨ Shift cable
- ⑩ Throttle cable

- A** To relay assembly
- B** To trim sensor
- C** To battery
- D** To remote control
- E** To trim meter
- F** To CDI unit
- G** To CDI unit
- H** To thermo switch

- B** : Black
- G** : Green
- L** : Blue
- O** : Orange
- P** : Pink
- R** : Red
- Gy/B** : Gray/black





**(Aft view)**



- ① Thermo switch
- ② Ignition coil
- ③ CDI unit

- A** To charge coil
- B** To wire harness
- C** To pulser coil
- D** To 10P coupler
- E** To relay assembly

- B** : Black
- P** : Pink
- B/W** : Black/white
- Gy/B** : Gray/black



## ELECTRICAL COMPONENTS ANALYSIS

### DIGITAL CIRCUIT TESTER



**Digital tester**  
J-39299 / 90890-06752


#### NOTE:

"○—○" indicates a continuity of electricity which means a closed circuit at the respective switch position.

## MEASURING THE PEAK VOLTAGE

#### NOTE:

- When checking the condition of the ignition system it is useful to know the peak voltage.
- Cranking speed is dependant on many factors (e.g., fouled or weak spark plugs, a weak battery). If one of these is defective, the peak voltage will be lower than specification.
- If the peak voltage measurement is not within specification the engine will not operate properly.





## PEAK VOLTAGE ADAPTOR

#### NOTE:


The peak voltage adaptor should be used with the digital circuit tester.



**Peak voltage adaptor**  
YU-39991 / 90890-03169

**NOTE:**

- When measuring the peak voltage, set the selector to the DC voltage mode.
- Make sure the peak voltage adaptor leads are properly installed in the digital tester.
- Make sure the positive pin (the “+” mark facing up as shown) on the peak voltage adaptor is installed into the positive terminal of the digital tester.
- The test harness is needed for the following tests.

**Measuring steps**

- (1) Disconnect the coupler connections.
- (2) Connect the test harness between the couplers.
- (3) Connect the peak voltage adaptor probes to the connectors which are being checked.
- (4) Start or crank the engine and observe the measurement.

**MEASURING A LOW RESISTANCE**

When measuring a resistance of  $10 \Omega$  or less with the digital tester, the correct measurement cannot be obtained because of the tester's internal resistance.


To obtain the correct value, subtract the internal resistance from the displayed measurement.




**Correct value**  
**Displayed measurement –**  
**internal resistance**

**NOTE:**

The internal resistance of the digital tester can be obtained by connecting both of its probes.




**IGNITION SYSTEM (OIL INJECTION AND 225DET MODELS)**




- ① Spark plugs
- ② Ignition coils
- ③ Charge coil
- ④ Pulser coil
- ⑤ CDI unit

- B : Black
- Br : Brown
- L : Blue
- R : Red
- W : White

- B/R : Black/red
- B/W : Black/white
- W/Br : White/brown
- W/G : White/green
- W/R : White/red
- W/Y : White/yellow









**IGNITION SYSTEM (PRE-MIX EXCEPT FOR 225DET MODELS)**



- ① Spark plugs
- ② Ignition coils
- ③ Charge coil
- ④ Pulser coil
- ⑤ CDI unit

- B : Black
- Br : Brown
- L : Blue
- R : Red
- W : White
- B/R : Black/red
- B/W : Black/white

- W/B : White/black
- W/Br : White/brown
- W/G : White/green
- W/L : White/blue
- W/R : White/red
- W/Y : White/yellow



## INSPECTING THE IGNITION SPARK GAP

### ⚠ WARNING

- Do not touch any of the connections of the spark gap tester lead wires.
- Do not let sparks leak out of the removed spark plug cap.
- Keep flammable gas or liquids away, since this test can produce sparks.

Inspect:

- Ignition spark gap  
Above specification → Replace the spark plug.  
Below specification → Inspect the CDI unit output.



**Ignition spark gap**  
9 mm (0.4 in)



### Inspecting steps

- (1) Remove the spark plugs from the engine.
- (2) Connect a spark plug cap to the spark gap tester.
- (3) Set the spark gap length on the adjusting knob.



**Spark gap tester**  
YM-34487 / 90890-06754

- (4) Crank the engine and observe the spark through the discharge window of the spark gap tester.



## MEASURING THE IGNITION SYSTEM PEAK VOLTAGE

### ⚠ WARNING

When checking the peak voltage do not touch any of the connections of the digital tester lead wires.

### NOTE:

- If there is no spark or the spark is weak, continue with the ignition system test.
- If a good spark is obtained, the problem is not with the ignition system, but possibly with the spark plug(s) or another component.

### 1. Measure:



- CDI unit output peak voltage  
Above specification → Replace the ignition coil.  
Below specification → Measure the charge coil output peak voltage.

<b>CDI unit output peak voltage (oil injection and 225DET models)</b> <b>Black/white (B/W) – Black (B)</b>				
r/min	Circuit	Loaded		
		Cranking	1,500	3,500
V	—	130	145	145

### NOTE:

With the oil injection and 225DET models, the CDI unit output peak voltage for cylinders #2 and #5 is "0" at either cranking or 1,500 r/min.

<b>CDI unit output peak voltage (pre-mix except for 225DET models)</b> <b>Black/white (B/W) – Black (B)</b>				
r/min	Circuit	Loaded		
		Cranking	1,500	3,500
V	—	65	140	135



**2. Measure:**

- Charge coil output peak voltage  
 Above specification → Measure the pulser coil output peak voltage.  
 Below specification → Replace the charge coil.

 **Charge coil output peak voltage (oil injection and 225DET models)**  
 Red (R) – Brown (Br)

r/min	Circuit	Loaded	
	Cranking	1,500	3,500
<b>V</b>	<b>140</b>	<b>160</b>	<b>165</b>

**Black/red (B/R) – Blue (L)**

r/min	Circuit	Loaded	
	Cranking	1,500	3,500
<b>V</b>	<b>40</b>	<b>55</b>	<b>165</b>

 **Test harness (4-pin)**  
 YB-38831 / 90890-06771



 **Charge coil output peak voltage (pre-mix except for 225DET models)**  
 Red (R) – Brown (Br)

r/min	Circuit	Loaded	
	Cranking	1,500	3,500
<b>V</b>	<b>80</b>	<b>90</b>	<b>165</b>

**Black/red (B/R) – Blue (L)**

r/min	Circuit	Loaded	
	Cranking	1,500	3,500
<b>V</b>	<b>30</b>	<b>30</b>	<b>160</b>

 **Test harness (4-pin)**  
 YB-38831 / 90890-06771




**3. Measure:**

- Pulser coil output peak voltage  
Above specification → Replace the CDI unit.  
Below specification → Replace the pulser coil.

<b>Pulser coil output peak voltage (oil injection and 225DET models)</b> White/red (W/R) – White/green (W/G) White/yellow (W/Y) – White/brown (W/Br)				
r/min	Circuit	Loaded		
	Cranking	1,500	3,500	
V	3.0	2.0	8.0	14



	<b>Test harness (4-pin)</b> YB-38831 / 90890-06771
--	---



<b>Pulser coil output peak voltage (pre-mix except for 225DET models)</b> White/red (W/R) – White/green (W/G) White/black (W/B) – White/blue (W/L) White/yellow (W/Y) – White/brown (W/Br)				
r/min	Circuit	Loaded		
	Cranking	1,500	3,500	
V	2.5	2.0	9.5	16

	<b>Test harness (6-pin)</b> YB-38832 / 90890-06772
--	---

- A** Oil injection and 225DET models
- B** Pre-mix except for 225DET models




### INSPECTING THE SPARK PLUG CAPS

#### 1. Inspect:

- Spark plug cap  
Loose connection → Tighten.  
Cracks/damage → Replace.



#### Replacement steps (oil injection and 225DET models)

- (1) To remove the spark plug cap turn it counterclockwise.
- (2) To install the spark plug cap turn it clockwise until it is tight.



#### Replacement steps (pre-mix except for 225DET models)

- (1) Remove the spark plug cap off of the lead.
- (2) Remove the spark plug cap spring.
- (3) Strip the insulation cover 5 mm (0.2 in) (a) and spread the core wires outward.
- (4) Fit the spark plug cap spring close to the spread core wires and bend the end of the spring around the lead.
- (5) Install the spark plug cap spring into the spark plug cap.




#### 2. Measure:

- (oil injection and 225DET models)
- Spark plug cap resistance  
Out of specification → Replace.



**Spark plug cap resistance**  
4.0 - 6.0 kΩ

**IGNITION CONTROL SYSTEM (OIL INJECTION AND 225DET MODELS)**




- ① Emergency switch
- ② Thermo switch
- ③ Crank position sensor
- ④ Engine cooling water temperature sensor
- ⑤ Oil level sensor (except for 225DET)
- ⑥ CDI unit

**A** To the trim sensor



- B : Black
- L : Blue
- P : Pink
- B/Y : Black/yellow
- Gy/B : Gray/black
- L/G : Blue/green
- L/R : Blue/red
- L/W : Blue/white

**IGNITION CONTROL SYSTEM (PRE-MIX EXCEPT FOR 225DET MODELS)**



① Thermo switch  
 ② CDI unit

B : Black  
 P : Pink  
 Gy/B : Gray/black



**MEASURING THE CRANK POSITION SENSOR OUTPUT PEAK VOLTAGE**

Measure:

- Crank position sensor output peak voltage

Below specification → Replace.



**Crank position sensor output peak voltage**  
Green (G) – Green (G)

r/min	Circuit	Loaded		
	Cranking	1,500	3,500	
V	3.0	2.0	5.5	6.0

**MEASURING THE ENGINE COOLING WATER TEMPERATURE SENSOR RESISTANCE**

Measure:


- Engine cooling water temperature sensor resistance

Out of specification → Replace.







**Engine cooling water temperature sensor resistance**  
Black/yellow (B/Y) –  
Black/yellow (B/Y)

5 °C (41 °F): 128 kΩ  
20 °C (68 °F): 54 - 69 kΩ  
100 °C (212 °F): 3.02 - 3.48 kΩ



**Measuring steps**

- (1) Place the engine cooling water temperature sensor in a container filled with water.
- (2) Place a thermometer in the water.
- (3) Slowly heat the water.
- (4) Measure the resistance when the specified temperature is reached.



**INSPECTING THE THERMO SWITCH CONTINUITY**

Inspect:

- Thermo switch continuity
- Out of specification → Replace.



**Thermo switch continuity temperature**

**Pink (P) – Black (B)**

- Ⓐ 84 - 90 °C (183 - 194 °F)
- Ⓑ 60 - 74 °C (140 - 165 °F)

- ① No continuity      Ⓐ Temperature
- ② Continuity        Ⓑ Time

**Measuring steps**

- (1) Place the thermo switch in a container filled with water.
- (2) Place a thermometer in the water.
- (3) Slowly heat the water.
- (4) Measure the continuity when the specified temperature is reached.

**INSPECTING THE OIL LEVEL SENSOR CONTINUITY**

Inspect:



- Oil level sensor continuity
- Out of specification → Replace.

Float position	Lead color			
	Black (B)	Blue/white (L/W)	Blue/green (L/G)	Blue/red (L/R)
Ⓐ ON	○—○			
Ⓐ OFF				
Ⓑ ON	○		○	
Ⓑ OFF				
Ⓒ ON	○			○
Ⓒ OFF				



**Float distance**

- Ⓐ: 3 - 6 mm (0.12 - 0.24 in)
- Ⓑ: 33 - 36 mm (1.30 - 1.42 in)
- Ⓒ: 53 - 56 mm (2.09 - 2.20 in)



**INSPECTING THE EMERGENCY SWITCH**

1. Inspect:


- Emergency switch continuity  
Out of specification → Replace.

	Switch position	Lead color
		Blue (L) – Black (B)
	Home (a)	No continuity
	On (b)	Continuity

2. Inspect:

- Emergency switch  
Does not automatically return to the home position → Replace.


**STARTING SYSTEM**



- ① Fuse (20A)
- ② Fuse (30A)
- ③ Fuel enrichment valve
- ④ Starter motor
- ⑤ Battery
- ⑥ Starter relay


- B : Black
- Br : Brown
- L : Blue
- R : Red

- A** Oil injection and 225DET models
- B** Pre-mix except for 225DET models



## INSPECTING THE BATTERY

Refer to "INSPECTING THE BATTERY" on page 3-20.



## INSPECTING THE FUSES

### 1. Inspect:

- Fuse holder continuity

No continuity → Check the fuse holder leads.

### 2. Inspect:

- Fuse holder lead continuity

No continuity → Replace the fuse holder.

Continuity → Inspect the fuse.

### 3. Inspect:

- Fuse continuity

No continuity → Replace.

- Fuse rating

Out of specification → Replace.



**Fuse rating**  
12 V - 20, 30 A

## INSPECTING THE WIRE HARNESS CONTINUITY

### Inspect:

- Wire harness continuity



No continuity → Replace.

## INSPECTING THE WIRE CONNECTIONS

### Inspect:

- Wire connections

Poor connection → Properly connect.




**INSPECTING THE STARTER RELAY**

1. Inspect:
  - Brown lead terminal
  - Black lead terminal
 Poor connection → Properly connect.
2. Inspect:
  - Starter relay continuity
 No continuity → Replace.


**Inspecting steps**

(1) Connect the tester and battery between the starter relay terminals.



**Positive digital tester probe ① → Starter relay terminal**  
**Negative digital tester probe ② → Starter relay terminal**  
**Positive battery terminal → Brown lead ③**  
**Negative battery terminal → Black lead ④**


(2) Inspect that there is continuity between the starter relay terminals.




**MEASURING THE FUEL ENRICHMENT VALVE**

- Measure:
- Fuel enrichment valve resistance
- Out of specification → Replace.



**Fuel enrichment valve resistance**  
**Blue (L) – Black (B)**  
**3.4 ~ 4.0 Ω at 20 °C (68 °F)**



**STARTER MOTOR**  
**DISASSEMBLING/ASSEMBLING THE STARTER MOTOR**





Order	Job/Part	Q'ty	Remarks
	Starter motor		Refer to "RELAY ASSEMBLY AND STARTER MOTOR" on page 5-16.
1	Bolt	2	
2	Starter motor bracket	1	
3	Clip	1	
4	Starter motor pinion stopper	1	
5	Spring	1	
6	Starter motor pinion	1	
			Continued on next page.





Order	Job/Part	Q'ty	Remarks
7	Bolt	2	
8	Upper cover	1	
9	O-ring	1	
10	Washer	2	
11	Lower bracket	1	
12	O-ring	1	
13	Stator	1	
14	Armature	1	

Continued on next page.



Order	Job/Part	Q'ty	Remarks
15	Metal plate	1	
16	Nut	1	
17	O-ring	1	
18	Screw	2	
19	Brush assembly	1	
20	Spring	3	
21	Brush holder	1	
			For assembly, reverse the disassembly procedure.




### REMOVING THE STARTER MOTOR PINION

Remove:

- Clips ①

#### NOTE:

Slide the pinion stopper ① down as shown and then remove the clip ②.



### INSPECTING THE STARTER MOTOR PINION

1. Inspect:


- Starter motor pinion teeth  
Damage/wear → Replace.

2. Inspect:

- Starter motor pinion movement  
Incorrect → Replace.

#### NOTE:

Rotate the starter motor pinion clockwise and make sure it moves smoothly. Also, rotate the starter motor pinion counter-clockwise and make sure it locks.




### INSPECTING THE ARMATURE

1. Inspect:



- Commutator  
Foreign matter → Clean.  
(with 600 grit sandpaper)

2. Measure:


- Commutator diameter  
Out of specification → Replace.



**Commutator diameter limit**  
31.0 mm (1.22 in)




3. Inspect:
- Commutator undercut  
Dirt/foreign matter → Clean.  
(with compressed air)




4. Measure:
- Commutator undercut (a)  
Out of specification → Replace the armature.

	<b>Commutator undercut limit</b> 0.2 mm (0.01 in)
--	--



5. Inspect:
- Armature continuity  
Out of specification → Replace.



Armature continuity	
<b>Commutator segments (a)</b>	<b>Continuity</b>
<b>Segment – Armature core (b)</b>	<b>No continuity</b>
<b>Segment – Armature shaft (c)</b>	<b>No continuity</b>



**MEASURING THE BRUSHES**

1. Measure:
- Brush length (a)  
Out of specification → Replace the brush assembly.

	<b>Brush length limit</b> 12.0 mm (0.47 in)
--	--




2. Inspect:

- Brush assembly continuity  
Out of specification → Replace the brush assembly.

 <b>Brush assembly continuity</b>	
<b>Brush ① – Brush ②</b>	<b>Continuity</b>
<b>Brush ① – Brush ③</b> <b>Brush ② – Brush ③</b> <b>Brush holder ④ –</b> <b>Brush assembly holder ⑤</b>	<b>No continuity</b>


**CHARGING SYSTEM**



- ① Rectifier/regulator
- ② Lighting coil
- ③ Battery
- ④ Fuses (20A, 30A)
- ⑤ Battery lead terminal


- B : Black
- G : Green
- R : Red
- G/W : Green/white

- A** Oil injection and 225DET models
- B** Pre-mix except for 225DET models



**INSPECTING THE RECTIFIER/REGULATOR**

1. Inspect:  
 (oil injection and 225DET models)  
 • Rectifier/regulator continuity  
 Out of specification → Replace.




<b>Rectifier/regulator continuity</b>			
	① Black (B)	② Green (G)	③ Red (R)
① Black (B)		○	○
② Green (G)	∞		○
③ Red (R)	∞	∞	

○ : Continuity  
 ∞ : No continuity




**NOTE:** \_\_\_\_\_  
 There are three green and one red terminal. The resistance between black and each of these terminals is the same.

2. Inspect:  
 (pre-mix except for 225DET models)  
 • Rectifier/regulator continuity



<b>Rectifier/regulator continuity</b>				
	① Green (G1)	② Green (G2)	③ Red (R)	④ Black (B)
① Green (G1)		○	○	○
② Green (G2)	∞		○	∞
③ Red (R)	∞	∞		∞
④ Black (B)	○	○	○	

○ : Continuity  
 ∞ : No continuity



**MEASURING THE LIGHTING COIL OUTPUT PEAK VOLTAGE**

Measure:

- Lighting coil output peak voltage  
Above specification → Replace the rectifier/regulator.  
Below specification → Replace the lighting coil.

	<b>Lighting coil output peak voltage (oil injection and 225DET models)</b> Green (G) – Green (G)		
r/min	Circuit	Loaded	
	Cranking	1,500	3,500
V	—	35	85

	<b>Test harness (3-pin)</b> YB-06770 / 90890-06770
--	---

	<b>Lighting coil output peak voltage (pre-mix except for 225DET models)</b> Green/white (G/W) – Green (G)		
r/min	Circuit	Loaded	
	Cranking	1,500	3,500
V	—	20	50


- A** Oil injection and 225DET models
- B** Pre-mix except for 225DET models

**INSPECTING THE FUSES**


Refer to “INSPECTING THE FUSES” on page 8-22.

**INSPECTING THE BATTERY**

Refer to “INSPECTING THE BATTERY” on page 3-20.




**POWER TRIM AND TILT SYSTEM**



- ① Power trim and tilt motor
- ② Power trim and tilt relay
- ③ Trailer switch
- ④ Fuse (20A)
- ⑤ Fuse (30A)
- ⑥ Battery
- ⑦ Trim sensor

- A** To remote control
- B** Pre-mix except for 225DET models
- C** Oil injection and 225DET models
- D** To trim meter

- B : Black
- G : Green
- Gy : Gray
- L : Blue
- Lg : Light green
- O : Orange
- P : Pink
- R : Red
- Sb : Sky blue
- Gy/B: Gray/black




**INSPECTING THE FUSES**

Refer to “INSPECTING THE FUSES” on page 8-22.

**INSPECTING THE BATTERY**

Refer to “INSPECTING THE BATTERY” on page 3-20.



**INSPECTING THE POWER TRIM AND TILT RELAY**

1. Inspect:


- Power trim and tilt relay assembly continuity
- Out of specification → Inspect the power trim and tilt relay continuity.



<b>Power trim and tilt relay assembly continuity</b>	
Sky blue (Sb) – Black (B) Light green (Lg) – Black (B)	<b>Continuity</b>

2. Inspect:

- Power trim and tilt relay continuity
- Out of specification → Replace.

<b>Power trim and tilt relay continuity</b>	
Sky blue (Sb) lead – Black (B) lead Light green (Lg) lead – Black (B) lead	<b>Continuity</b>
Sky blue (Sb) lead – Terminal ① Light green (Lg) lead – Terminal ①	<b>Continuity</b>
Sky blue (Sb) lead – Terminal ② Light green (Lg) lead – Terminal ②	<b>No continuity</b>
Terminal ① – Terminal ③	<b>Continuity</b>
Terminal ② – Terminal ③	<b>No continuity</b>





3. Inspect:

- Power trim and tilt relay operation  
No continuity → Replace.


**Inspecting steps**

- (1) Connect the tester between the power trim and tilt relay terminals.
- (2) Connect a 12-V battery as shown.

**Sky blue (Sb) lead → Positive terminal**  
**Black (B) lead → Negative terminal**

**Light green (Lg) lead → Positive terminal**  
**Black (B) lead → Negative terminal**

- (3) Check that there is continuity between the power trim and tilt relay terminals.





**INSPECTING THE TRAILER SWITCH CONTINUITY**

Inspect:

- Trailer switch continuity  
Out of specification → Replace.

Switch position	Lead color		
	Sky blue (Sb)	Red (R)	Light green (Lg)
Up	○ — ○		
Free			
Down		○ — ○	



### MEASURING THE TRIM SENSOR RESISTANCE

Measure:

- Trim sensor resistance

Out of specification → Replace.



#### Trim sensor resistance

Pink (P) – Black (B)

582 - 873  $\Omega$  at 20 °C (68 °F)

Orange (O) – Black (B)


800 - 1,200  $\Omega$  at 20 °C (68 °F)

#### NOTE:

Turn the lever ① and measure the resistance as it gradually changes.



**POWER TRIM AND TILT MOTOR**

**DISASSEMBLING/ASSEMBLING THE POWER TRIM AND TILT MOTOR**





Order	Job/Part	Q'ty	Remarks
	Power trim and tilt motor		Refer to "RESERVOIR AND POWER TRIM AND TILT MOTOR" on page 7-24.
1	Screw	1	
2	Lead holder	1	
3	Screw	2	
4	Stator	1	
5	Armature	1	
6	O-ring	1	
7	Screw	2	

Continued on next page.



Order	Job/Part	Q'ty	Remarks
8	Brush holder	2	For assembly, reverse the disassembly procedure.
9	Brush	2	
10	Spring	2	
11	Lower cover	1	
12	Oil seal	1	
13	Bearing	1	



## REMOVING THE STATOR

Remove:


- Stator ①

### CAUTION:

- Keep the power trim and tilt motor leads inside the stator.
- Do not allow grease or oil to contact the commutator.

### NOTE:

- Remove the lead holder ② and rubber spacer ③ from the stator and slide them towards the leads.
- Hold the end of the armature shaft with a clean cloth and pull off the stator.




## REMOVING THE BRUSH

1. Remove:

- Sky blue power trim and tilt motor lead ①

### NOTE:

Hold the brush with a screwdriver as shown. Then, disconnect the sky blue lead.




2. Remove:

- Brush holders ①
- Brushes ②

### CAUTION:

Do not touch the bimetal ①; touching it may affect the operation of the breaker.





## INSPECTING THE BRUSH

1. Measure:

- Brush length ①
- Out of specification → Replace.




**Brush length**  
4.8 mm (0.19 in)



2. Inspect:
- Brush continuity  
No continuity → Replace.

**CAUTION:**


**Do not touch the bimetal (a); touching it may affect the operation of the breaker.**



**INSPECTING THE ARMATURE**


1. Measure:
- Commutator diameter (a)  
Out of specification → Replace.

	<b>Commutator diameter limit</b> 21.0 mm (0.83 in)
--	---




2. Measure:
- Commutator undercut (a)  
Out of specification → Replace the armature.



	<b>Commutator undercut limit</b> 0.85 mm (0.03 in)
--	---



3. Inspect:
- Armature continuity  
Out of specification → Replace.

<b>Armature continuity</b>	
<b>Commutator segments</b>	<b>Continuity</b>
<b>Segment-laminations</b>	<b>No continuity</b>
<b>Segment-shaft</b>	<b>No continuity</b>






### INSTALLING THE BRUSH

Install:

- Brushes ①
- Brush holders ②
- Power trim and tilt motor leads ③
- Screw ④

#### CAUTION:

Do not touch the bimetal; touching it may affect the operation of the breaker.




### INSTALLING THE ARMATURE

Install:

- Armature ①

#### NOTE:

Push the brushes into the holder and then install the armature.



### INSTALLING THE STATOR

Install:

- Stator ①

#### NOTE:

Place a clean cloth over the end of the armature shaft and carefully push the armature into the stator with a pair of pliers as shown.

---

## CHAPTER 9 TROUBLE ANALYSIS

<b>TROUBLE ANALYSIS</b> .....	9-1
TROUBLE ANALYSIS CHART .....	9-1
<b>SELF-DIAGNOSIS</b> .....	9-4
DIAGNOSIS CODE INDICATION .....	9-4
DIAGNOSIS THE ELECTRONIC CONTROL SYSTEM .....	9-4

**TROUBLE ANALYSIS**

**NOTE:**

The following items should be checked before the "TROUBLE ANALYSIS CHART" is consulted.




1. The battery is charged and its specified gravity is within specification.
2. There are no incorrect wiring connections.
3. Wiring connections are properly secured and are not rusty.
4. The lanyard is installed onto the engine stop switch.
5. The shift position is in neutral.
6. Fuel is reaching the carburetor.
7. The rigging and engine setting are correct.
8. The engine is free from any "Hull problem".

**TROUBLE ANALYSIS CHART**

Trouble mode														Check elements			
ENGINE WILL NOT START	HARD STARTING	ROUGH IDLING	HIGH IDLING	ENGINE STALLS	POOR ACCELERATION	ENGINE WILL NOT STOP	POOR PERFORMANCE	LIMITED ENGINE SPEED	OVERHEATING	LOOSE STEERING	LOOSE TILT HOLDING	TILT MOTOR WILL NOT RUN	HARD SHIFTING	IRREGULAR WARNING INDICATION	POOR BATTERY CHARGING	Relative part	Reference chapter
														<b>FUEL SYSTEM</b>			
<input type="radio"/>				<input type="radio"/>			<input type="radio"/>									Fuel line	3
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>					<input type="radio"/>									Fuel filter	3
<input type="radio"/>							<input type="radio"/>									Fuel joint	4
<input type="radio"/>							<input type="radio"/>									Fuel pumps	4
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>			<input type="radio"/>		<input type="radio"/>									Carburetors	4
		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>			<input type="radio"/>									• Idle speed	3
		<input type="radio"/>	<input type="radio"/>				<input type="radio"/>									• Link adjustment	3
				<input type="radio"/>				<input type="radio"/>								• Pilot screw setting	4
														<b>POWER UNIT</b>			
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>					<input type="radio"/>									Compression	3
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>												Reed valves	5
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>					<input type="radio"/>		<input type="radio"/>							Cylinder head gaskets	5
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>			<input type="radio"/>											Seal	5
<input type="radio"/>							<input type="radio"/>									Cylinder block	5
<input type="radio"/>							<input type="radio"/>									Crankcase	5
<input type="radio"/>							<input type="radio"/>									Piston rings	5
<input type="radio"/>							<input type="radio"/>									Pistons	5
							<input type="radio"/>									Bearings	5

Trouble mode													Check elements				
ENGINE WILL NOT START	HARD STARTING	ROUGH IDLING	HIGH IDLING	ENGINE STALLS	POOR ACCELERATION	ENGINE WILL NOT STOP	POOR PERFORMANCE	LIMITED ENGINE SPEED	OVERHEATING	LOOSE STEERING	LOOSE TILT HOLDING	TILT MOTOR WILL NOT RUN	HARD SHIFTING	IRREGULAR WARNING INDICATION	POOR BATTERY CHARGING	Relative part	Reference chapter
									<input type="radio"/>							Thermostat	5
									<input type="radio"/>							Water passages	5
<b>LOWER UNIT</b>																	
<input type="radio"/>				<input type="radio"/>									<input type="radio"/>			Neutral position	6
<input type="radio"/>													<input type="radio"/>			Dog clutch	6
<input type="radio"/>				<input type="radio"/>									<input type="radio"/>			Gears	6
									<input type="radio"/>							Water inlets	6
									<input type="radio"/>							Water pump	6
							<input type="radio"/>									Propeller shaft(s)	6
													<input type="radio"/>			Shift rod joint/pin	6
													<input type="radio"/>			Shift cam	6
													<input type="radio"/>			Shift shaft	6
						<input type="radio"/>							<input type="radio"/>			Lower case	6
<b>BRACKET UNIT</b>																	
									<input type="radio"/>							Bracket	7
									<input type="radio"/>							Rubber mount	7
													<input type="radio"/>			Shift rod	7
<b>POWER TRIM AND TILT UNIT</b>																	
											<input type="radio"/>					Fluid level	3
											<input type="radio"/>					Relief valve	7
											<input type="radio"/>					Fluid passages	—
												<input type="radio"/>				Power trim and tilt motor	7
<b>ELECTRICAL</b>																	
<b>Ignition system</b>																	
<input type="radio"/>			<input type="radio"/>					<input type="radio"/>	<input type="radio"/>							• Charge coil	8
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>	<input type="radio"/>		<input type="radio"/>									• Pulser coils	8
<input type="radio"/>			<input type="radio"/>			<input type="radio"/>	<input type="radio"/>	<input type="radio"/>								• CDI unit	8
<input type="radio"/>	<input type="radio"/>				<input type="radio"/>	<input type="radio"/>	<input type="radio"/>									• Ignition coils	8
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>							• Spark plugs	3
<b>Ignition control system</b>																	
<input type="radio"/>					<input type="radio"/>											• Lanyard switch	—
		<input type="radio"/>	<input type="radio"/>		<input type="radio"/>											• Crank position sensor	8
	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>													• Engine cooling water temperature sensor	8

Trouble mode													Check elements				
ENGINE WILL NOT START	HARD STARTING	ROUGH IDLING	HIGH IDLING	ENGINE STALLS	POOR ACCELERATION	ENGINE WILL NOT STOP	POOR PERFORMANCE	LIMITED ENGINE SPEED	OVERHEATING	LOOSE STEERING	LOOSE TILT HOLDING	TILT MOTOR WILL NOT RUN	HARD SHIFTING	IRREGULAR WARNING INDICATION	POOR BATTERY CHARGING	Relative part	Reference chapter
								<input type="radio"/>	<input type="radio"/>							• Thermo switch	8
								<input type="radio"/>						<input type="radio"/>		• Oil level sensor (engine oil tank)	8
<b>Starting system</b>																	
<input type="radio"/>	<input type="radio"/>					<input type="radio"/>										• Engine start switch	—
<input type="radio"/>																• Starter relay	8
<input type="radio"/>																• Starter motor	8
<b>Charging system</b>																	
															<input type="radio"/>	• Lighting coil	8
															<input type="radio"/>	• Rectifier/regulator	8
															<input type="radio"/>	• Fuses	8
<input type="radio"/>		<input type="radio"/>		<input type="radio"/>											<input type="radio"/>	• Battery leads	—
<input type="radio"/>													<input type="radio"/>	<input type="radio"/>	• Battery	—	
<b>Power trim and tilt system</b>																	
												<input type="radio"/>				• Trailer switch	8
												<input type="radio"/>				• Power trim and tilt relay	8
														<input type="radio"/>		• Trim sensor	8



## SELF-DIAGNOSIS DIAGNOSIS CODE INDICATION

1. Normal condition  
(no defective part or irregular processing is found)
2. Single flash is given every 5 seconds.
  - Ⓐ : Light on, 0.3 second
  - Ⓑ : Light off, 5 seconds

3. Trouble code indication  
Example: The illustration indicates code number 23.
  - Ⓐ : Light on, 0.3 second
  - Ⓑ : Light off, 0.3 second
  - Ⓒ : Light off, 1.7 seconds
  - Ⓓ : Light off, 5 seconds


## DIAGNOSIS THE ELECTRONIC CONTROL SYSTEM

1. Install:
  - Diagnostic indicator



**NOTE:** \_\_\_\_\_  
When performing this diagnosis, all of the electrical wires must be properly connected.  
\_\_\_\_\_

2. Inspect:
  - Diagnosis code  
Code 1 is indicated → Normal.  
Code 12 - 21 indicated → Check the applicable parts.  
Code 33 - 44 indicated → Replace the CDI unit.



**Inspecting steps**

- (1) Start the engine and let it idle.
- (2) Check the diagnostic indicator's flash pattern to determine if there are any malfunctions.

**NOTE:**

When more than one problem is detected, the diagnostic tester's light flashes in the pattern of the lowest numbered problem. After that problem is corrected, the light flashes in the pattern of the next lowest numbered problem. This continues until all of the problems are detected and corrected.

**Diagnosis code chart**

Code	Symptoms
12	Incorrect charge coil input signal
13	Incorrect pulser coil input signal
14	No crank position sensor input signal
15	Incorrect engine cooling water temperature sensor input signal
33 ~ 44	Microcomputer processing information
(33)	Ignition timing is being slightly corrected (when starting a cold engine)
(41)	Overrevolution control (during ignition cutoff operation)
(42)	Overheat control/oil empty control
(43)	Buzzer sounding
(44)	Engine stop switch control operating




# WIRING DIAGRAM

150FETO, S150FETO, L150FETO, LS150FETO, 150GETO, D150HETO, 175DETO, S175DETO, 175FETO, 200FETO, S200FETO, L200FETO, LS200FETO, 200GETO, 225DET, 225DETO/  
150TR, S150TR, L150TR, P150TR, D150TR, S175TR, P175TR, 200TR, S200TR, L200TR, P200TR

## COLOR CODE

- B : Black
- Br : Brown
- G : Green
- Gy : Gray
- L : Blue
- Lg : Light green
- O : Orange
- P : Pink
- R : Red
- Sb : Sky blue
- W : White
- Y : Yellow
- B/R : Black/red
- B/W : Black/white
- B/Y : Black/yellow
- G/B : Green/black
- G/R : Green/red
- Gy/B : Gray/black
- L/G : Blue/green
- L/R : Blue/red
- L/W : Blue/white
- W/Br : White/brown
- W/G : White/green
- W/R : White/red
- W/Y : White/yellow





# YAMAHA

YAMAHA MOTOR CO., LTD.

Printed in USA

Oct. 1998 - × 1 CR

(150AET, L150AET, 150FETO, L150FETO, 150GETO, D150HETO, 175AET, 175DETO, 175FETO,  
200AET, L200AET, 200FETO, L200FETO, 200GETO, 225DET, 225DETO)

(英)

Printed on recycled paper