

**YAMAHA**

**SJ700AU**

**Service Manual**

LIT-18616-01-43

---

## PREFACE

This manual has been prepared by the Yamaha Motor Company Ltd. primarily for use by Yamaha dealers and their trained mechanics when performing maintenance procedures and repairs to Yamaha equipment. It has been written to suit the needs of persons who have a basic understanding of the mechanical and electrical concepts and procedures inherent in the work, for without such knowledge attempted repairs or service to the equipment could render it unsafe or unfit for use.

Because the Yamaha Motor Company Ltd. has a policy of continuously improving its products, models may differ in detail from the descriptions and illustrations given in this publication. Use only the latest edition of this manual. Authorized Yamaha dealers are notified periodically of modifications and significant changes in specifications and procedures, and these are incorporated in successive editions of this manual.

A10001-0\*

**SJ700AU  
SERVICE MANUAL**

**©1996 by Yamaha Motor Co., Ltd.**

**1st Edition, January 1996**

**All rights reserved.**

**No part of this publication may be reproduced or transmitted in any form or by any means including photocopying and recording without the written permission of the copyright holder.**

**Such written permission must also be obtained before any part of this publication is stored in a retrieval system of any nature.**

**Printed in U.S.A.  
LIT-18616-01-43**

---

**WARNINGS, CAUTIONS AND NOTES**

Attention is drawn to the various Warnings, Cautions and Notes which distinguish important information in this manual in the following ways.

 The Safety Alert Symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!

---

** WARNING**

Failure to follow **WARNING** instructions could result in severe injury or death to the machine operator, a bystander, or a person inspecting or repairing the water vehicle.

---

---

**CAUTION:**

A **CAUTION** indicates special precautions that must be taken to avoid damage to the water vehicle.

---

---

**NOTE:**

A **NOTE** provides key information to make procedures easier or clearer.

---

## HOW TO READ DESCRIPTIONS

1. A disassembly installation job mainly consists of the exploded diagram ①.
2. The numerical figures represented by the number ② indicates the order of the job steps.
3. The symbols represented by the number ③ indicates the contents and notes of the job.  
For the meanings of the symbols, refer to the next page(s).
4. The REMOVAL AND INSTALLATION CHART ④ is attached to the exploded diagram and explains the job steps, part names, notes for the jobs, etc.
5. The SERVICE POINTS, other than the exploded diagram, explains in detail the items difficult to explain in the exploded diagram or REMOVAL AND INSTALLATION CHART, the Service points requiring the detailed description ⑤, etc.

**JET PUMP**

**DEFLECTOR, NOZZLE AND DUCT**

**E**

**DEFLECTOR, NOZZLE AND DUCT  
EXPLODED DIAGRAM**

**④** → **REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
	<b>DEFLECTOR, NOZZLE AND DUCT REMOVAL</b>		Follow the left "Step" for removal.
	Jet pump unit		Refer to "JET PUMP UNIT REMOVAL".
② → 1	Nozzle deflector assembly	1	<div style="text-align: right;"> <b>⑤</b> →           </div>
2	Bolt	4	
3	Housing	1	
4	Pin	2	
5	Impeller duct assembly	1	
6	Pin	1	
7	Nozzle	1	
			Reverse the removal steps for installation.

6-2

---

## HOW TO USE THIS MANUAL

### MANUAL FORMAT

All of the procedures in this manual are organized in a sequential, step-by-step format. The information has been compiled to provide the mechanic with an easy to read, handy reference that contains comprehensive explanations of all disassembly, repair, assembly, and inspection operations.

In this revised format, the condition of a faulty component will precede an arrow symbol and the course of action required will follow the symbol, e.g.,

- Bearings  
Pitting/Damage → Replace.

To assist you to find your way about this manual, the Section Title and Major Heading is given at the head of every page.

An Index to contents is provided on the first page of each Section.

### MODEL INDICATION

Multiple models are shown in this manual. These indications are noted as follows.



Model name	Super Jet
	SJ700A
Indication	SJ700A

### THE ILLUSTRATIONS

Some illustrations in this manual may differ from the model you have. This is because a procedure described may relate to several models, though only one may be illustrated. (The name of model described will be mentioned in the description).

### REFERENCES

These have been kept to a minimum; however, when you are referred to another section of the manual, you are told the page number to go to.

① GEN INFO 	② SPEC 
③ INSP ADJ 	④ FUEL 
⑤ POWR 	⑥ JET PUMP 
⑦ ELEC 	⑧ HULL HOOD 
⑨ TRBL ANLS ? 	⑩ 
⑪ 	⑫ 
⑬ 	⑭ 
⑮ 	⑯ 
⑰ 	⑱ 
⑲ 	⑳ 
㉑ 	㉒ 
㉓ 	㉔ 

## SYMBOLS

Symbols ① to ⑨ are designed as thumb-tabs to indicate the content of a chapter:

- ① General Information
- ② Specifications
- ③ Periodic Inspection and Adjustment
- ④ Fuel System
- ⑤ Power Unit
- ⑥ Jet pump Unit
- ⑦ Electrical System
- ⑧ Hull and Hood
- ⑨ Trouble-analysis

Symbols ⑩ to ⑮ indicate specific data:

- ⑩ Special tool
- ⑪ Specified liquid
- ⑫ Specified engine speed
- ⑬ Specified torque
- ⑭ Specified measurement
- ⑮ Specified electrical valve  
[Resistance ( $\Omega$ ), Voltage (V), Electric current (A)]

Symbol ⑯ to ⑱ in an exploded diagram indicate grade of lubricant and location of lubrication point:

- ⑯ Apply Yamaha 2-stroke outboard motor oil
- ⑰ Apply water resistant grease (Yamaha grease A, Yamaha marine grease)
- ⑱ Apply molybdenum disulfide grease

Symbols ⑲ to ㉔ in an exploded diagram indicate grade of sealing or locking agent, and location of application point:

- ⑲ Apply Gasket Maker<sup>®</sup>
- ⑳ Apply Yamahabond #4 (Yamaha bond No.4)
- ㉑ Apply LOCTITE<sup>®</sup> No. 271 (Red LOCTITE)
- ㉒ Apply LOCTITE<sup>®</sup> No. 242 (Blue LOCTITE)
- ㉓ Apply LOCTITE<sup>®</sup> No. 572
- ㉔ Apply Silicon sealant

## NOTE:

In this manual, the above symbols may not be used in every case.

# INDEX

<b>GENERAL INFORMATION</b>	 GEN INFO	<b>1</b>
<b>SPECIFICATIONS</b>	 SPEC	<b>2</b>
<b>PERIODIC INSPECTION AND ADJUSTMENT</b>	 INSP ADJ	<b>3</b>
<b>FUEL SYSTEM</b>	 FUEL	<b>4</b>
<b>POWER UNIT</b>	 POWR	<b>5</b>
<b>JET PUMP UNIT</b>	 JET PUMP	<b>6</b>
<b>ELECTRICAL SYSTEM</b>	 ELEC	<b>7</b>
<b>HULL AND HOOD</b>	 HULL HOOD	<b>8</b>
<b>TROUBLE-ANALYSIS</b>	 TRBL ANLS	<b>9</b>


**CHAPTER 1  
GENERAL INFORMATION**



**IDENTIFICATION NUMBERS** ..... 1-1  
    PRIMARY I.D. NUMBER ..... 1-1  
    ENGINE SERIAL NUMBER ..... 1-1  
    PUMP SERIAL NUMBER..... 1-1  
    HULL IDENTIFICATION NUMBER  
    (H.I.N.) ..... 1-1

**SAFETY WHILE WORKING** ..... 1-2  
    FIRE PREVENTION ..... 1-2  
    VENTILATION ..... 1-2  
    SELF-PROTECTION ..... 1-2  
    OILS, GREASES AND SEALING FLUIDS ..... 1-2  
    GOOD WORKING PRACTICES ..... 1-3  
    DISASSEMBLY AND ASSEMBLY ..... 1-4


**SPECIAL TOOLS** ..... 1-5  
    MEASURING ..... 1-5  
    REMOVAL AND INSTALLATION..... 1-6




A60700-0\*

**IDENTIFICATION NUMBERS  
PRIMARY I.D. NUMBER**

The primary I.D. number is stamped on a label attached to the inside of the engine compartment.




**Starting primary I.D. number:**  
**GM6: 900101 ~,**  
**910101 ~ (FRA),**  
**930101 ~ (GUM, AUS)**



**ENGINE SERIAL NUMBER**

The engine serial number is stamped on a label attached to the crankcase.


**Starting serial number:**  
**64V: 000101 ~**



**PUMP SERIAL NUMBER**

The jet pump unit serial number is stamped on a label attached on the intermediate housing.

**Starting serial number:**  
**64V: 500101 ~**




**HULL IDENTIFICATION NUMBER  
(H.I.N.)**

The H.I.N. is stamped on a plate attached to the hull beside the jet nozzle.

**SAFETY WHILE WORKING**


The procedures given in this manual are those recommended by Yamaha to be followed by Yamaha dealers and their mechanics.

**FIRE PREVENTION**

Gasoline (petrol) is highly flammable. Petroleum vapor is explosive if ignited. Do not smoke while handling gasoline (petrol), and keep it away from heat, sparks, and open flames.

**VENTILATION**

Petroleum vapor is heavier than air and if inhaled in large quantities will not support life. Engine exhaust gases are harmful to breathe. When test-running an engine indoors, maintain good ventilation.

**SELF-PROTECTION**

Protect your eyes with suitable safety spectacles or safety goggles when using compressed air, when grinding or when doing any operation which may cause particles to fly off.


Protect hands and feet by wearing safety gloves or protective shoes if appropriate to the work you are doing.

**OILS, GREASES AND SEALING  
FLUIDS**

Use only genuine Yamaha oils, greases and sealing fluids or those recommended by Yamaha.



Under normal conditions of use, there should be no hazards from the use of the lubricants mentioned in this manual, but safety is all-important, and by adopting good safety practises, any risk is minimized. A summary of the most important precautions is as follows

1. While working, maintain good standards of personal and industrial hygiene.
2. Clothing which has become contaminated with lubricants should be changed as soon as practicable, and laundered before further use.
3. Avoid skin contact with lubricants; do not, for example, place a soiled wiping-rag in one's pocket.
4. Hands, and any other part of the body which have been in contact with lubricants or lubricant-contaminated clothing, should be thoroughly washed with hot water and soap as soon as practicable.
5. To protect the skin, the application of a suitable barrier cream to the hands before working is recommended.
6. A supply of clean lint-free cloths should be available for wiping purposes.



### **GOOD WORKING PRACTICES**

1. The right tools  
Use the special tools that are designed to protect parts from damage. Use the right tool in the right manner — don't improvise.
2. Tightening torque  
Follow the torque tightening instructions. When tightening bolts, nuts and screws, tighten the larger sizes first, and tighten inner-positioned fixings before outer-positioned ones.



**3. Non-reusable items**

Always use new gaskets, packings, O-rings, oil seals, split-pins and circlips etc. on reassembly.

**DISASSEMBLY AND ASSEMBLY**

1. Clean parts with compressed-air on disassembling them.
2. Oil the contact surfaces of moving parts on assembly.

3. After assembly, check that moving parts operate normally.

4. Install bearings with the manufacturer's markings on the side exposed to view, and liberally oil the bearings.

**CAUTION:**

**Do not use compressed air to spin the bearings dry. This causes damage to the bearing surfaces.**

5. When installing oil seals, apply a light coating of water-resistant grease to the outside diameter.

**SPECIAL TOOLS**


Use of the correct special tools recommended by Yamaha will aid the work and enable accurate assembly and tune-up. Improvisations and use of improper tools can cause damage to the equipment.


**NOTE:**

- For U.S.A. and Canada, use part numbers starting with "YB-", "YU-" or "YW-".
- For other countries, use part numbers starting with "90890-".

**MEASURING**

1. Dial gauge and stand  
P/N. YU-03097, YU-01256  
90890-01252
2. Digital multi meter  
P/N. YU-34899-A  
90890-06752
3. Pocket tester  
P/N. YU-03112  
90890-03112
4. Compression gauge  
P/N. YU-33223  
90890-06751
5. Cylinder gauge set  
P/N. YU-03017  
90890-06759
6. Engine tachometer  
P/N. YU-08036-A  
90890-06760
7. Spark gap tester  
P/N. YM-34487  
90890-06754





**REMOVAL AND INSTALLATION**

1. Coupler wrench  
P/N. YW-38741  
90890-06425
2. Flywheel holder  
P/N. YB-06139  
90890-06522
3. Flywheel puller  
P/N. YB-06117  
90890-06521
4. Shaft holder (Intermediate shaft)  
P/N. YW-38742  
90890-06069
5. Driver rod  
(Intermediate shaft and jet pump)  
P/N. YB-06071  
90890-06606
6. Bearing outer race attachment  
(Intermediate shaft)  
P/N. YB-06016  
90890-06626
7. Drive shaft holder (Impeller)  
P/N. YB-06049  
90890-06518
8. Slide hammer set (Jet pump bearing)  
P/N. YB-06096  
90890-06523  
90890-06531
9. Ball bearing attachment  
(Jet pump oil seal)  
P/N. YB-06156  
90890-06634
10. Bearing inner race attachment  
(Jet pump bearing)  
P/N. YB-34474  
90890-06662



---

## **CHAPTER 2 SPECIFICATIONS**

**GENERAL SPECIFICATIONS** ..... 2-1

**MAINTENANCE SPECIFICATIONS** ..... 2-2

    ENGINE ..... 2-2

    JET UNIT ..... 2-3

    ELECTRICAL ..... 2-3

**TIGHTENING TORQUE** ..... 2-4

    SPECIFIED TORQUE ..... 2-4

    GENERAL TORQUE ..... 2-5



**GENERAL SPECIFICATIONS**

Item	Unit	Model
		SJ700A
<b>DIMENSIONS:</b>		
Length	mm (in)	2,240 (88.2)
Width	mm (in)	680 (26.8)
Height	mm (in)	660 (26.0)
Dry weight	kg (lb)	132 (291)
<b>PERFORMANCE:</b>		
Maximum speed	km/h (mph)	73 (45.4)
Maximum output	kW (hp) @r/min	53.7 (73) @6,300
Maximum fuel consumption	ℓ /h (US gal/h, Imp gal/h)	29 (7.7, 6.4)
Crusing range (at full throttle)	hr.	0.6
<b>ENGINE:</b>		
Engine type		2-stroke
Number of cylinders		2
Displacement	cm <sup>3</sup> (cu. in)	701 (42.78)
Bore × stroke	mm (in)	81 × 68 (3.19 × 2.68)
Compression ratio		7.2 : 1
Intake system		Reed valve
Carburetor type		Floatless type
Number of carburetor		2
Carburetor starting system		Choke
Scavenging system		Loop charged
Lubrication system		Pre-Mixed fuel and oil
Cooling system		Water-cooled
Starting system		Electric starter
Ignition system		C.D.I.
Ignition timing	Degree	15 BTDC ~ 21 BTDC
Spark plug (NGK)		B8HS/BR8HS
Battery capacity	V/kC (A•h)	12/68.4 (19)
Lighting coil	A @r/min	2 ~ 4 @5,500
<b>DRIVE UNIT:</b>		
Propulsion system		Jet pump
Jet pump type		Axial flow, single stage
Impeller rotation (rear view)		Counter clockwise
Transmission		Direct drive from engine
Nozzle angle	Degree	18.5, 20.5, 22.5, 24.5
<b>FUEL AND OIL:</b>		
Fuel		Regular gasoline
Engine oil type		2 stroke outboard motor oil
Engine oil grade		TC-W3
Fuel and oil mixing ratio (wide open throttle)		50 : 1
Fuel tank capacity	ℓ (US gal, Imp gal)	18 (4.8, 4.0)
reserve	ℓ (US gal, Imp gal)	5.5 (1.5, 1.2)



## MAINTENANCE SPECIFICATIONS

### ENGINE

Item	Unit	Model
		SJ700A
Cylinder head: Warpage limit	mm (in)	0.1 (0.004)
Cylinder: Bore size Wear limit Taper limit Out of round limit	mm (in) mm (in) mm (in) mm (in)	81.00 ~ 81.02 (3.189 ~ 3.190) 81.10 (3.193) 0.08 (0.003) 0.05 (0.002)
Piston: Piston size Measuring point* Piston clearance Wear limit	mm (in) mm (in) mm (in) mm (in)	80.925 ~ 80.950 (3.186 ~ 3.187) 10 (0.4) 0.070 ~ 0.075 (0.0028 ~ 0.0030) 0.125 (0.0049)
Piston ring: Type Sectional sketch (B × T) Side clearance End gap (installed)	mm (in) mm (in) mm (in) mm (in)	Keystone 1.2 × 2.9 (0.047 × 0.114) 0.01 ~ 0.03 (0.0004 ~ 0.0012) 0.2 ~ 0.4 (0.008 ~ 0.016)
Piston pin: Outside diameter Limit	mm (in) mm (in)	19.995 ~ 20.000 (0.7872 ~ 0.7874) 19.98 (0.786)
Crankshaft: Crank width "A" Run out limit "B" Connection rod big end clearance "C" Small end free play limit "D"	mm (in) mm (in) mm (in) mm (in)	61.95 ~ 62.00 (2.439 ~ 2.441) 0.05 (0.002) 0.25 ~ 0.75 (0.010 ~ 0.030) 2.0 (0.08)
Carburetor: Stamped mark Main nozzle Main jet 2 (M.J.2) Pilot jet (P.J.) Low speed screw Throttle valve (Th. V.) Valve seat (V.S.) High speed screw Trolling speed	∅ mm (in) ∅ mm (in) Turns out Turns out r/min	64U00F/R 2.5 (0.10) 130 70 7/8 ± 1/4 190 1.5 (0.06) 1-1/8 (F), 1-1/2 (R) ± 1/4 1,300 ± 50
Reed valve: Thickness Valve lift Bending limit	mm (in) mm (in) mm (in)	0.2 (0.008) 9.0 ± 0.2 (0.35 ± 0.01) 0.2 (0.008)



## JET UNIT

Item	Unit	Model
		SJ700A
Jet pump:		
Impeller clearance	mm (in)	0.3 ~ 0.4 (0.01 ~ 0.02)
Service limit	mm (in)	0.6 (0.024)
Impeller shaft run out	mm (in)	0.3 (0.012)

## ELECTRICAL

Item	Unit	Model
		SJ700A
Ignition system:		
Type		CDI magneto
Ignition timing at 1,200 rpm	Degree	15 BTDC
at 5,500 rpm	Degree	21 BTDC
Stator:		
Model/Manufacturer		F-2192HR/MITSUBISHI
Pulser coil resistance (color)	$\Omega$	12.6 ~ 15.4 (W/R - B)
Charging coil resistance (color)	$\Omega$	497.7 ~ 608.3 (Br/W - B)
CDI unit:		
Stamped mark		62T-00
Model/Manufacturer		F-6192X/MITSUBISHI
Over revolution limit	r/min	7,000 ~ 7,400
Overheat revolution control	r/min	3,000 ~ 3,800
Ignition coil:		
Stamped mark		62E-00
Model/Manufacturer		F6T532/MITSUBISHI
Primary winding resistance	$\Omega$	0.078 ~ 0.106 (O - B)
Secondary winding resistance	k $\Omega$	3.5 ~ 4.7 (high tension cords)
Charging system:		
Type		Flywheel magneto
Lighting coil resistance (color)	$\Omega$	1.14 ~ 1.40 (G - G)
Rectifier regulator:		
Model/Manufacturer		SH589-12/SHINDENGEN
Regulate voltage	V	14.3 ~ 15.3
Thermo sensor:		
ON	$^{\circ}\text{C}$ ( $^{\circ}\text{F}$ )	76 ~ 84 (169 ~ 183)
OFF	$^{\circ}\text{C}$ ( $^{\circ}\text{F}$ )	63 ~ 77 (145 ~ 171)
Starter motor:		
Model/Manufacturer		SM13237/MITSUBA
Brush length limit	mm (in)	6.5 (0.26)
Commutator undercut limit	mm (in)	0.2 (0.01)
diameter limit	mm (in)	27 (1.06)
Fuse:		
Rating	A	10

**TIGHTENING TORQUE  
SPECIFIED TORQUE**


Part to tightened	Part name	Size	Q'ty	Tightening torque			Remarks	
				Nm	m•kg	ft•lb		
<b>ENGINE:</b>								
Electric box	Bolt	M8	2	13	1.3	9.4		
Mounting bolt	Bolt	M8	4	17	1.7	12		
Reed valve	Screw	M4	16	1	0.1	0.7		
Muffler stay	1st	Bolt	M10	5	4	0.4	2.9	
	2nd				40	4.0	29	
Muffler 2-Muffler stay	1st	Bolt	M10	3	28	2.8	20	
	2nd				53	5.3	38	
Muffler 1	1st	Bolt	M10	8	15	1.5	11	
	2nd				30	3.0	22	
Cylinder body	1st	Bolt	M10	6	23	2.3	17	
	2nd				40	4.0	29	
Cylinder head	1st	Bolt	M8	10	15	1.5	11	
	2nd				36	3.6	26	
Spark plug	Bolt	M14	2	20	2.0	14		
Flywheel bolt	Bolt	M10	1	70	7.0	51		
Crankcase	1st	Bolt	M8	8	15	1.5	11	
	2nd				28	2.8	20	
Mount bracket	1st	Bolt	M10	7	23	2.3	17	
	2nd				47	4.7	34	
Coupling	Nut	M27	1	37	3.7	27		
Frame arrestor cover	Bolt	M6	6	2	0.2	1.4		
Starter motor terminal nut	Nut	M6	1	5	0.5	3.6		
<b>JET UNIT:</b>								
Mounting bolt	Bolt	M10	4	17	1.7	12		
Ride plate	Bolt	M8	4	17	1.7	12		
Impeller (left-hand threads)	Bolt	M20	1	18	1.8	13		
Coupling	Nut	M27	1	37	3.7	27		
Intermediate housing	Bolt	M8	3	17	1.7	12		



Nut (A)	Bolt (B)	General torque specifications		
		Nm	m•kg	ft•lb
8 mm	M5	5.0	0.5	3.6
10 mm	M6	8.0	0.8	5.8
12 mm	M8	18	1.8	13
14 mm	M10	36	3.6	25
17 mm	M12	43	4.3	31

**GENERAL TORQUE**

This chart specifies the torques for tightening standard fasteners with standard clean dry ISO threads at room temperature. Torque specifications for special components or assemblies are given in applicable sections of this manual. To avoid causing warpage, tighten multifastener assemblies in a criss-cross fashion, in progressive stages until the specified torque is reached.



## CHAPTER 3

### PERIODIC INSPECTION AND ADJUSTMENT

<b>MAINTENANCE INTERVAL CHART .....</b>	<b>3-1</b>
<b>PERIODIC SERVICE.....</b>	<b>3-2</b>
<b>CONTROL SYSTEM .....</b>	<b>3-2</b>
Steering friction inspection and adjustment.....	3-2
Steering pole pivot shaft bushing inspection .....	3-2
Steering cable inspection and adjustment.....	3-3
Throttle cable inspection and adjustment.....	3-4
Choke cable inspection and adjustment.....	3-5
<b>FUEL SYSTEM.....</b>	<b>3-6</b>
Fuel filter inspection.....	3-6
Trolling speed inspection and adjustment.....	3-6
Carburetor adjustment.....	3-7
<b>POWER UNIT.....</b>	<b>3-8</b>
Spark plug inspection .....	3-8
<b>ELECTRICAL .....</b>	<b>3-9</b>
Battery inspection.....	3-9
<b>JET PUMP UNIT .....</b>	<b>3-11</b>
Impeller inspection.....	3-11
Bilge strainer inspection .....	3-12
<b>GENERAL.....</b>	<b>3-12</b>
Greasing point .....	3-12

## MAINTENANCE INTERVAL CHART



The following chart should be considered strictly as a guide to general maintenance intervals.

Depending on operating conditions, the intervals of maintenance should be changed.

Item	Initial		Every		Refer to page
	10 hours (Break-in)	50 hours (3 months)	100 hours (6 months)	200 hours (1 year)	
<b>CONTROL SYSTEM:</b>					
Steering cable			○		3-3
Throttle cable			○		3-4
Carburetor throttle shaft			○		—
Choke cable			○		3-5
Steering pivot	○		○		3-2
Steering friction	○		○		3-2
<b>FUEL SYSTEM:</b>					
Fuel tank				○	4-7
Fuel filter	○			○	3-6
Fuel line			○		4-1
Trolling speed			○		3-6
Carburetor setting	○		○		3-7
<b>POWER UNIT:</b>					
Spark plug	○	○	○		3-8
Cooling-water passage		○			—
Coupling rubber				○	—
<b>ELECTRICAL:</b>					
Battery	○				3-9
<b>JET PUMP UNIT:</b>					
Impeller		○	○		3-11
Bilge strainer		○	○		3-12
<b>GENERAL:</b>					
Bolt and nut	○		○		—
Greasing point			○		3-12
Bearing housing	○ *1		○ *2		3-12

\*1: Grease capacity 20.0 ~ 22.0 cm<sup>3</sup> (0.68 ~ 0.74 oz.)

\*2: Grease capacity 3.0 ~ 5.0 cm<sup>3</sup> (0.10 ~ 0.17 oz.)



**PERIODIC SERVICE**  
**CONTROL SYSTEM**

**Steering friction inspection and adjustment**

1. Check:

- Pivot shaft bearing  
Turn the handlebar lock to lock.  
Rough action → Adjust.  
Excessive play → Replace bearings.  
Refer to "HANDLE COLUMN" in chapter 8.

2. Adjust:

- Bearing friction


**Adjustment steps:**

- Remove the handle lower cover.
- Loosen the lock nut ①.
- Turn the adjusting nut ② until the desired amount of friction is reached.
- Tighten the lock nut while holding the adjusting nut.



**Lock nut:**  
**29 Nm (2.9 m · kg, 21 ft · lb)**





- Install the handle lower cover.



**Steering pole pivot shaft bushing inspection**

1. Check:

- Steering pole pivot shaft bushing  
Excessive play → Replace bearings.  
Refer to "STEERING POLE" in chapter 8.



**Steering cable inspection and adjustment**

**1. Check:**

- Jet nozzle clearance (a), (b)  
Incorrect → Adjust.

**Checking steps:**

- Turn the handlebar lock to lock.
- Measure the clearances (a) and (b).
- If the (a) and (b) clearances are not even, adjust the clearances.

**2. Adjust:**

- Cable joint (handle side) ①

**Adjustment steps:**

- Remove the steering pad.
- Loosen the lock nut ②.
- Disconnect the cable joint from the ball joint ③.
- Turn the cable joint to adjust.

Turn in	Clearance (a) is increased.
Turn out	Clearance (b) is increased.

**⚠ WARNING**

The cable joint must be screwed in more than 8 mm (0.31 in).

- Connect the cable joint and tighten the lock nut.




**Lock nut:**  
3 Nm (0.3 m · kg, 2.2 ft · lb)

- Install the steering pad.

**NOTE:**

If correct adjustment cannot be obtained using the cable joint at the handlebar end adjust the cable joint at the steering nozzle end.



**Throttle cable inspection and adjustment**

**NOTE:** \_\_\_\_\_  
Before adjusting the throttle lever free play, the trolling speed should be adjusted.


1. Measure:
- Throttle lever free play ①
- Out of specification → Adjust.

	<b>Throttle lever free play:</b> 7 ~ 10 mm (0.28 ~ 0.39 in)
--	--

2. Adjust:
- Throttle lever free play

<b>Adjustment steps:</b>	
● Loosen the lock nut ①.	
● Turn the adjuster ② in/out until the specified free play is obtained.	
<b>Turn in</b>	<b>Free play is increased.</b>
<b>Turn out</b>	<b>Free play is decreased.</b>
● Tighten the lock nut.	

**⚠ WARNING** \_\_\_\_\_  
After adjusting the free play, turn the handlebar to right and left, and make sure that the trolling speed does not increase.




**Choke cable inspection and adjustment**

1. Measure:

- Choke cable free play ①
- Out of specification → Adjust.

	<b>Choke cable free play:</b>
	<b>1 ~ 6 mm (0.04 ~ 0.24 in)</b>



2. Adjust:

- Choke cable free play


**Adjustment steps:**

- Loosen the lock nut ①.
- Turn the adjuster ② in/out until the specified free play is obtained.

<b>Turn in</b>	<b>Free play is increased.</b>
<b>Turn out</b>	<b>Free play is decreased.</b>

- Tighten the lock nut.

	<b>Lock nut:</b>
	<b>8 Nm (0.8 m · kg, 5.8 ft · lb)</b>



3. Inspect:

- Pull knob farthest toward
- Knob automatically returns → Adjust.

4. Adjust:

- Adjust nut ③
- Turn in to stop automatic return.



**FUEL SYSTEM**

**⚠ WARNING**

- Stop the engine, set the fuel cock to "OFF" and loosen the fuel filler cap before a fuel system service.
- When removing fuel system parts, hold them in a cloth and take care that no fuel spills into the engine compartment.

**Fuel filter inspection**

1. Inspect:
  - Filter element  
Contamination → Replace.
  - Filter body  
Crack/Damage → Replace.
  - Filter assembly  
Water contamination → Replace and check the fuel tank.

**Trolling speed inspection and adjustment**

1. Check:
  - Trolling speed  
Out of specification → Adjust.


	<b>Trolling speed:</b> <b>1,300 ± 50 r/min</b>
--	---


<b>Checking steps: (vehicle on water)</b>
<ul style="list-style-type: none"> <li>● Start the engine and allow it to warm up for a few minutes.</li> <li>● Attach the engine tachometer to the spark plug lead.</li> </ul>

	<b>Engine tachometer:</b> <b>YU-8036-A/90890-06760</b>
<ul style="list-style-type: none"> <li>● Measure the engine trolling speed.</li> </ul>	

2. Adjust:
  - Trolling speed

<b>Adjustment steps:</b>
<ul style="list-style-type: none"> <li>● Screw in the low speed screws ① until they are lightly seated.</li> <li>● Back the screws out by the specified number of turns.</li> </ul>






**Low speed screw:**  
 **$7/8 \pm 1/4$  (turns out)**

- Start the engine and allow it to warm up for a few minutes.
- Turn the throttle stop screws ② in or out until the specified speed is obtained.

<b>Turning in</b>	<b>Increase trolling speed.</b>
-------------------	---------------------------------

<b>Turning out</b>	<b>Decrease trolling speed.</b>
--------------------	---------------------------------



**Carburetor adjustment**

1. Adjust:


- High speed screw

**Adjustment steps:**

- Screw in the high speed screws ① until they are lightly seated.
- Back the screws out by the specified number of turns.



**High speed screw:**  
 **$1-1/8$  (F),  $1-1/2$  (R)  $\pm 1/4$   
(turns out)**



**POWER UNIT**

**Spark plug inspection**

1. Inspect:

- Electrode ①  
Wear/Damage → Replace.
- Insulator color ②  
Discolor → Check the engine condition.



**Color guide:**

**Medium to light tan color:**

**Normal**

**Whitish color:**

**Lean fuel mixture**

**Plugged fuel mixture**

**Air leak**

**Incorrect settings**


**Blackish color:**

**Overly rich mixture**

**Electrical malfunction**

**Excess oil used**

**Defective spark plug**



2. Clean:

- Spark plug  
Clean the spark plug with a spark plug cleaner or wire brush.

3. Measure:

- Spark plug gap ③  
Out of specification → Alter gap.  
Use a wire gauge.



**Spark plug gap:**

**0.6 ~ 0.7 mm (0.024 ~ 0.028 in)**


4. Tighten:

- Spark plug



**Spark plug:**

**20 Nm (2.0 m · kg, 14 ft · lb)**



**NOTE:**

- Before installing a spark plug, clean the gasket surface and plug surface. Also it is advisable to apply a thin film of Anti Seize Compound to the spark plug threads to prevent future thread seizure.
- If a torque wrench is not available, a good estimate of the correct torque for the spark plug is a further 1/4 to 1/2 turns ④ on from finger tightness ③.

**ELECTRICAL**  
**Battery inspection****CAUTION:**

Be careful not to place the battery on its side. Before adding the battery fluid or recharging, be sure to remove it from the engine compartment. When checking the battery, make sure the breather hose is connected to the battery and is not pinched shut anywhere in the engine compartment.


**⚠ WARNING**

- Battery electrolyte is poisonous and dangerous, causing severe burns, etc. Contains sulfuric acid.
- Avoid contact with skin, eyes or clothing.
- Antidote: EXTERNAL-Flush with water.
- INTERNAL-Drink large quantities of water or milk. Follow with milk of magnesia, beaten egg or vegetable oil. Call a physician immediately.
- Eyes: Flush with water for 15 minutes and get prompt medical attention. Batteries produce explosive gases.
- Keep sparks, flame, cigarettes, etc., away. Ventilate when charging or using in an enclosed space. Always shield your eyes when working near batteries.
- KEEP OUT OF REACH OF CHILDREN.

1. Remove:
  - Battery

**⚠ WARNING**

- When removing the battery, disconnect the negative lead first.
- Remove the battery to prevent acid loss during the impeller service.



2. Inspect:
  - Battery fluid level  
Battery fluid level low → Top up with distilled water.  
Fluid level should be between upper ① and lower ② level marks.

**Filling steps:**

- Remove each filler cap using pliers.
- Fill with distilled water using a jug.
- When the acid is up to the UPPER LEVEL, allow the cell to stand for 20 minutes. If the acid level has dropped, add more acid up to the UPPER LEVEL once again.

**CAUTION**

**Water other than distilled water contains minerals which are harmful to a battery; top up only with distilled water.**


3. Inspect:
  - Battery fluid specific gravity  
Out of specification → Charge.

	<b>Specific gravity at 20°C (68°F):</b>
	<b>1.28</b>
	<b>Charging current:</b>
	<b>68.4 kC (1.9 Amps × 10 Hrs)</b>

4. Install:
  - Filler cap

**CAUTION**


**Rinse off any acid from the battery case and wipe the battery dry prior to installation.**



5. Install:
- Breather hose ①
  - Battery ②
  - Positive lead ②
  - Negative lead ③
  - Battery band


**CAUTION:**

- Connect the positive red lead ⊕ to the battery terminal first.
- Make sure the battery leads are connected properly. Reversing the leads can seriously damage the electrical system.
- Make sure the breather hose is properly connected and is not obstructed.
- Coat the terminals with a water resistant grease to minimize terminal corrosion.



**JET PUMP UNIT**  
**Impeller inspection**

1. Check:
- Impeller ①  
Wear/Damage → Replace.  
Scratch/Nick → File/Grind.
2. Measure:
- Impeller clearance ②  
Out of specification → Replace.




 **Impeller clearance limit:**  
**0.6 mm (0.024 in)**

**Measurement steps:**

- Remove the battery.
- Remove the intake screen.
- Measure the clearance at all four points.
- Install the intake screen.

 **Bolt:**  
**5 Nm (0.5 m · kg, 3.6 ft · lb)**

- Install the battery.




**Bilge strainer inspection**

1. Inspect:

- Strainer  
Contamination → Clean.  
Crack/Damage → Replace.

**Inspection steps:**

- Remove the coupling cover.
- Disconnect the bilge strainer from the strainer holder.
- Inspect the bilge strainer.



**GENERAL**

**Greasing point**

1. Apply:

- Throttle cable inner wire

**NOTE:**

Squeeze the throttle lever and remove the seal. Spray a rust-inhibitor into the outer cable.



**Recommended fluid:  
Rust-inhibitor**

- Throttle cable inner wire
- Choke cable inner wire
- Cable joint
- Steering cable

**NOTE:**

Remove the cable joint and apply a small amount of grease to the following parts.

- Steering pivot shaft bearing
- Choke knob shaft
- Bearing housing



**Recommended grease:  
Water resistant grease**

**NOTE:**

- Fill in the bearing housing with water resistant grease from a nipple.
- Fill the grease slowly and carefully, as it can damage the hose and the joints.
- Refer to the "MAINTENANCE INTERVAL CHART".

## CHAPTER 4 FUEL SYSTEM


<b>FUEL LINE</b> .....	4-1
EXPLODED DIAGRAM .....	4-1
REMOVAL AND INSTALLATION CHART.....	4-1
<b>SERVICE POINTS</b> .....	4-2
Fuel filter inspection.....	4-2
Fuel cock inspection.....	4-2
Check vale inspection.....	4-2
 <b>FUEL TANK</b> .....	 4-3
EXPLODED DIAGRAM .....	4-3
REMOVAL AND INSTALLATION CHART.....	4-3
Pipe joint inspection.....	4-4
Pipe joint installation.....	4-4
 <b>CARBURETOR REMOVAL</b> .....	 4-5
EXPLODED DIAGRAM .....	4-5
REMOVAL AND INSTALLATION CHART.....	4-5
 <b>CARBURETOR</b> .....	 4-6
EXPLODED DIAGRAM .....	4-6
REMOVAL AND INSTALLATION CHART.....	4-6
<b>SERVICE POINTS</b> .....	4-7
Diaphragm inspection.....	4-7
Float arm inspection.....	4-7
Body assembly inspection.....	4-7
Needle valve inspection.....	4-7
Jet and carburetor body inspection.....	4-8
High and low speed screws inspection .....	4-8
High and low speed screws adjustment.....	4-8
Throttle valve synchronization inspection and adjustment.....	4-8
Choke valve synchronization inspection and adjustment.....	4-9
Carburetor assembly.....	4-9
 <b>FUEL PUMP</b> .....	 4-10
EXPLODED DIAGRAM .....	4-10
REMOVAL AND INSTALLATION CHART.....	4-10
<b>SERVICE POINTS</b> .....	4-11
Fuel pump inspection.....	4-11
Filter inspection .....	4-11



**⚠ WARNING**

Gasoline (petrol) is highly flammable and explosive. Handle with special care.

**FUEL LINE  
EXPLODED DIAGRAM**



**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
	<b>FUEL HOSE REMOVAL</b>		Follow the left "Step" for removal.
1	Battery breather hose	1	
2	Air ventilation hose	3	
3	Fuel hose (RES)	1	
4	Fuel hose (ON)	1	
5	Fuel hose (return)	1	
6	Fuel hose (filter - pump)	1	
7	Fuel hose (OUT)	1	
8	Nut	1	
9	Fuel cock body	1	
			Reverse the removal steps for installation.

**SERVICE POINTS****Fuel filter inspection**

Refer to "FUEL SYSTEM" in chapter 3.

**Fuel cock inspection**


1. Check:

- Fuel cock  
Unsmooth movement → Replace.  
Clog → Clean.

**Check valve inspection**


1. Check:

- Check valve  
Out of specification → Replace.



Flow from A to B

**FUEL TANK  
EXPLODED DIAGRAM**




**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
	<b>FUEL TANK REMOVAL</b>		Follow the left "Step" for removal.
	Battery		
1	Fuel hose	2	
2	Tank band	2	
3	Clamp	1	
4	Air ventilation hose	1	
5	Pipe joint assembly	1	
6	Fuel tank	1	
			Reverse the removal steps for installation.

**Pipe joint inspection**

1. Inspect:

- Pipe  
Bending/Damage → Replace.  
Contamination → Clean.
- Pipe joint  
Wear/Crack → Replace.



**Pipe joint installation**


1. Install:

- Pipe joint ①
- Pipe ②
- Hose ③
- Clamp




**Length ①:**  
**242 ± 2 mm (9.53 ± 0.08 in)**

**Length ②:**  
**165 ± 2 mm (6.50 ± 0.08 in)**



**NOTE:** \_\_\_\_\_  
Connect the hose for "RES" on the pipe side.  
\_\_\_\_\_


**CARBURETOR REMOVAL  
EXPLODED DIAGRAM**



**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
	<b>CARBURETOR REMOVAL</b>		Follow the left "Step" for removal.
	Fuel cock		<b>NOTE:</b> _____ Turn the fuel cock to "OFF".
1	Choke cable	1	 <p><b>Cable guide set position ①:</b> 17 mm (0.67 in) Between cable guide top and plate top.</p>
2	Throttle cable	1	
3	Cover 2	1	
4	Fuel hose	2	
5	Pulse hose	1	
6	Carburetor assembly	1	
			Reverse the removal steps for installation.

**CARBURETOR  
EXPLODED DIAGRAM**



**REMOVAL AND INSTALLATION CHART**





Step	Procedure/Part name	Q'ty	Service points
	<b>CARBURETOR DISASSEMBLY</b>		
	Carburetor assembly		Follow the left "Step" for removal. Refer to "CARBURETOR REMOVAL".
1	Diaphragm assembly	1	
2	Float arm	1	
3	Needle valve assembly	1	
4	Body assembly	1	
5	Main jet	1	
6	Pilot jet	1	
7	High speed screw	1	
8	Low speed screw	1	
			Reverse the removal steps for installation.



**SERVICE POINTS**

**CAUTION:**

Do not use steel wire for cleaning the jets as this may enlarge the jet diameters and seriously affect performance.



**Diaphragm inspection**

1. Inspect:
  - Diaphragm assembly  
Damage → Replace.

**Float arm inspection**

1. Inspect:
  - Float arm ①  
Bend/Damage → Repair or replace.
2. Measure:
  - Float arm height ②

**Float arm height:**  
0 ~ 0.2 mm (0 ~ 0.008 in)

**NOTE:**

- Measure the distance between the surface ② of the carburetor body and the top surface of the float arm.
- The float arm should be resting on the needle valve, but not compressing the needle valve.

**Body assembly inspection**

1. Inspect:
  - Body assembly ①  
Contamination → Clean.
  - Valve ②  
Damage → Replace.

**Needle valve inspection**

1. Inspect:
  - Needle valve
  - Valve seat  
Grooved wear ② → Replace.  
Dust ③ → Clean.

**NOTE:**

Always replace the needle valve and valve seat as a set.




**Jet and carburetor body inspection**

1. Inspect:
  - Main jet
  - Pilot jet
  - Carburetor body
 Contamination → Clean.

**High and low speed screws inspection**

1. Inspect:
  - High speed screw
  - Low speed screw
 Bend/Wear → Replace.



**High and low speed screws adjustment**


1. Adjust:
  - High speed screw
  - Low speed screw

**Adjustment steps:**

- Screw in the high speed screws ① or lower speed screws ② until it is lightly seated.
- Back out by the specified number of turns.



**High speed screw:**  
 1-1/8 (F), 1-1/2 (R) ± 1/4 turns out  
**Low speed screw:**  
 7/8 ± 1/4 turns out




**Throttle valve synchronization inspection and adjustment**

1. Check:
  - Throttle valve synchronization
 Out of specification → Adjust.

**Checking steps:**

- While turning the throttle lever, check the opening of all throttle valves.



## 2. Adjust:

- Throttle valve synchronization


**Adjustment steps:**

- Turn out the idle adjust screws ① until their tips are apart from the throttle lever ②.

**NOTE:**

Record the set position of the idle adjust screw.

- Check that the R throttle valve ③ is fully closed.
- Turn the synchronization screw ④ in or out until the F throttle valve ⑤ is fully closed.
- Turn in the idle adjust screws to the set position.


**Choke valve synchronization inspection and adjustment**

## 1. Check:

- Choke valve synchronization
- Out of specification → Adjust.

**Checking steps:**

- While turning the choke lever, check the opening of all choke valves.



## 2. Adjust:

- Choke valve synchronization

**Adjustment steps:**

- Turn in or out the synchronization screw ① to bring all the choke valves into a fully closed position when the choke lever is turned on the closed side.


**Carburetor assembly**

## 1. Adjust:

- Trolling speed
- Refer to "FUEL SYSTEM" in chapter 3.



**FUEL PUMP  
EXPLODED DIAGRAM**



**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
	<b>FUEL PUMP DISASSEMBLY</b>		
	Carburetor assembly		Follow the left "Step" for removal. Refer to "CARBURETOR REMOVAL".
1	Pump cover	1	
2	Diaphragm	1	
3	O-ring	1	
4	Diaphragm body assembly	1	
5	Diaphragm	1	
6	O-ring	1	
7	Filter	1	
			Reverse the removal steps for installation.



---

**SERVICE POINTS**

**Fuel pump inspection**

1. Inspect:
  - Diaphragm
  - Diaphragm body assemblyDamage → Replace.

**Filter inspection**

1. Inspect:
  - FilterContamination → Clean.  
Damage → Replace.

## CHAPTER 5 POWER UNIT


<b>REED VALVE</b> .....	5-1
EXPLODED DIAGRAM .....	5-1
REMOVAL AND INSTALLATION CHART .....	5-1
SERVICE POINTS .....	5-2
Reed valve inspection .....	5-2
<b>EXHAUST RING</b> .....	5-3
EXPLODED DIAGRAM .....	5-3
REMOVAL AND INSTALLATION CHART .....	5-3
<b>EXHAUST CHAMBER</b> .....	5-4
EXPLODED DIAGRAM .....	5-4
REMOVAL AND INSTALLATION CHART .....	5-4
<b>MUFFLER</b> .....	5-5
EXPLODED DIAGRAM .....	5-5
REMOVAL AND INSTALLATION CHART .....	5-5
<b>CYLINDER HEAD</b> .....	5-6
EXPLODED DIAGRAM .....	5-6
REMOVAL AND INSTALLATION CHART .....	5-6
SERVICE POINTS .....	5-7
Cylinder head inspection .....	5-7
<b>CYLINDER</b> .....	5-8
EXPLODED DIAGRAM .....	5-8
REMOVAL AND INSTALLATION CHART .....	5-8
SERVICE POINTS .....	5-9
Cylinder inspection .....	5-9
<b>PISTON</b> .....	5-10
EXPLODED DIAGRAM .....	5-10
REMOVAL AND INSTALLATION CHART .....	5-10
SERVICE POINTS .....	5-11
Piston inspection .....	5-11
Piston ring inspection .....	5-12
Piston pin and bearing inspection .....	5-12




<b>ENGINE UNIT REMOVAL</b> .....	5-14
EXPLODED DIAGRAM .....	5-14
REMOVAL AND INSTALLATION CHART.....	5-14
SERVICE POINTS .....	5-15
Shim removal .....	5-15
Mount bracket inspection .....	5-15
Coupling clearance inspection .....	5-15
<b>FLYWHEEL MAGNETO AND BASE</b> .....	5-16
EXPLODED DIAGRAM .....	5-16
REMOVAL AND INSTALLATION CHART.....	5-16
SERVICE POINTS .....	5-17
Coupling flange removal and installation .....	5-17
Flywheel magneto removal and installation.....	5-17
Coupling flange inspection .....	5-17
Flywheel magneto inspection .....	5-17
Idle gear assembly inspection.....	5-17
<b>ELECTRICAL UNIT</b> .....	5-18
EXPLODED DIAGRAM .....	5-18
REMOVAL AND INSTALLATION CHART.....	5-18
<b>STARTER MOTOR</b> .....	5-19
EXPLODED DIAGRAM .....	5-19
REMOVAL AND INSTALLATION CHART.....	5-19
SERVICE POINTS .....	5-20
Pinion inspection .....	5-20
Armature inspection.....	5-20
Brush holder inspection.....	5-21
Cover inspection.....	5-21
<b>CRANKCASE</b> .....	5-22
EXPLODED DIAGRAM .....	5-22
REMOVAL AND INSTALLATION CHART.....	5-22
SERVICE POINTS .....	5-23
Crankcase inspection .....	5-23
Crankcase installation .....	5-23
<b>CRANKSHAFT</b> .....	5-24
EXPLODED DIAGRAM .....	5-24
REMOVAL AND INSTALLATION CHART.....	5-24
SERVICE POINTS .....	5-25
Crankshaft inspection.....	5-25

---

<b>INTERMEDIATE HOUSING REMOVAL .....</b>	<b>5-26</b>
EXPLODED DIAGRAM .....	5-26
REMOVAL AND INSTALLATION CHART.....	5-26
<b>INTERMEDIATE HOUSING .....</b>	<b>5-27</b>
EXPLODED DIAGRAM .....	5-27
REMOVAL AND INSTALLATION CHART.....	5-27
SERVICE POINTS .....	5-28
Coupling removal and installation.....	5-28
Bearing removal and installation.....	5-28
Bearing inspection.....	5-28
Coupling inspection .....	5-28
Oil seal installation.....	5-28





**REED VALVE  
EXPLODED DIAGRAM**



**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
	<b>REED VALVE REMOVAL</b>		
	Carburetor assembly		Follow the left "Step" for removal. Refer to "CARBURETOR REMOVAL" in chapter 4.
1	Plate	1	
2	Intake manifold assembly	1	
3	Reed valve assembly	2	
4	Plate	1	
5	Valve stopper	4	
6	Reed valve	4	
			Reverse the removal steps for installation.

**SERVICE POINTS****Reed valve inspection**

## 1. Inspect:

- Reed valve  
Crack/Damage → Replace.

## 2. Measure:

- Valve bending @  
Out of specification → Replace.


**Valve bending limit:  
0.2 mm (0.008 in)**

## 3. Measure:

- Valve stopper height @  
Out of specification → Adjust or  
replace.

**Valve stopper height:  
 $9.0 \pm 0.2$  mm ( $0.35 \pm 0.01$  in)**


**EXHAUST RING  
EXPLODED DIAGRAM**



**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
	<b>EXHAUST RING REMOVAL</b>		Follow the left "Step" for removal.
1	Water hose	1	<b>NOTE:</b> _____ ● Pull and side the exhaust joint. ● Loosen the clamp at the muffler side. <hr/> <b>CAUTION:</b> _____ <b>Tighten the clamp, before installing the ring on the muffler.</b> <hr/> Reverse the removal steps for installation.
2	Exhaust joint	1	
3	Clamp	1	
4	Ring	1	
5	Clamp	1	
6	Joint	1	


**EXHAUST CHAMBER  
EXPLODED DIAGRAM**



**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
	<b>EXHAUST CHAMBER REMOVAL</b>		Follow the left "Step" for removal. Refer to "EXHAUST RING".
	Ring		
1	Exhaust hose	1	
2	Water hose	1	
3	Bolt (muffler)	3	
4	Chamber assembly	1	
5	Bolt (muffler stay)	5	
6	Muffler stay	1	
7	Bolt (with washer)	1	
8	Bolt (with washer)	7	
			<b>CAUTION:</b> _____ <b>Tighten the bolts in sequence.</b> _____
			Reverse the removal steps for installation.


**MUFFLER  
EXPLODED DIAGRAM**



**REMOVAL AND INSTALLATION CHART**




Step	Procedure/Part name	Q'ty	Service points
	<b>MUFFLER REMOVAL</b>		Follow the left "Step" for removal. Refer to "EXHAUST CHAMBER".
	Exhaust chamber		
1	Water inlet hose	1	
2	Bolt (with washer)	8	
3	Muffler	1	
4	Gasket	1	
5	Bolt (with washer)	4	
6	Protector	1	
7	Gasket	1	
			Reverse the removal steps for installation.

**CYLINDER HEAD  
EXPLODED DIAGRAM**



**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
	<b>CYLINDER HEAD REMOVAL</b>		
	Muffler		Follow the left "Step" for removal. Refer to "MUFFLER".
1	Spark plug	2	
2	Thermo switch assembly	1	
3	Bolt (with washer)	10	<b>CAUTION:</b> _____ <b>Tighten the bolts in sequence and in two steps of torque.</b>
4	Cylinder head	1	Reverse the removal steps for installation.



## SERVICE POINTS

### Cylinder head inspection

1. Eliminate:
  - Carbon deposits  
Use a rounded scraper ①.

#### NOTE:

Take care to avoid damaging the spark plug threads. Do not use a sharp instrument. Avoid scratching the aluminum.

2. Inspect:
  - Cylinder head water jacket  
Mineral deposits/Corrosion → Clean.
3. Measure:
  - Cylinder head warpage  
Out of specification → Resurface.




**Warpage limit:**  
0.1 mm (0.004 in)

#### Measurement steps:



- Attach a straight edge and a thickness gauge to the cylinder head.
- Measure the warpage.

**CYLINDER  
EXPLODED DIAGRAM**



**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
<b>CYLINDER REMOVAL</b>			
1	Cylinder head Bolt (with washer)	6	Follow the left "Step" for removal. Refer to "CYLINDER HEAD". <b>CAUTION</b> _____ <b>Tighten the bolts in sequence and in two steps of torque.</b>
2	Cylinder	1	<b>CAUTION</b> _____ <b>After installing, check the smooth movement of the piston.</b>
3	Pin	2	Reverse the removal steps for installation.



**SERVICE POINTS**


**Cylinder inspection**

1. Eliminate:

- Carbon deposits  
Use a rounded scraper ①.

2. Inspect:

- Cylinder water jacket  
Mineral deposits/Corrosion → Clean.
- Cylinder inner surface  
Score marks → Repair or replace.  
Use #600 ~ 800 grit wet sandpaper.




3. Measure:

- Cylinder bore "D"  
Use cylinder gauge.  
Out of specification → Replace.

**NOTE:**

Measure the cylinder bore "D" in several different directions. Then find the average of the measurements.



	Standard	Limit
Cylinder bore "D"	81.00 ~ 81.02 mm (3.189 ~ 3.190 in)	81.10 mm (3.193 in)
Taper "T"	—	0.08 mm (0.003 in)
Out of round "R"	—	0.05 mm (0.002 in)
D = Maximum (D <sub>1</sub> ~ D <sub>6</sub> ) T = (Maximum D <sub>1</sub> or D <sub>2</sub> ) - (Maximum D <sub>5</sub> or D <sub>6</sub> ) R = (Maximum D <sub>1</sub> , D <sub>3</sub> or D <sub>5</sub> ) - (Minimum D <sub>2</sub> , D <sub>4</sub> or D <sub>6</sub> )		






**SERVICE POINTS**


**Piston inspection**

1. Eliminate:
  - Carbon deposits  
From the piston crown and ring groove.



2. Inspect:
  - Piston wall  
Score marks → Repair or replace.  
Use #600 ~ 800 grit wet sandpaper.

**NOTE:** \_\_\_\_\_  
Sand in a criss-cross pattern. Do not sand excessively.  
\_\_\_\_\_






3. Measure:
  - Piston skirt diameter  
Use micrometer.  
Out of specification → Replace.

	Piston diameter	Distance ①
	80.925 ~ 80.950 mm (3.186 ~ 3.187 in)	10 mm (0.39 in)

4. Calculate:
  - Piston clearance  
Out of specification → Replace piston, piston rings as a set.

<b>PISTON CLEARANCE</b>	=	<b>CYLINDER BORE</b>	-	<b>PISTON DIAMETER</b>
-------------------------	---	----------------------	---	------------------------

	<b>Piston clearance:</b> 0.070 ~ 0.075 mm (0.0028 ~ 0.0030 in)
---	--



**Piston ring inspection**

1. Measure:

- Side clearance  
Out of specification → Replace piston and/or ring.  
Use a thickness gauge ①.

	<b>Side clearance:</b>
	Top
	2nd
	0.01 ~ 0.03 mm (0.0004 ~ 0.0012 in)

2. Measure:

- End gap  
Out of specification → Replace rings as a set.  
Use a thickness gauge ①.

	<b>End gap:</b>
	Top
	2nd
	0.2 ~ 0.4 mm (0.008 ~ 0.016 in)



**NOTE:** \_\_\_\_\_

- Install the piston ring in the cylinder.
- Push the ring with the piston crown.

**Piston pin and bearing inspection**

1. Inspect:

- Piston pin
- Bearing  
Signs of heat discoloration → Replace.



## 2. Measure:


- Piston pin outside diameter  
Use micrometer.  
Out of limit → Replace.

**Piston pin outside diameter:****Standard**

19.995 ~ 20.000 mm  
(0.7872 ~ 0.7874 in)


**Limit**

19.98 mm (0.786 in)



## 3. Check:


- Free play (when the piston pin is in place in the piston)  
There should be no noticeable free play.  
Free play is noticeable → Replace piston pin and/or piston.



## 4. Check:

- Free play  
There should be no noticeable free play.  
Free play is noticeable → Inspect the connecting rod for wear/Replace the pin and/or connecting rod as required.


**ENGINE UNIT REMOVAL  
EXPLODED DIAGRAM**



**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
	<b>ENGINE UNIT REMOVAL</b>		Follow the left "Step" for removal. Refer to "FUEL TANK" in chapter 4.
1	Battery lead	2	
2	Handle switch lead coupler	2	
3	Electrical box	1	
4	Grease nipple plate	1	
5	Choke cable	1	
6	Throttle cable	1	
7	Exhaust hose	1	
8	Coupling cover	1	
9	Water inlet hose	1	
10	Pilot water hose	1	
11	Fuel hose (fuel filter - carburetor)	1	
12	Engine mounting bolt	4	
13	Shim	*	
14	Engine unit	1	
			Reverse the removal steps for installation.

\*: As required



## SERVICE POINTS

### Shim removal


1. Remove:
  - Shim

### NOTE:

Mark the engine mounting shim packs prior to the mounting bolt removal for ease of reassembly and coupling alignment.

### Mount bracket inspection

1. Inspect:
  - Mount bracket
  - Crack/Damage → Replace.



### Coupling clearance inspection

1. Check:
  - Clearance ①
  - Clearance ②
  - Out of specification → Adjust using shim.

### NOTE:

- Before measuring the clearance, remove the coupling rubber.
- Attach a straight edge and a thickness gauge.





Clearance ①:

0 ~ 1.0 mm (0 ~ 0.039 in)

Clearance ②:

2 ~ 4 mm (0.079 ~ 0.157 in)





**SERVICE POINTS**

**Coupling flange removal and installation**

1. Remove and install:
  - Coupling flange

	<p><b>Coupler wrench:</b>  <b>YW-38741/90890-06425</b></p> <p><b>Flywheel holder:</b>  <b>YB-06139/90890-06522</b></p>
--	--


**Flywheel magneto removal and installation**

1. Remove and install:
  - Bolt

	<p><b>Flywheel holder:</b>  <b>YB-06139/90890-06522</b></p>
--	---

2. Remove:
  - Flywheel magneto

	<p><b>Flywheel puller:</b>  <b>YB-06117/90890-06521</b></p>
--	---



**CAUTION:**

To prevent damage to the engine or tools, screw in the flywheel puller set-bolts evenly and completely so that the puller plate is parallel to the flywheel.

**Coupling flange inspection**

1. Inspect:
  - Coupling flange

Wear/Damage → Replace.

**Flywheel magneto inspection**

1. Inspect:
  - Flywheel gear


Wear/Damage → Replace.

**Idle gear assembly inspection**

1. Inspect:
  - Pinion gear **a**
  - Inner gear **b**


Wear/Damage → Replace.
2. Check:
  - Clutch movement

Unsmooth movement → Replace.






**ELECTRICAL UNIT  
EXPLODED DIAGRAM**




**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
	<b>ELECTRICAL UNIT REMOVAL</b>		
	Electrical box		Follow the left "Step" for removal. Refer to "ENGINE UNIT REMOVAL". Refer to "FLYWHEEL MAGNETO AND BASE".
	Base assembly		
1	Spark plug cap	2	
2	Thermo switch	1	
3	Starter motor negative lead	1	
4	Housing	1	
			Reverse the removal steps for installation.




**STARTER MOTOR  
EXPLODED DIAGRAM**



**REMOVAL AND INSTALLATION CHART**


Step	Procedure/Part name	Q'ty	Service points
	<b>STARTER MOTOR DISASSEMBLY</b>		
	Starter motor assembly		Follow the left "Step" for removal. Refer to "CRANKCASE".
1	Through bolt	2	
2	Front bracket	1	
3	Armature assembly	1	
4	Rear bracket	1	
5	Bolt	1	
6	Brush holder	1	
7	York assembly	1	
			Reverse the removal steps for installation.



**SERVICE POINTS**


**Pinion inspection**

1. Inspect:
  - Pinion teeth ①
  - Wear/Damage → Replace.




**Armature inspection**

1. Inspect:
  - Commutator
  - Dirty → Clean with #600 abrasive paper.




2. Measure:
  - Commutator diameter
  - Out of specification → Replace.

	<b>Commutator diameter:</b> Limit 27 mm (1.06 in)
--	--





3. Check:
  - Commutator undercut
  - Clog/Dirt → Clean.

**NOTE:** \_\_\_\_\_  
Remove all particles of mica and metal using compressed air.  
\_\_\_\_\_




4. Measure:
  - Commutator undercut
  - Out of specification → Replace.

	<b>Commutator undercut:</b> Limit 0.2 mm (0.01 in)
--	---



5. Inspect:
- Armature coil continuity  
Out of specification → Replace.


<b>Armature coil continuity:</b>	
<b>Commutator segments ①</b>	<b>Continuity</b>
<b>Segment - Laminations ②</b>	<b>Discontinuity</b>
<b>Segment - Shaft</b>	<b>Discontinuity</b>



**Brush holder inspection**


1. Measure:
- Brush length ①  
Out of specification → Replace.

	<b>Brush length: Limit 6.5 mm (0.26 in)</b>
--	---



2. Check:
- Brush holder continuity  
Out of specification → Replace.


<b>Brush holder continuity:</b>	
<b>Brush holder - Base</b>	<b>Discontinuity</b>



**Cover inspection**


1. Inspect:
- Cover bushing  
Wear/Damage → Replace the cover.

**CRANKCASE  
EXPLODED DIAGRAM**




**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
	<b>CRANKCASE DISASSEMBLY</b>		
	Base assembly		Follow the left "Step" for removal. Refer to "FLYWHEEL MAGNETO AND BASE".
	Piston		Refer to "PISTON".
1	Engine mount bracket	2	
2	Starter motor	1	
3	Bolt (with washer)	8	<b>NOTE:</b> _____
4	Crankcase	1	Tighten the bolts in sequence and in two steps of torque.
			Reverse the removal steps for installation.

**SERVICE POINTS****Crankcase inspection**

1. Inspect:
  - Contacting surface  
Scratch → Replace.
  - Crankcase  
Crack/Damage → Replace.


**Crankcase installation**

1. Apply:
  - Gasket Maker

**NOTE:** \_\_\_\_\_  
Clean the contacting surface of crankcase before applying the Gasket Maker.  
\_\_\_\_\_



2. Check:
  - Crankshaft  
Rough action → Repair.

**CRANKSHAFT  
EXPLODED DIAGRAM**



**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
1	<b>CRANKSHAFT REMOVAL</b>	1	Follow the left "Step" for removal. Refer to "CRANKCASE". <b>CAUTION</b> _____ ● Do not allow the bearing clip open ends to meet the crankcase contacting surface. ● Place the locating pins on the bearing into the crankcase body groove.
	Crankcase		
	Crankshaft assembly		
2	Dowel pin	5	
3	Oil seal	3	
			Reverse the removal steps for installation.




**SERVICE POINTS**

**Crankshaft inspection**

1. Measure:

- Crank width (A)  
Out of specification → Replace.


**Crank width:**  
61.95 ~ 62.00 mm  
(2.439 ~ 2.441 in)



2. Measure:

- Deflection (B)  
Use a dial gauge.  
Out of specification → Replace.


**Maximum deflection:**  
0.05 mm (0.002 in)



3. Measure:

- Big end side clearance (C)  
Use a thickness gauge.  
Out of specification → Replace.

**Big end side clearance:**  
0.25 ~ 0.75 mm  
(0.010 ~ 0.030 in)



4. Measure:

- Small end free play (D)  
Use a dial gauge.  
Out of specification → Replace.


**Small end free play:**  
2.0 mm (0.08 in)

5. Inspect:

- Crankshaft bearing  
Pitting/Damage → Replace.

**NOTE:**


Lubricate the bearings immediately after examining them to prevent rusting.



6. Inspect:

- Crankshaft oil seal  
Wear/Damage → Replace.

**INTERMEDIATE HOUSING REMOVAL  
EXPLODED DIAGRAM**




**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
	<b>INTERMEDIATE HOUSING REMOVAL</b>		Follow the left "Step" for removal.
	Engine unit		Refer to "ENGINE UNIT REMOVAL".
1	Bolt (with washer)	3	<b>NOTE:</b> _____ Install the previously marked shims back into their original location.
2	Shim	*	
3	Bearing housing assembly	1	Reverse the removal steps for installation.
4	Pin	2	

\*: As required




**INTERMEDIATE HOUSING  
EXPLODED DIAGRAM**



**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
	<b>INTERMEDIATE HOUSING DISASSEMBLY</b> Bearing housing assembly		Follow the left "Step" for removal.  Refer to "INTERMEDIATE HOUSING REMOVAL".
1	Coupling	1	 <b>Distance:</b> Ⓐ: 17.6 ~ 18.0 mm (0.69 ~ 0.71 in) Ⓑ: 6.4 ~ 7.2 mm (0.25 ~ 0.28 in) Ⓒ: 10.3 ~ 10.7 mm (0.41 ~ 0.42 in) Ⓓ: 1.6 ~ 2.0 mm (0.06 ~ 0.08 in) Ⓔ: 19.5 ~ 20.5 mm (0.77 ~ 0.81 in)
2	Shaft	1	
3	Oil seal	2	
4	Oil seal	1	
5	Clip	1	
6	Bearing	1	
7	Clip	1	
			Reverse the removal steps for installation.




**SERVICE POINTS**

**Coupling removal and installation**

1. Remove and install:
  - Coupling



**Coupler wrench:**  
**YW-38741/90890-06425**  
**Shaft holder:**  
**YW-38742/90890-06069**




**Bearing removal and installation**

1. Remove and install:
  - Bearing



**Driver rod:**  
**YB-06071/90890-06606**  
**Bearing outer race attachment:**  
**YB-06016/90890-06626**



**Bearing inspection**

1. Inspect:
  - Bearing
    - Rotate inner race by hand.
    - Rough spots/Seizure → Replace.
  - Shaft
    - Pitting/Damage → Replace.
  - Hose
    - Wear/Cracks → Replace.

**Coupling inspection**


1. Inspect:
  - Coupling flange
  - Coupling rubber
    - Wear/Damage → Replace.

**Oil seal installation**

1. Install:
  - Oil seal [T = 10 mm (0.38 in)]





**Driver rod:**  
**YB-06071/90890-06606**  
**Bearing outer race attachment:**  
**YB-06016/90890-06626**



**NOTE:** \_\_\_\_\_


Fill the with water resistant grease clip inner circumference before installing the oil seal.



2. Install:

- Shaft

	<b>Distance ①:</b>
	<b>19.5 ~ 20.5 mm (0.77 ~ 0.81 in)</b>



3. Install:

- Oil seal

	<b>Distance ①:</b>
	<b>10.3 ~ 10.7 mm (0.41 ~ 0.42 in)</b>
	<b>Distance ②:</b>
	<b>1.6 ~ 2.0 mm (0.06 ~ 0.08 in)</b>

**NOTE:**

Fill the with water resistant grease clip inner circumference before installing the oil seal.

4. Fill:


- Shaft

	<b>Water resistant grease:</b>
	<b>8 cm<sup>3</sup> (0.5 cu.in)</b>

## **CHAPTER 6 JET PUMP UNIT**

<b>JET PUMP UNIT REMOVAL</b> .....	6-1
EXPLODED DIAGRAM .....	6-1
REMOVAL AND INSTALLATION CHART.....	6-1
<b>DEFLECTOR, NOZZLE AND DUCT</b> .....	6-2
EXPLODED DIAGRAM .....	6-2
REMOVAL AND INSTALLATION CHART.....	6-2
<b>IMPELLER AND DRIVE SHAFT</b> .....	6-3
EXPLODED DIAGRAM .....	6-3
REMOVAL AND INSTALLATION CHART.....	6-3
SERVICE POINTS .....	6-4
Impeller removal .....	6-4
Drive shaft and bearing removal .....	6-4
Impeller inspection .....	6-4
Drive shaft inspection .....	6-4
Bearing inspection.....	6-4
Oil seal and bearing installation.....	6-5
Impeller installation.....	6-5
<b>BILGE SYSTEM</b> .....	6-6
EXPLODED DIAGRAM .....	6-6
REMOVAL AND INSTALLATION CHART.....	6-6
SERVICE POINTS .....	6-6
Bilge strainer inspection .....	6-6
Hose inspection .....	6-6

**JET PUMP UNIT REMOVAL  
EXPLODED DIAGRAM**




**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
	<b>JET PUMP UNIT REMOVAL</b>		Follow the left "Step" for removal.
1	Ride plate	1	<p><b>NOTE:</b> _____ Mark jet pump mounting shim packs prior to the mounting bolt removal for ease of reassembly.</p> <p><b>NOTE:</b> _____ Pull the jet pump unit until upward (if the hull is upside down) to release it from the knock pins and pull it straight backward.</p> <p>Reverse the removal steps for installation.</p>
2	Steering cable joint	1	
3	Water hose	2	
4	Shim	*	
5	Jet pump unit	1	

\*: As required


**DEFLECTOR, NOZZLE AND DUCT  
EXPLODED DIAGRAM**



**REMOVAL AND INSTALLATION CHART**


Step	Procedure/Part name	Q'ty	Service points
	<b>DEFLECTOR, NOZZLE AND DUCT REMOVAL</b>		Follow the left "Step" for removal.
	Jet pump unit		Refer to "JET PUMP UNIT REMOVAL".
1	Nozzle deflector assembly	1	
2	Bolt	4	
3	Housing	1	
4	Pin	2	
5	Impeller duct assembly	1	
6	Pin	1	
7	Nozzle	1	
			Reverse the removal steps for installation.

**IMPELLER AND DRIVE SHAFT  
EXPLODED DIAGRAM**



**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
	<b>IMPELLER AND DRIVE SHAFT DISASSEMBLY</b>		Follow the left "Step" for removal.
	Impeller duct assembly		Refer to "DEFLECTOR, NOZZLE AND DUCT".
1	Impeller	1	<b>NOTE:</b> _____ The impeller has a left-hand thread. Turn the impeller clockwise to loosen it.
2	Cap	1	
3	Drive shaft assembly	1	
4	Bearing (rear)	1	
5	Drive shaft	1	
6	Bearing (front)	1	
7	Oil seal	2	
			Reverse the removal steps for installation.




**SERVICE POINTS**

**Impeller removal**

1. Remove:
  - Impeller




**Drive shaft holder:**  
YB-06049/90890-06518



**Drive shaft and bearing removal**

1. Remove:
  - Drive shaft and bearing (rear) ①
  - Bearing (rear) ②

**NOTE:** \_\_\_\_\_  
Use a press.



2. Remove:
  - Bearing (front)



**Slide hammer set:**  
90890-06523  
YB-06096/90890-06531

**Impeller inspection**


Refer to "JET PUMP UNIT" in chapter 3.

**Drive shaft inspection**

1. Inspect:
  - Drive shaft
 Wear/Damage → Replace.

**Bearing inspection**


1. Inspect:
  - Bearing (front and rear)
 Rotate inner race by hand.  
Rough spot/Seizure → Replace.



**Oil seal and bearing installation**


1. Install:
  - Oil seal

	<b>Driver rod:</b> YB-06071/90890-06606 <b>Ball bearing attachment:</b> YB-06156/90890-06634
---	---



2. Install:
  - Bearing (front)
  - Drive shaft and bearing

**NOTE:** \_\_\_\_\_  
 Use a press.




3. Fill:
  - Between the drive shaft and duct

	<b>Water resistant grease:</b> 24 cm <sup>3</sup> (1.45 cu. in)
---	--


4. Install:
  - Bearing (rear)

	<b>Bearing inner race attachment:</b> YB-34474/90890-06662
---	---



5. Fill:
  - Into the cap

	<b>Water resistant grease:</b> 21 cm <sup>3</sup> (1.3 cu. in)
---	---




**Impeller installation**

1. Install:
  - Impeller

	<b>Drive shaft holder:</b> YB-06049/90890-06518
---	--

**BILGE SYSTEM  
EXPLODED DIAGRAM**



**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
<b>BILGE SYSTEM REMOVAL</b>			Follow the left "Step" for removal.  Reverse the removal steps for installation.
1	Bilge strainer	1	
2	Bilge hose	1	
3	Hose joint	1	

**SERVICE POINTS**

**Bilge strainer inspection**

Refer to "JET PUMP UNIT" in chapter 3.

**Hose inspection**

1. Inspect:

- Hose

Crack/Wear/Damage → Replace.

# CHAPTER 7 ELECTRICAL SYSTEM

**ELECTRICAL COMPONENTS** ..... 7-1

**ELECTRICAL ANALYSIS** ..... 7-2

    INSPECTION ..... 7-2

        Low resistance measurement ..... 7-2

**IGNITION SYSTEM** ..... 7-3

    WIRING DIAGRAM ..... 7-3

    IGNITION SPARK GAP ..... 7-4

    SPARK PLUG ..... 7-5

    SPARK PLUG CAP ..... 7-5

    IGNITION COIL ..... 7-5

    ENGINE STOP SWITCH ..... 7-6

    CHARGE COIL ..... 7-6

    PULSER COIL ..... 7-6

    THERMO SWITCH ..... 7-7

    CDI UNIT ..... 7-7

**STARTING SYSTEM** ..... 7-8

    WIRING DIAGRAM ..... 7-8

    BATTERY ..... 7-9

    STARTER MOTOR ..... 7-9

    WIRING CONNECTION ..... 7-9

    FUSE ..... 7-9

    STARTER SWITCH ..... 7-9

    STARTER RELAY ..... 7-10

**CHARGING SYSTEM** ..... 7-11

    WIRING DIAGRAM ..... 7-11


    FUSE ..... 7-12

    BATTERY ..... 7-12

    LIGHTING COIL ..... 7-12

    RECTIFIER REGULATOR ..... 7-12

**ELECTRICAL COMPONENTS**



- 1 Flywheel magneto base lead
- 2 Handle switch lead
- 3 Thermo sensor lead
- 4 Battery (positive) lead
- 5 Starter motor (positive) lead

- 6 High tension cord
- 7 Battery (negative) lead
- 8 2P connector (Black)
- 9 2P connector (White)

**ELECTRICAL ANALYSIS  
INSPECTION**

**CAUTION:**

All measuring instruments should be handled with special care, or correct measurement is impossible.

On an instrument powered by dry batteries, the batteries' voltage should be checked periodically and the batteries replaced, if necessary.

**NOTE:**

"○—○" indicates the terminals between which there is electrical continuity; i.e., a closed circuit in the given switch position.

**Low resistance measurement**


When measuring resistance of 10 Ω or less using the digital tester, the correct measurement cannot be obtained because of the tester's internal resistance.

To obtain the correct value, subtract this internal resistance from the displayed measurement.


	<b>Correct value = Displayed measurement - Internal resistance</b>
---	--

**NOTE:**

The internal resistance of the tester can be obtained by connecting both of its terminals.








**IGNITION SYSTEM  
WIRING DIAGRAM**



- ① Pulser coil
- ② Charge coil
- ③ CDI unit
- ④ Stop switch
- ⑤ Engine stop switch
- ⑥ Thermo switch
- ⑦ Ignition coil

- B : Black
- Br/W: Brown/White
- O : Orange
- P : Pink
- W : White
- W/R : White/Red



## IGNITION SPARK GAP

### ⚠ WARNING

- While making a spark check be careful not to touch any of the "Ignition spark gap tester" lead wires.
- When doing the spark test, take special care not to allow leakage from the removed plug cap.
- This check is likely to produce sparks, so be sure that no flammable gas or fluid is in the vicinity.

#### 1. Check:

- Ignition spark gap  
Out of specification → Replace.



**Spark gap:**  
9 mm (0.35 in)


#### Checking steps:

- Adjust the spark gap to specification by turning the adjusting knob.



**Spark gap tester:**  
YM-34487/90890-06754

- Connect the spark plug cap to the spark gap tester.
- Remove the spark plugs from the engine.
- Crank the engine and check the sparks from the ignition system through the discharge window.




## SPARK PLUG

Refer to "GENERAL" in CHAPTER 3.

## SPARK PLUG CAP

1. Inspect:
  - Spark plug cap
    - Loosen → Tighten.
    - Crack/Damage → Replace.



## IGNITION COIL

1. Inspect:
  - High tension cord
    - Cracks/Damage → Replace.
2. Measure:
  - Primary coil resistance
    - Out of specification → Replace.



**Primary coil resistance:**  
**Orange (O) – Black (B)**  
 0.078 ~ 0.106  $\Omega$  at 20°C (68°F)

### NOTE:

When measuring the resistance of 10  $\Omega$  or less using the digital tester, the correct measurement cannot be obtained. Refer to "Lower resistance measurement".


3. Measure:
  - Secondary coil resistance
    - Out of specification → Replace.



**Secondary coil resistance:**  
**High tension cords**  
 3.5 ~ 4.7 k $\Omega$  at 20°C (68°F)

### NOTE:


Remove the spark plug cap from the high tension cord.



**ENGINE STOP SWITCH**

1. Check:
- Continuity
- Out of specification → Replace.


		Leads	
		White	Black
<b>Installed</b>	<b>Free</b>		
	<b>Push</b>	○—○	○—○
<b>Removed</b>	<b>Free</b>	○—○	○—○
	<b>Push</b>	○—○	○—○



**CHARGE COIL**

1. Measure:
- Charge coil resistance
- Out of specification → Replace.




	<p><b>Charge coil resistance:</b>  <b>Brown/White (Br/W) – Black (B)</b>  <b>497.7 ~ 608.3 Ω at 20°C (68°F)</b></p>
---	---



**PULSER COIL**

1. Measure:
- Pulser coil resistance
- Out of specification → Replace.

	<p><b>Pulser coil resistance:</b>  <b>White/Red (W/R) – Black (B)</b>  <b>12.6 ~ 15.4 Ω at 20°C (68°F)</b></p>
---	--



**THERMO SWITCH**

1. Measure:

- Thermo switch continuity
- Out of specification → Replace.

**Thermo switch continuity temperature:**  
**Pink (P) – Black (B)**  
 Ⓐ 76 ~ 84°C (169 ~ 183 °F)  
 Ⓑ 63 ~ 77°C (145 ~ 171 °F)

- ① Discontinuity      Ⓐ Temperature
- ② Continuity        Ⓑ Time

**Measurement steps:**

- Suspend thermostat in a vessel.
- Place known reliable thermometer in water.
- Heat water slowly.
- Observe thermometer, while stirring water continually.

**CDI UNIT**

1. Measure:

- CDI unit resistance
- Out of specification → Replace.

**Pocket tester:**  
**YU-03112/90890-03112**


- NOTE:**
- The resistance values will vary from meter to meter, especially with electronic digital meters. For some testers, the polarity of the leads is reversed.
  - The needle swings once to the “•” mark and then returns to the home position.
  - The “∞” mark stands for discontinuity.

62T00


Unit: kΩ

⊕	⊖	B	Br/W	O	P	W	W/R
B			2~6	•	3~11	10~40	150~600
Br/W		20~80		•	50~200	15~60	250 ~ 1000
O		•	•		•	•	•
P		∞	∞	∞		∞	∞
W		∞	∞	∞	∞		∞
W/R		9~36	17~70	•	10~40	50~200	

- B : Black
- Br/W: Brown/White
- O : Orange
- L : Blue
- P : Pink
- W : White
- W/R : White/Red



**STARTING SYSTEM  
WIRING DIAGRAM**



- ① Fuse
- ② Engine stop switch
- ③ Starter switch
- ④ Battery
- ⑤ Starter motor
- ⑥ Starter relay

B : Black  
 Br : Brown  
 R : Red

**BATTERY**

Refer to "GENERAL" in chapter 3.

**STARTER MOTOR**

Refer to "STARTER MOTOR" in chapter 5.


**WIRING CONNECTION**

1. Check:
  - Wiring connection
  - Poor connection → Correct.

**FUSE**

1. Check:
  - Fuse
  - Blown → Replace.


	<b>Fuse rating:</b> 12 V/10 A
---	----------------------------------



**STARTER SWITCH**

1. Check:
  - Continuity
  - Out of specification → Replace.


	<b>Starter continuity:</b> (White coupler)		
Lock plate	Position	Leads	
		Red	Brown
Installed	Free		
	Push	○ — ○	
Removed	Free		
	Push		



## STARTER RELAY

### 1. Inspect:

- Brown lead terminal
  - Black lead terminal
- Loose → Tighten.



### 2. Check:


- Relay operation
- Does not function → Replace.

#### Checking steps:


- Connect the tester between the terminals of the starter relay as shown.
- Connect a 12 V battery.

**Brown lead ① → Positive terminal**  
**Black lead ② → Negative terminal**

- Check that there is continuity between the starter relay terminals.



**CHARGING SYSTEM  
WIRING DIAGRAM**



- ① Fuse
- ② Battery
- ③ Lighting coil
- ④ Rectifier regulator


- B : Black
- G : Green
- R : Red

**FUSE**

Refer to "STARTING SYSTEM".

**BATTERY**

Refer to "ELECTRICAL" in chapter 3.



**LIGHTING COIL**

1. Measure:

- Lighting coil resistance  
Out of specification → Replace.



**Lighting coil resistance:**  
Green (G) – Green (G)  
1.14 ~ 1.40 Ω at 20°C (68°F)

**NOTE:**

When measuring the resistance of 10 Ω or less using the digital tester, the correct measurement cannot be obtained. Refer to "Lower resistance measurement".

**RECTIFIER REGULATOR**

1. Check:

- Continuity  
Out of specification → Replace.



**Pocket tester:**  
YU-03112/90890-03112

∞: Discontinuity

Unit: kΩ

⊕	⊖	R	B	G	G
R			∞	∞	∞
B		2~20		1~10	1~10
G		1~10	2~15		3~30
G		1~10	2~15	3~30	


## **CHAPTER 8 HULL AND HOOD**

<b>BATTERY CASE AND WATER LOCK</b> .....	8-1
EXPLODED DIAGRAM .....	8-1
REMOVAL AND INSTALLATION CHART.....	8-1
SERVICE POINTS .....	8-2
Exhaust system inspection .....	8-2
<b>HANDLE</b> .....	8-3
EXPLODED DIAGRAM .....	8-3
REMOVAL AND INSTALLATION CHART.....	8-3
SERVICE POINTS .....	8-4
Handle inspection.....	8-4
Handle switch installation.....	8-4
Handle holder installation.....	8-4
<b>HANDLE COLUMN</b> .....	8-5
EXPLODED DIAGRAM .....	8-5
REMOVAL AND INSTALLATION CHART.....	8-5
SERVICE POINTS .....	8-6
Column bushing inspection.....	8-6
Handle column inspection .....	8-6
<b>STEERING CABLE</b> .....	8-7
EXPLODED DIAGRAM .....	8-7
REMOVAL AND INSTALLATION CHART.....	8-7
SERVICE POINTS .....	8-8
Cable inspection .....	8-8
Cable joint installation .....	8-8
<b>THROTTLE CABLE AND CHOKE CABLE</b> .....	8-9
EXPLODED DIAGRAM .....	8-9
REMOVAL AND INSTALLATION CHART.....	8-9
SERVICE POINTS .....	8-10
Cable inspection .....	8-10
Cable installation .....	8-10
<b>STEERING POLE</b> .....	8-11
EXPLODED DIAGRAM .....	8-11
REMOVAL AND INSTALLATION CHART.....	8-11
SERVICE POINTS .....	8-12
Pivot inspection .....	8-12

---

<b>STEERING POLE BRACKET</b> .....	8-13
EXPLODED DIAGRAM .....	8-13
REMOVAL AND INSTALLATION CHART.....	8-13
SERVICE POINTS .....	8-14
Steering pole bracket inspection.....	8-14
<b>ENGINE HOOD</b> .....	8-15
EXPLODED DIAGRAM .....	8-15
REMOVAL AND INSTALLATION CHART.....	8-15
SERVICE POINTS .....	8-16
Hood lock hook inspection .....	8-16
Engine hood inspection .....	8-16
<b>DECK</b> .....	8-17
EXPLODED DIAGRAM .....	8-17
REMOVAL AND INSTALLATION CHART.....	8-17
<b>GUNWALE</b> .....	8-18
EXPLODED DIAGRAM .....	8-18
REMOVAL AND INSTALLATION CHART.....	8-18
<b>MAT</b> .....	8-19
EXPLODED DIAGRAM .....	8-19
REMOVAL AND INSTALLATION CHART.....	8-19
SERVICE POINTS .....	8-19
Mat installation .....	8-19
<b>HULL</b> .....	8-20
EXPLODED DIAGRAM .....	8-20
REMOVAL AND INSTALLATION CHART.....	8-20
HULL REPAIR.....	8-21
Light scratching .....	8-21
Deep scratching .....	8-21
Hull damage (punctured) .....	8-22
Insert nut .....	8-23
Removing a graphic .....	8-25
Applying a graphic .....	8-25

**BATTERY CASE AND WATER LOCK  
EXPLODED DIAGRAM**



**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
	<b>BATTERY CASE AND WATER LOCK REMOVAL</b>		Follow the left "Step" for removal.
1	Battery	1	
2	Battery case	1	
3	Clamp	2	
4	Exhaust hose	2	
5	Water lock	1	
			Reverse the removal steps for installation.




**SERVICE POINTS**

**Exhaust system inspection**

1. Inspect:
  - Band  
Crack → Replace.
2. Inspect:
  - Exhaust hose  
Crack/Wear/Burn → Replace.
3. Inspect:
  - Water lock  
Crack/Leak → Replace.  
Gathered water → Drain.

**HANDLE  
EXPLODED DIAGRAM**




**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
<b>HANDLE REMOVAL</b>			Follow the left "Step" for removal.
1	Steering pad	1	<b>NOTE:</b> _____ Disconnect the throttle cable from the throttle lever. _____
2	Handle cover	2	
3	Handle switch	1	
4	Throttle cable	1	
5	Handle holder	2	Reverse the removal steps for installation.
6	Handlebar	1	

**SERVICE POINTS**

**Handle inspection**


1. Inspect:
  - Handlebar  
Bend/Crack/Damage → Replace.



**Handle switch installation**

1. Install:
  - Handle switch

**NOTE:** \_\_\_\_\_  
Tighten the screw at the stop button side first.




**Handle holder installation**

1. Install:
  - Handle holder

**NOTE:** \_\_\_\_\_  
Tighten the bolt at stern side first.

**HANDLE COLUMN  
EXPLODED DIAGRAM**



**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
	<b>HANDLE COLUMN REMOVAL</b>		Follow the left "Step" for removal. Refer to "HANDLE".
	Handlebar assembly		
1	Steering cable joint	1	
2	Nut	2	
3	Plane washer	1	
4	Column bushing	2	
5	Handle column	1	
6	Ball joint	1	
			Reverse the removal steps for installation.



---

**SERVICE POINTS**


**Column bushing inspection**

1. Inspect:
  - Column bushing  
Wear/Damage → Replace.

**Handle column inspection**

1. Inspect:
  - Handle column  
Bend/Crack/Damage → Replace.

**STEERING CABLE  
EXPLODED DIAGRAM**




**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
	<b>STEERING CABLE REMOVAL</b>		Follow the left "Step" for removal.
	Ride plate		Refer to "JET PUMP UNIT REMOVAL" in chapter 6.
	Handle cover		Refer to "HANDLE".
1	Cable joint	2	
2	Cable stopper	1	
3	Grommet	1	
4	Steering cable	1	
			Reverse the removal steps for installation.

**SERVICE POINTS**

**Cable inspection**

1. Inspect:
  - Steering cableKink/Fray/Stick → Replace.



**Cable joint installation**


1. Install:
  - Cable joint

	<b>Cable joint set length ③:</b> <b>Jet pump side</b> <b>12.8 ~ 14.4 mm (0.50 ~ 0.57 in)</b>
---	--

**⚠ WARNING**

The cable joint must be screwed in more than 8 mm (0.31 in).

**THROTTLE CABLE AND CHOKE CABLE  
EXPLODED DIAGRAM**




**REMOVAL AND INSTALLATION CHART**


Step	Procedure/Part name	Q'ty	Service points
<b>THROTTLE CABLE REMOVAL</b>			Follow the left "Step" for removal. Refer to "HANDLE".
	Handle cover		
1	Lock nut	1	
2	Grommet	1	 <b>Cable guide set position @: 17 mm (0.67 in)</b>
3	Throttle cable	1	
<b>CHOKE CABLE REMOVAL</b>			
4	Choke knob	1	
5	Lock nut	1	
6	Choke cable	1	
			Reverse the removal steps for installation.

**SERVICE POINTS****Cable inspection**

1. Inspect:
  - Throttle cable
  - Choke cableKink/Fray/Stick → Replace.


**Cable installation**

1. Install:
  - Cable guide



2. Check:
  - Throttle cable
  - Choke cableFree play → Repair.  
Refer to "CONTROL SYSTEM" in chapter 3.

**STEERING POLE  
EXPLODED DIAGRAM**



**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
	<b>STEERING POLE REMOVAL</b>		Follow the left "Step" for removal. Refer to "HANDLE".
1	Handle switch lead	1	
2	Steering cable	1	
3	Bow cover	1	
4	Shaft bolt	1	
5	Pivot spring	1	
6	Steering pole	1	
			Reverse the removal steps for installation.



---

**SERVICE POINTS**


**Pivot inspection**

1. Inspect:

- Shaft bolt
- Bushing
- Plain washer
- Pivot spring

Crack/Wear/Damage → Replace.

**STEERING POLE BRACKET  
EXPLODED DIAGRAM**



**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
	<b>STEERING POLE BRACKET DISASSEMBLY</b>		Follow the left "Step" for removal.
	Steering pole		Refer to "STEERING POLE".
1	Nylon nut	4	
2	Steering pole bracket assembly	1	
3	Stopper rubber	1	
4	Grommet	1	
5	Stopper pin	1	
6	Stopper	4	
7	Plate	2	
			Reverse the removal steps for installation.




**SERVICE POINTS**

**Steering pole bracket inspection**

1. Inspect:

- Stopper rubber
- Stopper pin
- Stopper
- Steering pole bracket  
Crack/Wear/Damage → Replace.

**ENGINE HOOD  
EXPLODED DIAGRAM**



**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
<b>ENGINE HOOD DISASSEMBLY</b>			Follow the left "Step" for removal.
1	Stopper	2	<b>NOTE:</b> _____ Align the hose protrusion with hose joint protrusion. _____
2	Plate	1	
3	Fire extinguisher box assembly	1	
4	Damper	1	
5	Hook	1	
6	Ventilator hose	2	
7	Engine hood	1	Reverse the removal steps for installation.



**SERVICE POINTS**


**Hood lock hook inspection**

1. Inspect:
  - Hood lock hook  
Bend/Damage → Replace.

**Engine hood inspection**

1. Inspect:
  - Engine hood  
Crack/Damage → Replace.


**DECK  
EXPLODED DIAGRAM**



**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
<b>DECK DISASSEMBLY</b>			Follow the left "Step" for removal.
1	Hood packing	1	<p><b>NOTE:</b> _____</p> <ul style="list-style-type: none"> <li>● Clean the seal rubber groove of the deck.</li> <li>● Apply cyano-acrylate adhesive on the seal rubber.</li> </ul>
2	Lock packing	1	
3	Hood lock	1	
4	Choke knob	1	
5	Fuel cock knob	1	
6	Bow mat	1	
			Reverse the removal steps for installation.


**GUNWALE  
EXPLODED DIAGRAM**



**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
<b>GUNWALE REMOVAL</b>			Follow the left "Step" for removal.
1	Cap nut	4	
2	Rope hole bolt	1	
3	Bow gunwale	1	
4	Stern gunwale	2	
5	Inner gunwale	1	
6	Cover gunwale	1	
7	Side gunwale	2	
			Reverse the removal steps for installation.

**MAT  
EXPLODED DIAGRAM**



**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
	<b>MAT REMOVAL</b>		Follow the left "Step" for removal.
1	Pad	2	
2	Upper mat	2	
3	Rope hole bolt	1	
4	Step mat	1	
			Reverse the removal steps for installation.

**SERVICE POINTS**


**Mat installation**

1. Install:
  - Mat

**NOTE:** \_\_\_\_\_

- Clean the riding tray surface before installing the mat.
- Apply cyanoacrylate adhesive on the mat.

**HULL  
EXPLODED DIAGRAM**




**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
	<b>HULL DISASSEMBLY</b>		Follow the left "Step" for removal.
1	Pilot water hose Nut	1	
2	Pilot water plug	1	
			Reverse the removal steps for installation.

**HULL REPAIR**

**Light scratching**

1. Sand the scratched area smooth with #400 grit wet or dry paper, and then with #600 grit wet or dry paper.
2. Polish the area with rubbing compound and buff to a high gloss using a wool pad and automotive wax.







**Deep scratching**

1. Remove any sharp/rough edges from the surface.
2. Sand the area smooth for about one inch all around the scratch with #80 grit wet or dry paper.
3. Clean the area with acetone and dry it.
4. Mix gel-coat with gel-coat thickener to make gel-coat putty and then add the catalyst to make.
5. Apply and spread the catalyzed putty with a squeegee, then cover the putty with a piece of waxed paper.
6. When the putty has set, sand the area catalyzed putty. Smooth using #80 grit to #400 grit wet or dry paper and a sanding block.
7. Clean the area with a dry cloth and polish it.

**⚠ WARNING**



**Resin, catalyst and solvent are flammable and toxic. Use only in a well-ventilated area and keep away from open flames and sparks. Observe all warnings given by the manufacturer.**



**Hull damage (punctured)**

1. Remove any damaged fiberglass.
2. Cut and open the crack approximately 1/4 inch.
3. Grind the opened edge less than 30° on the outside.
4. Grind the area from inside the hull approximately 4 inches beyond it.
5. Clean the area with acetone, apply BP-1 or an equivalent primer on both sides of the area and cure for 1/2 hour.
6. Tape a piece of cardboard covered with waxed paper ① over the damaged area.
7. Mix polyester resin and catalyst and apply it to the hull.
8. Apply a glass mat ② (2 inches smaller than the ground area).
9. Apply catalyzed resin.
10. Apply a 20 oz fiberglass cloth ③ (1 inch smaller than the glass mat).
11. Apply catalyzed resin.
12. Apply a final glass mat ④ (1 inch smaller than the ground area).
13. When the resin has hardened, remove the piece of cardboard.
14. Finish the outer surface using steps 3 - 7 in the "Deep scratching" section.

**NOTE:** \_\_\_\_\_  
 Refer to the "WATER VEHICLE FRP REPAIR MANUAL".  
 \_\_\_\_\_



**Insert nut**

**NOTE:** \_\_\_\_\_

When a pop nut clinched to a hull slipped off or when a bolt fastened to an insert nut or pop nut was broken, use this insert nut.



Part No.	Part Name	Remarks
EW2-62733-09	nut	Stainless steel, M6

- Nut ①
- Direction of thread ②
- Slot to be threaded ③

**NOTE:** \_\_\_\_\_

**Drilling size**

Material	Pilot hold diameter
FRP or SMC	9.1 ~ 9.2 mm (0.36 in)
Brass	9.4 mm (0.37 in)



**Example 1:**

The nut is used to repair the pop nut designed for plate 2.

(by repairing the FRP portion, the new-type nut can be used for all models)


For details of repairs to the FRP portion, refer to the "Water Vehicle FRP Repair Manual".

1. Remove:
  - Pop nut
2. Scarf the shaded portion.
3. Clean the surface to be scarfed and the inside of the hull with acetone.
4. As shown, first tape up the inner surface of the hull and then laminate fiberglass mats over the tape using a resin.

**NOTE:** \_\_\_\_\_

When it is possible to work inside the hull, the mats should be laminated from the inside.

5. Smooth out the out surface by sanding it.
6. Install plate 2. Then, using a 9.2 mm (0.36 in) diameter drill, make a hole of depth 20 mm (0.79 in) in the center of the laminated fiberglass layers.
7. Pass the bolt ① through the insert nut, as shown, and lock the bolt with the nut ②. Screw in the insert nut so that the top is flush with the FRP surface. Loosen the lock nut and remove the bolt.




**CAUTION:**

- The bolt should be made of steel and its strength should be 8T or more.
- If the bolt is inferior in strength, or is made of stainless steel, it may break.


- Bolt ① <Strength is 8T or more>
- Lock nut ②

- Example 2:**  
The brass insert nut designed for the Super Jet Plate 2 or the screen intake is used:
1. If the bolt is broken, remove it using drills.

**NOTE:**  
Use a small-diameter drill first, followed by drills of gradually increasing diameter.



2. Use a 9.4 mm (0.37 in) drill for the final drilling.
3. Apply silicone sealant to the inside of the hole so that no water can enter the urethane foam.
4. As in Example 1 above, screw in the insert nut.
  - Brass insert ①
  - Hull ②
  - Urethane foam ③
  - Silicone sealant ④



**Removing a graphic**

1. Remove:
  - Graphic ①

**NOTE:**

- Using a hair dryer, start at one corner and blow heat the graphic, holding the heat source at least 1-1/2" above the graphic.
- Slowly peel off the heated part and continue working towards the other side.

**2. Clean:**

Once the graphic is removed, clean the entire bow area with Isopropyl Alcohol to remove any residual adhesive.


**Applying a graphic**

**1. Preparation:**

Mix 1 tablespoon of liquid washing-up detergent with water in a 1qt spray bottle. Remove the backing from the new graphic and spray both sides and the area of the hull to which it is to be fitted.

**NOTE:**

Spraying the front of the graphic will protect it from being scratched during application.



**2. Apply:**

Align the graphic on the fitting area and smooth it into position with a small rubber squeegee, removing all air bubbles in the process. Begin at the top of the graphic and work down and outwards from the center line of the graphic area.

**3. Dry:**

Let the graphic dry in place prior to waxing or using the vehicle.

---

**CHAPTER 9**  
**TROUBLE ANALYSIS**

**TROUBLE ANALYSIS** ..... 9-1  
**TROUBLE ANALYSIS CHART** ..... 9-1

**TROUBLE ANALYSIS**

**NOTE:**

- Following items should be obtained before "trouble analysis".
1. Battery is charged and its specified gravity is in specification.
  2. There is no incorrect wiring connection.
  3. Wiring connections are surely engaged and without any rust.
  4. Lanyard is installed to the engine stop switch.
  5. Fuel is coming to the carburetor.

**TROUBLE ANALYSIS CHART**

Trouble mode										Check elements		
ENGINE WILL NOT START	ROUGH IDLING	ENGINE STALLS	ENGINE WILL NOT STOP	POOR PERFORMANCE	OVERHEATING	LOOSE STEERING	BILGE INCREASE	POOR BATTERY CHARGING			Relative part	Reference Chapter
										<b>FUEL SYSTEM</b>		
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>							Fuel tank	4
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>							Air vent hose	4
<input type="radio"/>		<input type="radio"/>		<input type="radio"/>							Fuel hose	4
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>							Fuel filter	4
<input type="radio"/>		<input type="radio"/>		<input type="radio"/>							Fuel pump	4
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>							Carburetor	4
	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>							Low speed screw setting	4
		<input type="radio"/>		<input type="radio"/>							High speed screw setting	4
		<input type="radio"/>		<input type="radio"/>							Carburetor synchronization	4
		<input type="radio"/>		<input type="radio"/>							Trolling speed	3
										<b>POWER UNIT</b>		
<input type="radio"/>	<input type="radio"/>			<input type="radio"/>							Compression	5
<input type="radio"/>	<input type="radio"/>			<input type="radio"/>							Reed valve	5
<input type="radio"/>	<input type="radio"/>										Cylinder head gasket	5
<input type="radio"/>				<input type="radio"/>							Piston ring	5
<input type="radio"/>				<input type="radio"/>							Cylinder block	5
<input type="radio"/>				<input type="radio"/>							Seal	5
<input type="radio"/>				<input type="radio"/>							Crank case	5
<input type="radio"/>				<input type="radio"/>							Piston	5
<input type="radio"/>				<input type="radio"/>							Bearing	5
<input type="radio"/>				<input type="radio"/>							Intermediate housing	5
				<input type="radio"/>							Coupling	5
				<input type="radio"/>							Coupling rubber	5
					<input type="radio"/>		<input type="radio"/>				Pilot water hose	5

Trouble mode										Check elements		
ENGINE WILL NOT START	ROUGH IDLING	ENGINE STALLS	ENGINE WILL NOT STOP	POOR PERFORMANCE	OVERHEATING	LOOSE STEERING	BILGE INCREASE	POOR BATTERY CHARGING			Relative part	Reference Chapter
					<input type="radio"/>		<input type="radio"/>				Water hose	5
					<input type="radio"/>		<input type="radio"/>				Water passage	5
<b>JET PUMP UNIT</b>												
				<input type="radio"/>	<input type="radio"/>		<input type="radio"/>				Duct	6
				<input type="radio"/>							Impeller	6
				<input type="radio"/>							Intake screen	6
				<input type="radio"/>							Bearing	6
				<input type="radio"/>							Duct intake	6
					<input type="radio"/>		<input type="radio"/>				Water inlet hose	6
							<input type="radio"/>				Bilge hose	6
							<input type="radio"/>				Bilge strainer	6
							<input type="radio"/>				Bilge hose joint	6
							<input type="radio"/>				Valve body	6
<b>ELECTRICAL</b>												
<input type="radio"/>						Ignition system	7					
<input type="radio"/>											Starting system	7
								<input type="radio"/>			Charging system	7
<b>HULL AND HOOD</b>												
						<input type="radio"/>					Column bushing	8
				<input type="radio"/>			<input type="radio"/>				Water lock	8
				<input type="radio"/>			<input type="radio"/>				Exhaust hose	8

**PROTECT YOUR INVESTMENT**  
**Use Genuine YAMAHA Parts And Accessories**

4/25/2000

LIBRARY COPY

**DO NOT REMOVE THIS ITEM FROM  
THE YAMAHA LIBRARY!**

**LIT-18616-01-43**



**SJ700(U-W) 1996 Service  
Manual**



LIT-18616-01-43