



D0240 Switch, Control Assembly Master Electrical - Replace	D1808 Actuator And/Or Motor, Electric - Mode Valve - Replace
D1200 Ambient Air Temperature Sensor Replacement	D1810 Air Inlet Valve Actuator Replacement
D1203 Sensor, Sun - Replace	N6642 HVAC System Wiring and/or Connector Repair or Replacement