



---

## Sensing and Diagnostic Module Handling Caution

**CAUTION:** Be careful when you handle a sensing and diagnostic module (SDM). Do not strike or jolt the SDM. Before applying power to the SDM:

- Remove any dirt, grease, etc. from the mounting surface
- Position the SDM horizontally on the mounting surface
- Point the arrow on the SDM toward the front of the vehicle
- Tighten all of the SDM fasteners and SDM bracket fasteners to the specified torque value

**Failure to follow the correct procedure could cause air bag deployment, personal injury, or unnecessary SIR system repairs.**

---

