

Windshield Wiper Arm Replacement

Removal Procedure



Important: The left-hand drive is shown. The right-hand drive is similar.

- 1. Open the hood.
- 2. Remove the nuts to access wiper arm nut from the wiper arm.
- 3. Lift wiper arm assembly away from windshield and remove wiper arm from pivot shaft.

Installation Procedure



- 1. Install the wiper arm.

Notice: Refer to [Fastener Notice](#) in Cautions and Notices.

- 2. Secure the wiper arm with the nut.

Tighten

Tighten the wiper arm nut to 22 N·m (16 lb ft).

- 3. Operate the windshield wipers and inspect for proper operation.
- 4. Close the hood.