

# Liftgate Latch Replacement

## Removal Procedure

1. Disconnect the negative battery cable. Refer to [Battery Negative Cable Disconnection and Connection](#) .



2. Remove the liftgate trim panel. Refer to [Liftgate Trim Panel Replacement](#) .
3. Disconnect the electrical connector.
4. Remove the bolts and the liftgate latch.

## Installation Procedure



1. Connect the electrical connector.

**Notice:** Refer to [Fastener Notice](#) in Cautions and Notices.

2. Install the liftgate latch with the bolts.

### Tighten

Tighten the liftgate latch bolts to 10 N·m (89 lb in).

3. Install the liftgate trim panel. Refer to [Liftgate Trim Panel Replacement](#) .
4. Connect the negative battery cable. Refer to [Battery Negative Cable Disconnection and Connection](#) .