



16. Install the instrument cluster trim panel.
17. Install the headlamp leveling switch assembly. Refer to [Headlamp Leveling Switch Replacement](#) .
18. Install the radio . Refer to [Radio Replacement](#) .
19. Install the ambient light sensor . Refer to [Ambient Light Sensor Replacement](#) .
20. Install the floor console. Refer to [Console Replacement](#) .
21. Connect the negative battery cable. Refer to [Battery Negative Cable Disconnection and Connection](#) .