
	Front Suspension	SUSPENSION	Section11 
E0500 Bolt, Wheel Mounting - Front - Right - Replace		E3537 Lower Control Arm Replacement - Both Sides	
E2147 Stabilizer Shaft Link Replacement - Both Sides		E3800 Shock Absorber, Front - Right - Replace	
E2160 Shaft, Front Stabilizer - Replace		E3801 Shock Absorber, Front - Left - Replace	
E2180 Insulator and/or Bracket, Front Stabilizer Shaft At Frame - Replace		E3807 Front Shock Absorber Replacement - Both Sides	
E2520 Steering Knuckle Replacement - Right Side		E3850 Strut, Front - Right - Replace	
E2521 Steering Knuckle Replacement - Left Side		E3851 Strut, Front - Left - Replace	
E3020 Springs, Front Coil - Right - Replace		E3857 Strut Assembly Replacement - Both Sides	
E3021 Springs, Front Coil - Left - Replace		E3900 Seat and/or Insulator, Front Spring (Upper and/or Lower) - Right - Replace	
E3027 Front Spring Replacement - Both Sides		E3901 Seat and/or Insulator, Front Spring (Upper and/or Lower) - Left - Replace	
E3530 Arm Assembly, Front Control - Lower - Right - Replace		E3910 Shield and/or Bumper, Front Strut - Right - Replace	
E3531 Arm Assembly, Front Control - Lower - Left - Replace		E3911 Shield and/or Bumper, Front Strut - Left - Replace	