



D0240 Switch, Control Assembly Master Electrical - Replace	D1810 Air Inlet Valve Actuator Replacement
D0447 Cables, Air Distribution - Air Conditioning - Temperature - R&R or Replace	N6642 HVAC System Wiring and/or Connector Repair or Replacement
D1808 Actuator and/or Motor, Electric - Mode Valve - Replace	

