



---

## Power Windows Description and Operation

The power windows are controlled by electrical switches on the door panels and are operated by a motor at each window regulator. Each door has a switch to control its window, and the driver's side door has 4 switches to control all of the door windows on the vehicle. Press the switch to lower the window and pull up on the switch to raise the window. The window will stop movement when the switch is released or when the window is completely open or closed.

The driver side window opens automatically. By pressing and releasing the switch, the window will lower and will stop only when the switch is activated again, or when the window is completely open.

The driver side door control also contains a window lock button. When depressed this button will prevent the operation of the windows on the front passenger door or the rear door.

---

