



---

# Sunroof Description and Operation

## [Power Sunroof/Sunroof Control Switch](#)

The sunroof has the following characteristics:

- Intended to provide light and air through the roof the vehicle
- Built into the roof
- Made of glass
- Equipped with a sunshade that opens and closes manually
- Powered by an electric motor
- Controlled by a switch built into the map lamp assembly.

The sunroof control switch is located on the center of the map lamp assembly.

To operate the sunroof, the ignition must be ON.

### Tilting the Sunroof, Open and Closed

To tilt open the rear end of the sunroof, press the switch rearward direction until the sunroof tilts open. To close the sunroof from a tilted-open position, press the switch forward direction until the sunroof tilts closed.

### Sliding the Sunroof, Open and Closed

To slide open the sunroof, press the switch rearward direction until the sunroof slides. If the sun shade is closed, the sunroof will pull the sunshade open when the sunroof slides open. To close the sunroof from a slid-open position, press the switch forward direction until the sunroof slides closed.

---