



3. Turn the steering wheel in order to expose the upper steering column cover panel screw holes.

**Notice:** Refer to [Fastener Notice](#) in Cautions and Notices.

4. Install the upper and the lower steering column cover panel screws.

**Tighten**

Tighten the steering column cover panel screws to 1.5 N·m (13 lb in).