



- 3. Press the wiper arm linkage onto the motor driveshaft.
- 4. Install the wiper arm linkage to the motor driveshaft with the bolts.

Tighten

Tighten the wiper arm linkage nut to 10 N·m (89 lb ft).

- 5. Install the air inlet grille. Refer to [Air Inlet Grille Panel Replacement](#) .
- 6. Connect the negative battery cable. Refer to [Battery Negative Cable Disconnection and Connection](#) .