



1. Install the connector to the driver air bag module.
2. Align the retaining pins on the driver air bag module with the steering wheel.
3. Push the driver air bag module to secure.
4. Enable the SIR. Refer to [SIR Disabling and Enabling](#) .

