



---

## Sensing and Diagnostic Module Voltage after Ignition is Turned Off Caution

**Caution:** The sensing and the diagnosis module (SDM) can maintain sufficient voltage to deploy the airbags and pretensioners for up to 1 minute after the ignition has been turned OFF and the fuse has been removed. If the airbags and pretensioners are not disconnected, do not begin service until one minute has been passed after disconnecting power to the SDM. Failure to do so may cause personal injury.

---

