



- 23. Install the knee bolster. Refer to [Knee Bolster Replacement](#) .
- 24. Install the instrument panel lower left trim. Refer to [Instrument Panel Lower Trim Panel Replacement - Left Side](#) .
- 25. Connect the instrument compartment electrical connectors.
- 26. Install the storage compartment. Refer to [Instrument Panel Storage Compartment Replacement](#) .
- 27. Install the kick panels.
- 28. Install the instrument cluster. Refer to [Instrument Cluster Replacement](#) .
- 29. Install the automatic temperature controls assembly. Refer to [Heater and Air Conditioning Control Replacement](#) .
- 30. Install the instrument cluster trim panel.
- 31. Install the headlamp leveling switch assembly. Refer to [Headlamp Leveling Switch Replacement](#) .
- 32. Install the radio . Refer to [Radio Replacement](#) .
- 33. Install the ambient light sensor . Refer to [Ambient Light Sensor Replacement](#)
- 34. Install the floor console. Refer to [Console Replacement](#) .
- 35. Connect the negative battery cable. Refer to [Battery Negative Cable Disconnection and Connection](#) .