



Important: Align the marks on the intermediate shaft and on the stub shaft.

4. Attach the intermediate shaft onto the steering gear stub shaft.

Important: When installing the lower intermediate shaft pinch bolt, ensure the bolt goes through the universal joint on the side of the stub shaft with the notch. If you have trouble seating the universal joint completely down onto the stub shaft, have an assistant unlock the steering column and rotate the steering wheel slightly while you push down on the universal joint.

5. Install the bolt into the lower universal joint on the intermediate shaft.

Tighten

Tighten the intermediate shaft pinch bolt to 34 N·m (25 lb ft).

6. Install the left front tire and wheel assembly. Refer to [Tire and Wheel Removal and Installation](#) .
7. Lower the vehicle.