

Heating Ventilation and Air Conditioning	HVAC SYSTEM	Section12
D1322 Motor and/or Fan, Blower - R&R or Replace	D2747 Hoses, Heater (Without Air Conditioning) - Both - Replace	
D1340 Housing, Front Blower Motor - R&R or Replace	D2822 Heater Core Replacement	
D1446 Deflector, Air (Outlet Vent) - Centre - Replace	D3086 Hoses and/or Lines, Refrigerant - Evaporator to Compressor - Replace	
D2009 Heater/Air Distribution Case, Passenger Compartment (Heater Module) - R&R or Replace	D3088 Hoses and/or Lines, Refrigerant - Compressor Suction and Discharge Hose Assembly - Replace	
D2232 Passenger Compartment Air Filter Housing Replacement	D3100 Hoses and/or Lines, Refrigerant - Evaporator to Condenser Line (Liquid Line) - Replace	
D2420 Case, Air Conditioning - Replace	D3140 Condenser - Replace	
D2520 Case, Air Inlet - Replace	D3320 Air Conditioning Evaporator Core Replacement	
D2744 Hoses, Heater (Without Air Conditioning) - Inlet - Replace	D3344 Core, Evaporator - Front Unit - Replace	
D2745 Hoses, Heater (Without Air Conditioning) - Outlet - Replace	D4440 Compressor Assembly - Replace	