



3. Install the upper and lower steering column cover screws.

Tighten

Tighten the upper and lower steering column cover screws to 1.5 N·m (13 lb in).