



- 8. Install the upper bracket bolts.

**Tighten**

Tighten the steering column assembly upper bracket bolts to 22 N·m (16 lb ft).

- 9. Install the SSPS control module, if equipped. Refer to [Power Steering Control Module Replacement](#) .
- 10. Install the key cylinder. Refer to [Ignition Switch Lock Cylinder Replacement](#) .
- 11. Install the immobilizer module, if equipped. Refer to [Theft Deterrent Module Replacement](#) .
- 12. Install the key hole lamp. Refer to [Ignition Lock Cylinder Bulb Replacement](#) .
- 13. Install the ignition switch. Refer to [Ignition and Start Switch Replacement](#) .
- 14. Install the driver knee bolster. Refer to [Knee Bolster Replacement](#) .
- 15. Install the coil. Refer to [Inflatable Restraint Steering Wheel Module Coil Replacement](#) .
- 16. Install the windshield wiper and washer switch. Refer to [Windshield Wiper and Washer Switch Replacement](#) .
- 17. Install the turn signal and headlamp switch. Refer to [Turn Signal Multifunction Switch Replacement](#) .
- 18. Install the steering column trim covers. Refer to [Steering Column Trim Covers Replacement](#) .
- 19. Install the steering wheel. Refer to [Steering Wheel Replacement](#) .
- 20. Install the inflatable restraint steering wheel module. Refer to [Inflatable Restraint Steering Wheel Module Replacement](#) .
- 21. Connect the negative battery cable. Refer to [Battery Negative Cable Disconnection and Connection](#) .