



Index	RESTRAINTS	0-8
Specifications	Driver or Passenger Seat Side Inflatable Restraint Module Replacement	
Component Locator	Inflatable Restraint Instrument Panel Compartment Module Disable Switch Replacement	
SIR Disabling and Enabling	Roof Side Rail Inflatable Restraint Module Replacement (AYC)	
SIR Service Precautions	Front Seat Belt Anchor Plate Tensioner Replacement	
Front End Inflatable Restraint Discriminating Sensor Replacement	Driver or Passenger Seat Shoulder Belt Replacement (with A69)	
Inflatable Restraint Side Impact Sensor Replacement	Driver or Passenger Seat Shoulder Belt Replacement (without A69)	
Inflatable Restraint Sensing and Diagnostic Module Replacement	Repairs and Inspections Required After a Collision	
Steering Wheel Inflatable Restraint Module Replacement	Inflatable Restraint Module Handling and Scrapping	
Steering Wheel Airbag Coil Replacement	Pretensioner Handling and Scrapping	
Inflatable Restraint Steering Wheel Module Coil Centering	Description and Operation	
Instrument Panel Inflatable Restraint Module Replacement	Special Tools	

