



Note: When you are lifting a vehicle with a service jack, block the wheels at the opposite end from which you are lifting. Use jack stands to provide additional support.

When using a service jack under the front of the vehicle use one of the following locations:

Front of Vehicle

Place the service jack pad in the same location as shown for the front lift pads.

Rear of Vehicle

Note: Place jackstands **ONLY** under strong and stable vehicle structures. Place the service jack pad in the same location as shown for the rear lift pads.

