



Specifications	Instrument Panel Lower Compartment Replacement
Instrument Panel Insulator Replacement	Instrument Panel Compartment Door Latch Replacement
Instrument Panel Accessory Upper Trim Plate Replacement	Instrument Panel Compartment Door Dampener Replacement
Instrument Panel Center Trim Panel Replacement	Instrument Panel Center Molding Replacement (With U58)
Instrument Panel Center Upper Molding Replacement	Instrument Panel Center Molding Replacement (Without U58)
Instrument Panel Upper Trim Panel Replacement - Right Side (Without AR1)	Instrument Panel Assembly Replacement
Instrument Panel Upper Trim Panel Replacement - Right Side (With AR1)	Instrument Panel Tie Bar Replacement
Instrument Panel Upper Trim Panel Replacement - Left Side	Front Floor Console Cover Replacement (Automatic Transmission)
Instrument Panel Fuse Block Access Hole Cover Replacement	Front Floor Console Cover Replacement (Manual Transmission)
Instrument Panel Outer Trim Cover Replacement	Front Floor Console Cup Holder Replacement
Instrument Cluster Upper Bezel Replacement	Automatic Transmission Control Indicator Opening Cover Replacement
Instrument Panel Lower Trim Pad Cover Replacement	Front Floor Console Extension Replacement - Right Side
Instrument Panel Upper Compartment Door Latch Replacement	Front Floor Console Extension Replacement - Left Side
Instrument Panel Compartment Housing Replacement (RHD)	Front Floor Console Replacement
Instrument Panel Compartment Replacement	Instrument Cluster Replacement

