

	Procedure Remove the seat belt with latch from front seat belt tensioner.
5	Driver or Passenger Seat Belt Tensioner Fastener Tighten 45 N·m (33 lb ft)
6	Driver or Passenger Seat Belt Tensioner Assembly Procedure Disconnect the electrical connector.