

5	<p>Driver or Passenger Shoulder Belt Retractor Fastener</p> <p>Tighten 45 N·m (33 lbft)</p>
6	<p>Driver or Passenger Seat Belt Push On Retainer</p> <p>Procedure</p> <p>Use a flat-bladed tool to remove locking pin in retainer.</p>
7	<p>Driver or Passenger Seat Shoulder Belt Retractor Assembly</p> <p>Procedure</p> <p>1. Disconnect the electrical connector. 2. Full deploy the module before disposal. If the module was replaced under warranty, full deploy and dispose of the module after the required retention period. Refer to Pretensioner Handling and Scrapping .</p>