

Liftgate Strut Replacement



Callout	Component Name
1	<p>Liftgate Strut</p> <p>Warning: When a lift gate hold open device is being removed or installed, provide alternate support to avoid the possibility of damage to the vehicle or personal injury.</p> <p>Caution: Apply pressure only at the end of the liftgate/hood assist rod that you are removing or attaching. Do NOT apply pressure to the middle of the rod because damage or bending will result.</p> <p>Procedure</p> <ol style="list-style-type: none">1. Release the locking tabs on the strut.2. Ensure the clip is fully seated when the strut is reinstalled. If the clip cannot be fully seated, a new strut should be installed.