



2. Align the steering wheel module fasteners to the steering column fastener holes.
3. Push the steering wheel module (1) firmly into the steering column in order to engage the fasteners.
4. Enable the SIR system. Refer to [SIR Disabling and Enabling](#) .
5. After replacing the module, fully deploy the module before disposal. If the module was replaced under warranty, fully deploy and dispose of the module after the required retention period. Refer to [Inflatable Restraint Module Handling and Scrapping](#) .