



4. Install the NEW lower ball joint bolt (2) and nut (1) and tighten the to nut (1):
- First Pass: **30N·m (22 lb ft)**
 - Final Pass: **plus an additional 35 degrees**
5. Install the tire and wheel assembly. Refer to [Tire and Wheel Removal and Installation](#) .
6. Remove the support and lower the vehicle.