



off. The vehicle has a PASSENGER AIR BAG ON/OFF indicator to tell the customer when the passenger air bag is on or off based on the disable switch position.

Seat Belt Indicators

The seat belt indicators are controlled through the inflatable restraint sensing and diagnostic module (SDM). For further information on seat belt indicators refer to [Seat Belt System Description and Operation](#) .

