



Index	HEATING VENTILATION AND AIR CONDITIONING	11
Specifications	Heater Inlet Hose Replacement (1.2L or 1.4L)	
Refrigerant Recovery and Recharging	Heater Inlet Hose Replacement (Diesel)	
Flushing	Side Window Defogger Outlet Grille Replacement	
Air Conditioning Compressor Replacement (1.6L or 1.8L)	Instrument Panel Outer Air Outlet Replacement - Left Side	
Air Conditioning Compressor Replacement (1.2L or 1.4L)	Instrument Panel Center Air Outlet Replacement	
Air Conditioning Compressor Replacement (Diesel)	Instrument Panel Outer Air Outlet Replacement - Right Side	
Air Conditioning Compressor Bracket Replacement (Diesel)	Instrument Panel Outer Air Outlet Duct Replacement	
Air Conditioning Compressor and Condenser Hose Replacement (1.6L or 1.8L)	Floor Air Outlet Duct Replacement - Left Side (RHD)	
Air Conditioning Compressor and Condenser Hose Replacement (1.2L or 1.4L)	Floor Air Outlet Duct Replacement - Right Side (RHD)	
Air Conditioning Compressor and Condenser Hose Replacement (Diesel)	Floor Rear Air Outlet Duct Replacement - Left Side	
Air Conditioning Evaporator Hose Assembly Replacement	Floor Rear Air Outlet Duct Replacement - Right Side	
Air Conditioning Condenser Replacement	Heater and Air Conditioning Control Replacement	
Heater and Air Conditioning Evaporator and Blower Module Replacement	Description and Operation	
Heater Inlet Hose Replacement (1.6L or 1.8L)	Special Tools	
Heater Outlet Hose Replacement (1.6L or 1.8L)		
Heater Outlet Hose Replacement (1.2L or 1.8L)		

