

Tail Lamp Replacement (Hatchback)



Callout	Component Name
<p>Preliminary Procedure</p> <p>Open and support the liftgate assembly.</p>	
1	<p>Tail Lamp Bolt/Screw (Qty: 2)</p> <p>Caution: Refer to Fastener Caution .</p> <p>Tighten 2.5N·m (22lbin)</p>
2	<p>Tail Lamp Assembly</p> <p>Procedure</p> <p>1. Hold both sides of the tail lamp assembly and give a quick pull rearward in order to disengage the two locator pins from the bodyside outer panel.</p> <p>2. Rotate all three bulb sockets and remove from the tail lamp housing, being careful not to damage the exposed bulbs.</p> <p>3. Disengage the tail lamp bulb electrical harness from the retainer clips on the tail lamp housing.</p>