


## Tail Lamp Pocket Replacement (5HB)

### Removal Procedure


**Warning:** Refer to [Approved Equipment for Collision Repair Warning](#) .

**Warning:** Refer to [Glass and Sheet Metal Handling Warning](#) .

1. Disable the SIR system. Refer to [SIR Disabling and Enabling](#) .
2. Disconnect the negative battery cable. Refer to [Battery Negative Cable Disconnection and Connection](#) .
3. Remove all related panels and components.
4. Visually inspect the damage. Repair as much of the damage as possible.
5. Remove the sealers and anti-corrosion materials from the repair area, as necessary. Refer to [Anti-Corrosion Treatment and Repair](#) .
6. Locate and mark all the necessary factory welds of the body rear end panel.



7. Drill all factory welds (1). Note the number and location of welds for installation of the service assembly.



8. Remove the tail lamp pocket (1).