

Driver or Passenger Seat Cushion Frame Replacement



Callout	Component Name
<p>Preliminary Procedures</p> <p>1. Remove the driver or passenger seat. Refer to Driver or Passenger Seat Replacement</p> <p>2. Remove the front seat cushion outer trim panel. Refer to Front Seat Cushion Outer Trim Panel Replacement</p> <p>3. Remove the front seat cushion inner recliner. Refer to Front Seat Cushion Inner Trim Panel Replacement</p>	
1	<p>Front Seat Cushion Frame Bolt (Qty: 4)</p> <p>Caution: Refer to Fastener Caution .</p> <p>Tighten 22 N·m (16 lbft)</p>
2	<p>Driver or Passenger Seat Cushion Frame</p> <p>Procedure</p> <p>1. Disconnect electrical connectors as needed.</p> <p>2. If replacing with a new front seat cushion frame, transfer components as necessary.</p>