


Stabilizer Shaft Link Replacement



Callout	Component Name
<p><b>Preliminary Procedure</b></p> <p>1. Raise and Support the vehicle. Refer to <a href="#">Lifting and Jacking the Vehicle</a> .</p> <p>2. Remove the tire and wheel assembly. Refer to <a href="#">Tire and Wheel Removal and Installation</a> .</p>	
1	<p>Front Stabilizer Shaft Link Upper Nut</p> <p><b>Caution:</b> Refer to <a href="#">Fastener Caution</a> .</p> <p><b>Procedure</b></p> <p>1. Use the proper size Allen wrench to hold the stabilizer shaft link stud when loosening or tightening the stabilizer shaft link nut.</p> <p>2. Remove and discard the stabilizer shaft link nut. Replace with NEW only.</p> <p><b>Tighten</b> 65 N·m (48 lbft)</p>
2	<p>Front Stabilizer Shaft Link Lower Nut</p> <p><b>Procedure</b></p> <p>1. Use the proper size Allen wrench to hold the stabilizer shaft link stud when loosening or tightening the stabilizer shaft link nut.</p> <p>2. Remove and discard the nut. Replace with NEW only.</p> <p><b>Tighten</b> 65 N·m (48 lbft)</p>
3	<p>Front Stabilizer Shaft Link</p>