

Transmission Fluid Vent Cap Removal Caution

Caution: The fluid vent cap must be removed before checking the fluid level, in order to ensure the proper level. Improper fluid level may damage the transmission.