



operation of the inflatable restraint impact sensing system. Do not try to determine whether the sensor is undamaged, replace the inflatable restraint impact sensor. Also, if you follow a diagnostic trouble code (DTC) procedure and a malfunctioning sensor is indicated, replace the inflatable restraint impact sensor.

