



1. After remounting and inflating the tire, check both beads, the repair and the valve with a water and soap solution in order to detect leaks.
2. If the tire continues to lose air, the tire must be demounted and reinspected.
3. Balance the tire and wheel assembly. Refer to [Tire and Wheel Assembly Balancing - Off Vehicle](#).

For additional tire puncture repair information, contact:

Rubber Manufacturers Association (RMA)
1400 K Street, N.W., Suite 900
Washington, DC 20005-2403

Telephone: 202-682-4800

E-mail: info@rma.org

Website: www.rma.org