


12. Lay the wire under the rear window all the way round.  
Pull the remaining wire into the interior.


**Note:** The cutting wire (1) should be rolled in beneath the rubber window seal (2) at the rear window.



13. Place the winch with two winding heads in the vehicle.

**Note:** Ensure that the cutting wire is fitted correctly to the winch deflection roller.

- Position the winch vertically at the same height as the C-pillar (2).
  - Attach the cutting wire to the winch (1).
  - Insert transfer ratchet and pre-tension cutting wire.
14. Cut out rear window.
- Cut out the rear window until the cutting wire is level with the winch.
  - Arrow shows the path taken by the cutting wire.



15. Place the winch with two winding heads in the vehicle.

**Note:** Ensure that the cutting wire is fitted correctly to the winch deflection roller.

- Position the winch (2) in the area of the roof frame.
  - Insert transfer ratchet and pre-tension cutting wire (1).
16. Cut out rear window.

**Note:** Increased cutting effort is required in the area of the rear window radius.

- Cut out the rear window until the cutting wire is level with the winch.