



- 3. Install the wheel speed sensor (1).
- 4. Install the wheel speed sensor bolt (2) and tighten to **6 N·m (54 lb in)**.
- 5. Remove the support (1) from the brake backing plate.
- 6. Install the plug to the drum brake actuator access hole in the backing plate.
- 7. Install the brake drum. Refer to [Brake Drum Replacement](#).
- 8. Install the tire and wheel assembly. Refer to [Tire and Wheel Removal and Installation](#).
- 9. Remove the support and lower the vehicle.