

If a child seat is to be used in the second seat position, a special dealer-installed anchor must be used in order to anchor the child seat top strap. This only applies to the seats designed with the top strap provision and for the vehicles sold in Canada. In order to ensure the correct top strap angle, the child seat is only to be used at the seating position for which the top strap anchor is installed.

Fasten Safety Belt Indicators

There are 2 fasten safety belt indicators for this vehicle. The driver fasten safety belt reminder is monitored on the instrument cluster and the passenger fasten safety belt reminder is located in the PASSENGER AIR BAG ON/OFF status indicator near the center of the instrument panel. The fasten safety belt indicator may only be ON during RUN. The instrument cluster illuminates the fasten safety belt indicator under the following conditions:

- During the bulb check
- The inflatable restraint sensing and diagnostic module (SDM) sends the status of the driver and passenger seat belt switch to the instrument cluster via a serial data. If the seat belt is unfastened, the instrument cluster will send a message requesting a chime sound to be turned ON after a bulb check.