

Disabling Procedure - Negative Battery Cable

- 1. Turn the steering wheel so that the vehicles wheels are pointing straight ahead.
- 2. Place the ignition in the OFF position.
- 3. Disconnect the negative battery cable from the battery. Refer to [Battery Negative Cable Disconnection and Connection](#).
- 4. Wait 1 minute before working on system.

Enabling Procedure - Negative Battery Cable

- 1. Place the ignition in the OFF position.
- 2. Connect the negative battery cable to the battery. Refer to [Battery Negative Cable Disconnection and Connection](#).
- 3. Turn the ignition switch to the ON position. The AIR BAG indicator will flash then turn OFF.
- 4. Perform the Diagnostic System Check - Vehicle if the AIR BAG warning indicator does not operate as described. Refer to [Diagnostic System Check - Vehicle](#).