



Hvac Automatic

HVAC SYSTEM

Section 12



D0362 Heater and Air Conditioning Control Replacement	D1212 Inside Air Temperature Sensor Replacement
D0371 Heater and Air Conditioning Remote Control Replacement	D1809 Temperature Valve Actuator Replacement
D0399 Vent Valve Lever Replacement	D1810 Air Inlet Valve Actuator Replacement
D0889 Heater and Blower and Air Conditioning Control Module Replacement	D1825 Mode Valve Actuator Gear Replacement
D1202 Sun Load Temperature and Headlamp Automatic Control	D1826 Air Inlet Valve Actuator Gear Replacement
Ambient Light Sensor Replacement	D1829 Mode Control Cam Actuator Replacement
D1208 Ambient Air Quality Sensor Replacement	D1831 Mode Control Cam Replacement
	D1832 Air Inlet Valve and Inside Air Valve Control Cam Replacement