



-
4. Enable the SIR system. Refer to [SIR Disabling and Enabling](#).
 5. After replacing the module, fully deploy the old module before disposal.