

- *CH 6615-10* cylinder (1).
 - *CH-49233* adapter (2).
 - NEW rear axle bushing (3).
 - *CH 906-42* adapter (4)
 - Install and tighten counter nut (5) onto spindle of *CH 6615-10* cylinder (1)
10. Connect pressure hose (6) of *CH 6616* pump to *CH 6615-10* cylinder
 11. Press carefully the rear axle bushing in to rear axle, using *CH 6616* pump .
 12. When lift way of *CH 6615-10* cylinder reaches stop, release pressure on *CH 6616* pump , retighten counter nut (5) and press rear axle bushing in to rear axle until final installation position.
 13. Remove ALL special tools.
 14. Install rear axle. Refer to [Rear Axle Replacement](#)