

## Front Side Door Outer Panel Replacement (MAG-Welding)

### Special Tools

- BO-6396 Bonding Pliers
- BO-6392 Flanging Tool Kit


For equivalent regional tools, refer to [Special Tools](#)

**Note:** According to different corrosion warranties, only the regional mandatory joining methods are allowed.


### Removal Procedure

**Warning:** Refer to [Glass and Sheet Metal Handling Warning](#) in the Preface section.

1. Disable the SIR System. Refer to [SIR Disabling and Enabling](#).
2. Disconnect the negative battery cable. Refer to [Battery Negative Cable Disconnection and Connection](#).
3. Remove the front side door. Refer to [Front Side Door Replacement](#).
4. Remove the front side door outside handle. Refer to [Front Side Door Outside Handle Replacement](#).
5. Remove the outside rearview mirror. Refer to [Outside Rearview Mirror Replacement](#).
6. Remove the sealers and anti-corrosion materials from the repair area, as necessary. Refer to [Anti-Corrosion Treatment and Repair](#).



7. Grind the edges of the front side door outer panel to separate the outer door panel from the door shell.



8. Remove the front side door outer door panel.
9. Remove the sealers and anti-corrosion materials from the repair area, as necessary. Refer to [Anti-Corrosion Treatment and Repair](#).
10. Straighten the edges of the door shell.

### Installation Procedure

1. Align the front side door outer panel.
2. Verify the fit of the front side door outer panel.