

Select a Document:

-  [Specifications](#)
-  [Module Power, Ground, and MIL](#)
-  [Front Impact Sensor, Retractors, and Driver/Passenger Air Bags](#)
-  [Side Impact Sensors and Side/Roof Air Bags](#)
-  [Air Bag Indicator and Disable Switch \(C99\)](#)
-  [SIR Identification Views](#)
-  [SIR Service Precautions](#)
-  [Front End Inflatable Restraint Discriminating Sensor Replacement](#)
-  [Inflatable Restraint Side Impact Sensor Replacement](#)
-  [Inflatable Restraint Sensing and Diagnostic Module Replacement](#)
-  [Steering Wheel Inflatable Restraint Module Replacement](#)
-  [Steering Wheel Inflatable Restraint Module Coil Replacement](#)
-  [Inflatable Restraint Steering Wheel Module Coil Centering](#)
-  [Instrument Panel Inflatable Restraint Module Replacement](#)
-  [Driver or Passenger Seat Side Inflatable Restraint Module Replacement](#)
-  [Roof Side Rail Inflatable Restraint Module Replacement](#)
-  [Driver or Passenger Seat Retractor Side Belt Replacement](#)
-  [Repairs and Inspections Required After a Collision](#)
-  [Inflatable Restraint Module Handling and Scrapping](#)
-  [Pretensioner Handling and Scrapping](#)
-  [SIR System Description and Operation](#)
-  [SIR Disabling and Enabling](#)
-  [Special Tools and Equipment](#)