

Select a Document:

-  [Specifications](#)
-  [Refrigerant Recovery and Recharging](#)
-  [Air Conditioning Compressor Replacement \(1.6L LDE, LXV, and 1.8L 2H0\)](#)
-  [Air Conditioning Compressor Replacement \(1.6L LXT\)](#)
-  [Air Conditioning Compressor and Condenser Hose Replacement \(1.6L LXT\)](#)
-  [Air Conditioning Compressor and Condenser Hose Replacement \(1.6L LDE, LXV, and 1.8L 2H0\)](#)
-  [Air Conditioning Evaporator Hose Assembly Replacement](#)
-  [Air Conditioning Condenser Replacement \(1.6L LDE, LXT, LXV, and 1.8L 2H0\)](#)
-  [Instrument Panel Outer Air Outlet Replacement - Left Side](#)
-  [Instrument Panel Center Air Outlet Replacement](#)
-  [Instrument Panel Outer Air Outlet Replacement - Right Side](#)
-  [Radio Cooling Duct Replacement \(Right Hand Drive\)](#)
-  [Floor Air Outlet Replacement](#)
-  [Instrument Panel Outer Air Outlet Duct Replacement](#)
-  [Floor Air Outlet Duct Replacement - Left Side \(Right Hand Drive\)](#)
-  [Floor Air Outlet Duct Replacement - Right Side \(Right Hand Drive\)](#)
-  [Floor Rear Air Outlet Duct Replacement - Left Side](#)
-  [Floor Rear Air Outlet Duct Replacement - Right Side](#)
-  [Heater and Air Conditioning Remote Control Replacement](#)
-  [Heating and Air Conditioning System Description and Operation](#)
-  [Special Tools and Equipment](#)