

Steering Gear Replacement (Hydraulic Power Steering)


Special Tools

EN 45059 Torque Angle Sensor Kit


For equivalent regional tools, refer to [Special Tools](#).

Removal Procedure


1. Turn the front wheels to the straight forward position and secure the steering wheel from moving.



2. Remove the lower steering intermediate shaft bolt (1).
3. Remove the steering intermediate shaft from the steering gear.
4. Raise and support the vehicle. Refer to [Lifting and Jacking the Vehicle](#).
5. Remove the tire and wheel assemblies. Refer to [Tire and Wheel Removal and Installation](#).
6. Remove the exhaust flexible pipe. Refer to [Exhaust Flexible Pipe Replacement](#).
7. Remove the front compartment splash shield. Refer to [Front Compartment Splash Shield Replacement](#).
8. Remove the front compartment insulator, if equipped. Refer to [Front Compartment Insulator Replacement](#).
9. Remove the steering linkage inner tie rod. Refer to [Steering Linkage Inner Tie Rod Replacement](#).



10. Remove and discard the stabilizer link shaft nut (1) from the strut.
11. Remove the stabilizer link shaft from the strut.
12. Place a large container under the vehicle in order to collect the draining fluid.



13. Remove the power steering gear inlet and outlet hose bolt (1), remove the inlet and outlet hose (2) from the steering gear (3).