



3. Install the strut mount insulator washer (3).

Caution: Refer to [Fastener Caution](#) in the Preface section.

- 4. Install the strut nut (2) to the strut shaft and tighten to **70 N·m (52 lb ft)**.
- 5. Remove the *CH-6068* tensioner (1) from the spring (4).
- 6. Remove the front strut from *CH-6066* holder (5).
- 7. Install the strut assembly. Refer to [Strut Assembly Replacement](#).