



- 5. Install the wheel speed sensor (1) to the steering knuckle.
- 6. Install the wheel speed sensor screw (2) and tighten to **6 N·m (54 lb in)**.
- 7. Install the brake rotor. Refer to [Front Brake Rotor Replacement](#).
- 8. Remove the support and lower the vehicle.

